

# **FURUNO**

# **INSTALLATION MANUAL**

**MARINE RADAR/ARPA**

**MODEL FR/FAR-2825W/2855W**



**FURUNO ELECTRIC CO., LTD.**  
NISHINOMIYA, JAPAN

© **FURUNO ELECTRIC CO., LTD.**

9-52, Ashihara-cho,  
Nishinomiya, Japan

Telephone: 0798-65-2111  
Telefax: 0798-65-4200

•Your Local Agent/Dealer

All rights reserved.

Printed in Japan

FIRST EDITION : FEB. 1996  
G : AUG. 8, 2001

(YOSH)

PUB. No. IME-34050-G  
FAR/FR-2825/2855W



\* 00080727000 \*

# **SAFETY INSTRUCTIONS**

"**DANGER**", "**WARNING**" and "**CAUTION**" notices appear throughout this manual. It is the responsibility of the installer of the equipment to read, understand and follow these notices. If you have any questions regarding these safety instructions, please contact a FURUNO agent or dealer.

## **DANGER**

This notice indicates a potentially hazardous situation which, if not avoided, will result in death or serious injury.

## **WARNING**

This notice indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

## **CAUTION**

This notice indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or property damage.

## **DANGER**



**Hazardous voltage.**  
Can shock, burn, or cause death.

Only qualified personnel should work in the units of a radar system.

**Turn off the power at the ship's mains switchboard before beginning the installation. Post a warning sign near the switchboard to ensure the power will not be applied while the radar system is being installed.**

Electrical shock, fire, serious injury or death can result if the power is not turned off, or is applied while the equipment is being installed.

## **WARNING**



**Turn off the radar power switch before working on the antenna unit. Post a warning sign near the switch to ensure it will not be turned on while the antenna unit is being installed.**

Serious injury or death can result if the radiator starts rotating and strikes someone near the scanner unit.



**Wear a safety belt and hard hat when working on the antenna unit.**

Serious injury or death can result if someone falls from the scanner mast.

## **WARNING**



**Microwave radiation can be harmful to the human body, particularly the eyes.**

Do not look into a transmitting antenna from a distance of less than 2.0 meter (7 feet).

## **WARNING**

**The neck of the scanner unit becomes VERY HOT when the de-icer is working.**

Before beginning any work on the scanner unit, turn off the breaker for the de-icer line at the main switchboard to remove the power (100VAC, 1Ø) to the de-icer. (Turning off the power to the display unit has no effect.)

## **CAUTION**



**Ground both the display unit and the antenna unit.**

Ungrounded equipment can cause mutual interference or electrical shock.

**Confirm that the power supply voltage is compatible with the voltage rating of the equipment.**

Connection to the wrong power supply can cause fire or equipment damage. The voltage rating appears on the label at the rear of the display unit.

**Use only the supplied power cable.**

Use of other power cables (particularly cables whose diameter is smaller than the supplied cable) can cause fire or short circuit.

**Use the correct fuse.**

Use of a wrong fuse can cause fire or equipment damage.

# TABLE OF CONTENTS

---

<b>SAFETY INSTRUCTIONS</b>	<b>i</b>
----------------------------	----------

<b>EQUIPMENT LISTS</b>	<b>iv</b>
------------------------	-----------

<b>SYSTEM CONFIGURATION</b>	<b>vi</b>
-----------------------------	-----------

## **1. MOUNTING**

---

1.1 Assembling the Scanner Unit	1-1
1.2 Mounting the Antenna Unit on the Mounting Platform	1-4
1.3 Mounting the Display Unit	1-8
1.4 Mounting the Separate Type Control Panel	1-9
1.5 Transceiver Unit	1-10
1.6 Power Supply Unit	1-10

## **2. CONNECTIONS**

---

2.1 Antenna Unit Connections	2-1
2.2 Transceiver Unit Connections	2-3
2.3 Installing the Rectangular Waveguide (WRJ-9)	2-7
2.4 Aligning the Circulator with the Output Waveguide (FR-2855W only)	2-8
2.5 Display Unit Connection	2-9
2.6 Power Supply Unit	2-16

## **3. INITIALIZATION AND ADJUSTMENT**

---

3.1 Setting Operating Voltage of Fan Motor	3-1
3.2 Menus for Initialization and Adjustment	3-1
3.3 Heading Alignment	3-2
3.4 Adjusting Sweep Timing	3-3
3.5 Adjusting Video Signal Level	3-4
3.6 Suppressing Main Bang	3-4
3.7 Confirming Tuning	3-5
3.8 Confirming Magnetron Heater Voltage	3-6
3.9 Initial Setting Menus	3-8
3.10 Setting the Function Keys	3-9
3.11 Default of Initial Setting Menus	3-12
3.12 Adjusting ARP Board	3-13
3.13 Installation Check List	3-15

## **4. INSTALLATION OF GYRO CONVERTER GC-8 (option)**

---

4.1 General Procedure for Installing and Setting up the GYRO CONVERTER Board	4-1
4.2 Connection of External Power Supply	4-3
4.3 Confirming Gyrocompass Specifications	4-3
4.4 Changing Settings on the GYRO CONVERTER Board	4-4
4.5 Setting the Bearing on the Radar Display	4-8

# EQUIPMENT LISTS


## Complete set

No.	Name	Type	Qty	Remarks
1	Scanner unit		1	
2	Display unit	RDP-115	1	Pedestal mount type
				Tabletop type
3	Accessories	FP03-05710	1 set	For built-in control unit
		FP03-05730		For separate control unit
		FP03-05704		Hood
		FP03-05705		Hand grips
4	Installation materials	CP03-14401	1 set	For scanner unit
		CP03-14602	1 set	For display unit
5	Signal cable	RW-4873 *15m*	1	no armor
		RW-4873 *20m*		
		RW-4873 *30m*		
		RW-6875 *15m*		w/armor
		RW-6875 *20m*		
		RW-6875 *30m*		
6	Spare parts	SP03-08902	1 set	For scanner unit
		SP03-11301	1 set	For display unit

## **Optional equipment**

<b>No.</b>	<b>Name</b>	<b>Type</b>	<b>Code No.</b>	<b>Remarks</b>
1	M card fixing plate	OP03-133	008-452-400	
2	Display unit cover	OP03-126	008-459-820	Tabletop w/built-in control unit
		OP03-127	008-459-760	Tabletop w/separate control unit
		OP03-128	008-459-890	Pedestal mount
3	Display unit conversion kit	OP03-129-1	008-459-830	Converts from tabletop type/built-in control unit to pedestal mount
		OP03-129-2	008-452-410	
		OP03-130-1	008-459-900	Converts from tabletop type/separate control unit to pedestal mount
		OP03-130-2	008-452-430	
		OP03-131	008-459-910	Converts from pedestal mount to tabletop type/built-in control unit
		OP03-132-1	008-459-920	Converts from pedestal mount to tabletop type/separate control unit
		OP03-132-2	008-452-450	
4	Control panel fixing plate	OP03-134	008-461-340	For fastening separate type control unit to a tabletop
5	Video plotter	RP-25		
6	Gyro converter	GC-8-2	008-446-520	With installation materials
7	Interswitch	RJ-7		
8	External buzzer	OP03-21	000-030-097	1 m, with connector
9	Performance monitor	PM-30		
10	Range unit conversion kit	OP03-110-1	008-446-610	To km
11	Range unit conversion kit	OP03-110-2	008-452-200	To sm
12	Color display unit	CD-141		
13	Slave display unit	FMD-8000		
14	Transformer unit	RU-1758	000-030-416	Converts 220 VAC to 100 VAC
15	Transformer unit	RU-1803	000-030-420	Converts 440 VAC to 100 VAC
16	Interswitch	RJ-8		

# SYSTEM CONFIGURATION






# 1. MOUNTING

## 1.1 Assembling the Scanner Unit

### FR/FAR-2825W: XN20AF (206 cm), XN24AF (220 cm)

The scanner unit consists of the scanner radiator and the scanner unit chassis, and they are packed separately. Fasten the scanner radiator to the scanner unit chassis as follows:

1. Attach two guide pins to the underside of the scanner radiator.
2. Remove the waveguide cap from the radiator bracket. The cap may be discarded.
3. Coat the waveguide flange with anticorrosive sealant as shown in Figure 1-2.



*Figure 1-1 Coating the waveguide flange with anticorrosive sealant*


4. Coat fixing holes for the scanner radiator with anticorrosive sealant.
5. Grease the O-ring and set it to the O-ring groove of the radiator flange.
6. Set the scanner radiator to the radiator bracket.
7. Coat hex bolts (M8 x 40, slotted washer head, 8 pcs.) with anticorrosive sealant and use them to loosely fasten the scanner radiator to the scanner unit chassis.
8. Remove two guide pins (inserted at step 1), and then tighten fixing bolts.



### CAUTION


**Be sure to remove the guide pins.**

Injury may result if the guide pins loosen and fall.



*Figure 1-2 Fastening the radiator to the radiator bracket*

### **FR/FAR-2855W: Radiator XN3A (200 cm)/XN4A (240 cm)**



*Figure 1-3 Assembling antenna radiator XN3A/XN4A*

## Procedure


*Table 1-1 XN3A/XN4A antenna assembly materials*

- 1) Remove the radiator joint flange cap. The cap may be discarded.
- 2) Wipe the feeder waveguide and radiator joint with a clean cloth.
- 3) Coat the waveguide flange with silicone sealant as shown on the next page.
- 4) Insert the O-ring (1) into the O-ring groove of the radiator flange of the rotary joint. Fix the feeder waveguide with hex. bolts (2).

No.	Name	Specification	Qty
1	O-ring	AS568-125	2
2	Washerhead Hex. Bolt (B)	M4 x 16(SUS304)	8
3	Hex. Bolt (B)	M8 x 35(SUS304)	4
4	Spring Washer	M8(SUS304)	4
5	Flat Washer	M8(SUS304)	4
6	Hex. Bolt	M8 x 30(SUS304)	4
7	Flat Washer	M8(SUS304)	8
8	Spring Washer	M8(SUS304)	4
9	Hex. Nut	M8(SUS304)	4
10	Hex. Bolt	M4 x 30(SUS304)	2
11	Spring Washer	M4(SUS304)	2
12	Flat Washer	M4(SUS304)	2
13	W/G Clamp	RSB-2006-1	1
14	W/G Gasket	03-003-4003-1	1

## Coating the waveguide flange with silicone sealant

1. Do not coat the O-ring with silicone sealant; use grease.
2. Clean the surface of the waveguide flange, if necessary. Evenly coat the waveguide flange with silicone sealant as shown in the illustration below.



Evenly coat the waveguide flange with silicone sealant. Apply sealant sparingly; it leaks out slightly when the fixing bolts are tightened. Be sure no sealant contacts the choke groove and waveguide.

*Figure 1-4 Coating the waveguide flange with silicone sealant*

## 1.2 Mounting the Antenna Unit on the Mounting Platform



### CAUTION

- 1) Work at high places is dangerous. Always wear a hard hat and safety belt when working on the scanner unit mast.
- 2) Both a service platform and steps to the service platform must be mounted to provide safe access for service personnel. Improperly installed platforms present a hazard to service personnel.

### Siting considerations

### CAUTION



A magnetic compass will be affected if placed too close to the antenna unit. Below are the minimum safe distances for magnetic compasses.


Radar model	Standard compass	Steering compass
FR/FAR-2825W	1.20m	0.75m
FR/FAR-2855W	2.0m	1.5m



Consider the following points when selecting a mounting location for the antenna unit.

- No funnel, mast or derrick should be within the vertical beamwidth of the antenna (XN3A/XN4A, 20°) in the bow direction, especially zero degrees  $\pm 5^\circ$ , to prevent blind sectors and false echoes on the radar picture.
- Fumes from the funnel or other exhaust vent can adversely affect performance and hot gas can distort the radiator. The antenna unit must not be mounted in a place where the temperature may exceed 70°C.
- Leave sufficient space around the unit for maintenance and servicing. See the antenna unit outline drawing for recommended maintenance space.
- Locate the unit well away from the aerial of a radiotelephone or navigation receiver to prevent interference. Separation of more than two meters is recommended.

The scanner unit is normally mounted with the waveguide outlet facing the ship's stern however the waveguide outlet can be faced toward port or starboard as well. In this case, the synchronous gear magnet (See below), which produces the heading single, should be remounted. Fix the magnet according to waveguide outlet attitude.




*Fig1-5 Remounting the Synchronous Gear Magnet*

## Mounting procedure

# CAUTION

- 1) The antenna radiator may be fastened to the rotating bracket before mounting the antenna unit. However, **DO NOT** lift the antenna unit by the radiator. Always hold the unit by its housing. When using a crane or hoist, lift the unit by the hoist rings which should be fastened to the bolt fixing the covers of the antenna housing.
- 2) The antenna unit is constructed of aluminum and therefore subject to galvanic corrosion if improperly fastened to steel structures. To prevent galvanic corrosion, fasten the unit to the mounting platform using the rubber mat and washers (supplied).
- 3) **DO NOT** paint the radiator. Performance will be affected.

- 1) Drill four mounting holes (15mm diameter) and one cable entry hole (50mm diameter approximately) in the mounting platform.
- 2) Lay the rubber mat (supplied) on the mounting platform.




*Figure 1-6 Antenna unit, front view*


- 3) Place the antenna unit on the rubber mat and orient the unit so the bow mark on its base is facing the ship's bow.
- 4) Fasten the antenna unit to the mounting platform with M12 x 60 bolts, nuts, flat washers and seal washers.

# CAUTION


**DO NOT** lift the antenna unit by the radiator; lift it by the hoist rings. (Be sure to remove rings after hoisting the antenna unit.)



- 5) Using hex bolt (M6x25), nut (M6) and flat washer (M6) establish the ground system on the mounting platform as shown in Figure 1-7.
- 6) Connect the ground wire (RW-4747, 340 mm) between the grounding point and the ground terminal on the antenna unit.
- 7) Coat the ground point and the ground terminal with silicone sealant (supplied) as shown in Figure 1-5 to prevent corrosion.



*Figure 1-7 Fastening the antenna unit to the mounting location*



## CAUTION

The antenna unit must be grounded. Failure to ground the unit may cause electrical shock when its metallic parts are touched and give off or receive electro-magnetic interference.

## 1.3 Mounting the Display Unit



The display unit is designed to be mounted on a tabletop or on a pedestal (option).

### Before mounting the display unit

If Gyro Converter GC-8 (option) is to be used, install and setup the GYRO PROCESSOR Board before mounting the display unit, because of the difficulty involved if done after the unit is mounted. Instructions for installation and setup are in Chapter 4.

### Siting considerations

Locate the display unit on the bridge in a place where it can be viewed and operated conveniently. In addition, consider the points noted in the figure which follows.

<h1>CAUTION</h1>	
	<p>A magnetic compass will be affected if placed too close to the display unit. The minimum compass safe distances for magnetic compasses are</p> <p>standard compass: 1.6 m steering compass: 1.2 m</p>
	<p>Consider the points mentioned below when selecting a mounting location for the display unit.</p> <ul style="list-style-type: none"><li>• The orientation of the display unit should be so the operator views the screen while facing the bow. This makes determination of position much easier.</li><li>• The location should be free of water spray.</li><li>• The daylight bright type radar display provides excellent visibility even in direct sunlight. However, locate the unit out of direct sunlight and away from heat sources because of heat that can build up inside the cabinet.</li><li>• The mounting location should be determined considering the length of the signal cable between the transceiver unit and the display unit. (The signal cable comes in lengths of 15, 30 or 50 meters; maximum 100 meters.)</li><li>• Leave sufficient space around the unit for maintenance and servicing. See the display unit outline drawing for recommended maintenance space.</li></ul>



## Mounting procedure

### Tabletop


- 1) Unfasten the three M10 bolts at the front of the display unit and separate the mounting base from the display unit.
- 2) Drill five holes of 12mm diameter in the tabletop.
- 3) Secure the mounting base to the tabletop by using M10 nuts, bolts and flat washers.
- 4) Place the display unit on the mounting base and fasten it to the mounting base with the bolts removed in step 1.

### Pedestal

Fix the pedestal to the mounting location with M12 nuts, bolts and washers. (The cable gland is at the bottom of the pedestal.)

## 1.4 Mounting the Separate Type Control Panel

The separate type control panel connects to the display unit with a connection cable. Non-slip rubber feet (supplied) can be attached to the bottom of the control panel. The panel can be permanently fixed to a tabletop with the control panel fixing plate kit (option).



*Figure 1-8 Mounting dimensions for tabletop mount display unit*

## 1.5 Transceiver Unit


The transceiver unit is designed for bulkhead mounting, and may be mounted in any dry, well-ventilated place. Ensure the mounting location is strong enough to support the weight of the unit under the continued shock and vibration normally encountered onboard. The transceiver must not be installed in close proximity of a magnetic compass; observe the compass safe distances.

Fix the unit to the bulkhead with four bolts (FR/FAR-2825W: M10, FR/FAR-2855W: M12). Run a ground wire (8mm<sup>2</sup>) between the ship's body and the transceiver unit, using the lug supplied to make the connection at the earth stud on the transceiver unit. Keep the length of the ground wire as short as possible.

## 1.6 Power Supply Unit

The power supply unit can be installed almost anywhere provided the location is dry, well-ventilated, the compass safe distances are observed and sufficient maintenance space is provided.


The unit may be installed inside the display unit console type.

<b>CAUTION</b>										
	A magnetic compass will be affected if placed too close to the transceiver/power supply units. The minimum compass safe distances for magnetic compasses are									
	<table border="1"><thead><tr><th>Unit</th><th>Standard compass</th><th>Steering compass</th></tr></thead><tbody><tr><td>Transceiver Unit 25W 55W</td><td>4.3 m 2.5 m</td><td>3.2 m 2.0 m</td></tr><tr><td>Power Supply Unit</td><td>0.7 m</td><td>0.5 m</td></tr></tbody></table>		Unit	Standard compass	Steering compass	Transceiver Unit 25W 55W	4.3 m 2.5 m	3.2 m 2.0 m	Power Supply Unit	0.7 m
Unit	Standard compass	Steering compass								
Transceiver Unit 25W 55W	4.3 m 2.5 m	3.2 m 2.0 m								
Power Supply Unit	0.7 m	0.5 m								

## 2. CONNECTIONS


### 2.1 Antenna Unit Connections

1. Remove the scanner cover with the wrench supplied.
2. Unscrew the cable gland and take out the washers and rubber packing.
3. Cut the cable to a suitable length, extending the length actually required by 600mm. Strip off about 600mm of the inner vinyl sheath. Wrap vinyl tape around the areas indicated below.




*Fig. 2-1*

4. Slide the clamping gland, washers and rubber packing on to the cable as shown below.



*Fig. 2-2*

5. Fix cable cores with cable ties (see below). Trim cores considering their location on STB1/2/3, fit a crimp-on lug (STB1/STB3 .... FV1.25-3, STB2 .... FV2-4) to each core. Connect lugs to terminal boards. Tape spare wires. Connect lugs to terminal boards. Tape spare wires.



*Fig. 2-3 Location of Cable Ties in Antenna Unit*

#### WHEN THE DE-ICER IS INSTALLED

- 1) Before beginning any work on the scanner unit, turn off the breaker for the de-icer line at the main switchboard to remove the power (100VAC, 1 $\phi$ ) to the de-icer. ( turning off the power to the display unit has no effect.)
- 2) The neck of the scanner unit becomes **VERY HOT** when the de-icer is working. ( The de-icer turns on when ambient temperature is below 0°C.)

## 2.2 Transceiver Unit Connections

### 25 kW Transceiver Unit Fabrication of Signal cable (RW-6895)

- 1) Remove the anti-corrosive sheath by 500mm. Remove the armor and vinyl sheath leaving 50mm each approximately.
- 2) Unravel the outer shield to expose the cores in the outer layer. Then, unravel the inner shield to expose the cores in the inner layer. Label all inner cores for later identification.
- 3) Trim each core (except coaxial core) considering its location on the terminal board.
- 4) Trim the inner and outer shields leaving 50cm each. Attach crimp-on lug FV5.5-4 (blue,  $\varnothing 4$ ) to the shields.
- 5) Remove insulation of each core by 6 mm approximately. Attach crimp-on lug FV1.25-M3 (red,  $\varnothing 3$ ) to each core.
- 6) Fabricate the coaxial wire. Make the length 10 mm longer than the shield to prevent wire strain. Attach crimp-on lug FVD1.25-3 (red,  $\varnothing 3$ ) to coaxial wire.






Figure 2-4 How to fabricate signal cable RW-6895

## Connection

1. Remove transceiver cover.
2. Pass the signal cable through the cable entrance. Lay the cable in the clamp with the exposed armor inside the clamp; and then tighten the cable clamp. Use either of the cable entrances located at bottom rear chassis.
3. Connect wires to RTB1 and FL801.
4. Cover the filter terminals with the terminal caps (supplied) to inside the terminals.
5. Connect the shield to the chassis.
6. Run a ground wire (shipyard supply) between the ground terminal on the transceiver unit and the ship's body.



*Fig. 2-5 Transceiver Unit (25kW)*

	<h1>CAUTION</h1>
<p>An ungrounded unit can cause electrical shock when its metallic parts are touched and give off or receive electro-magnetic interference.</p> <p>An uncovered filter terminals can cause electrical shock.</p>	

## 50kW Transceiver Unit (FAR/FR-2855W)

### Fabrication of Signal Cable RW-5093

1. Remove the vinyl sheath by 1200mm.
2. Expose 50mm of the armor.
3. Expose 5mm of the inner vinyl sheath, and cover exposed part with tape.
4. Separate the outer layer wires with a small screwdriver.
5. Separate the outer layer wires in the same way as above. Mark each core for future identification.
6. Cut each core to a suitable length considering its location on the terminal board.
7. Cut the inner and outer shields to a suitable length considering the distance to the ground terminal. Attach crimp-on lug FV5.5-4.
8. Expose the conductor of each core by 6mm. Fit a crimp-on lug to each conductor.
9. Spare wires: Bundle and cover with vinyl tubing.
10. Fabricate the coaxial wire. Make the length 10 mm longer than the shield to prevent wire strain. Attach crimp-on lug FVD 1.25-3 (red,  $\phi 3$ ) to coaxial wire.




Fig. 2-6 Fabrication of the Signal Cable

Fit the BNC connector to the coaxial cable as;

- a) Remove the vinyl sheath by 10 mm.
- b) Slip the washer, packing and gland onto the coaxial cable.
- c) Comb out braid and fold back as illustrated.
- d) Trim braid so that its edge just touches the outer part of the clamp.
- e) Remove the dielectric by 3 mm.
- f) Slip male conductor in place; but against dielectric and solder.





Fig. 2-7 Fitting the BNC Connector

- g) Push assembly into body as far as it will go. Slide nut into body and screw in place with wrench until tight. For this operation, hold cable and shell rigidly and rotate nut.

### Connections

1. Loosen the six bolts securing the transceiver cover.
2. Pass the signal cable through one of the two cable entrances. Lay the cable in the cable clamp with the exposed armor under the clamp; and then tighten cable clamp.
3. Connect conductors to their proper location on RTB1 and FL801.
4. Connect the coaxial cable to BNC connector J651 on the IF Amplifier.
5. Connect the shield to the ground terminal.
6. Run a cable wire (shipyard Supply) between the ground terminal on the transceiver unit and the ship's body.

**NOTE:** To prevent magnetron demagnetization, do not bring metallic objects such as screwdrivers near the magnetron.



N Photo No.2177

*Fig. 2-8 Transceiver Unit (50 kW)*




## 2.3 Installing the Rectangular Waveguide (WRJ-9)

The RF interconnection between the scanner unit and the transceiver can be made with a rectangular waveguide (WRJ-9) or flexible waveguide (WELF-A-10). If the rectangular waveguide is used, observe the following installation guidelines.

- 1) Correctly installed waveguide runs ensure the most efficient transmission of electrical energy at high frequencies. Electrical losses, however, occur in the waveguide runs. To minimize them the following factors are of great importance: minimum length, airtightness and electrical continuity.
- 2) Another consideration required is that of frequency disturbance. The transmitting valve, a magnetron, is the primary oscillator in the radar.

This is different from the oscillation system at lower frequencies in which conventional radio valves are used. In the latter case, the primary oscillator is always protected from the effects of load impedance by a buffer stage so that frequency and waveform are left unobstructed. With a waveguide and magnetron, however, mismatch of impedance causes "frequency pulling." For this reason, the number of possible mismatches in a waveguide run, i.e., joins and bends, must be kept minimum.

- 3) Each pair of flanges should be coupled with one O-ring, four bolts and spring washers and the choke flange must be in the upper position. The bolts and O-ring must be greased before insertion to facilitate removal if required at a later date.
- 4) The transceiver unit output flange is a plain type and the scanner unit output flange is a choke type, and it is important to maintain this relationship throughout the waveguide run.



*Fig. 2-9 Flange connection*


- 5) After installation of the waveguide is completed, the coupling portions must be sealed by using the adhesive supplied.
- 6) In a very short time the surface of the waveguide becomes green with verdigris. Therefore, paint both the surface of the waveguide and flanges to avoid corrosion and water penetration. Paint must not be allowed to reach the inner surface of the waveguide or the mating surface of any flange.

## 2.4 Aligning the Circulator with the Output Waveguide (FR-2855W only)

Realignment of the circulator with the output waveguide is required whenever the RF module is swung out for magnetron replacement, etc.


After tightening the six bolts fixing the RF module, follow one of the steps shown below to make alignment.

A) When the port of the output waveguide is visible.



*Fig.2-10 Output waveguide*

B) When the above condition cannot be met.




*Fig.2-11 Output waveguide alignment 2*

Confirm that the vertical (A) and horizontal (B) faces of the output waveguide are aligned with the front face of the circulator. If not, loosen the four screws on the output waveguide and realign it with the circulator. Alternatively, check that the distance between the circulator and the output waveguide is between 0.2 mm. If not, loosen the circulator and readjust it to obtain the above mentioned tolerance.

### When the drain waveguide is not used

When the drain waveguide is not used, drill the four tapped holes on the flange of the waveguide to plane down the screw thread.



## 2.5 Display Unit Connection

Two cable are terminated at the display unit: the signal cable RW-5093 or RW-6895 and the power cable. The signal cable, available in lengths of 15m, 20m, or 30m, comes with a connector preattached to it for connection to the display unit.

### Fabricating power cable DPYCY-3.5

- 1) Remove the vinyl jacket by 150mm.
- 2) Cut off jute tape wrapped around the braided shield.
- 3) Unravel the braided shield to expose the cores by about 120 mm
- 4) Slip the terminal cap onto the core.
- 5) Remove insulation of cores by about 10mm. Fix crimp-on lugs to the cores and braided shield.
- 6) Cover the braided shield with vinyl tape, leaving the portion which will lie inside the cable clamp untaped.




Fig. 2-12 How to fabricate power cable DPYCY-3.5

### Leading in cables to the display unit

To lead in cables easily, unfasten the cable clamp at the right side of the display unit.





Figure 2-13 Location of cable clamp inside the display unit

## Tabletop

Cables can be led in through the cable gland at the rear or underside of the unit.

## Pedestal

Lead in cables through the cable gland at the bottom right-hand side of the pedestal. Pass cables through the cable clamp and tighten the cable clamp. Fix cables to the pedestal frame with cable ties as shown in Figure 2-12. Finally, pass cables through the cable clamp at the right side of the display unit and then tighten the cable clamp.




*Figure 2-12 How to lead in cables through the pedestal*

## Connections

### Power cable


Connect the power cable to the filter at the right hand side of the display unit. Cover the filter terminals with the terminal caps (supplied) to insulate the terminals.



*Figure 2-13 Location of filter inside the display unit*


### Gyro signal

Solder the 5 pin and 3 pin VH connectors (supplied) to the gyrocompass cable. Plug in the connectors on the GYRO CONVERTER Board. For further details, see page 4-2.



*Figure 2-14 Location of GYRO CONVERTER Board*

### HOW TO ATTACH NH CONNECTOR TO SIGNAL CABLE




### Grounding

The display unit must be grounded at the point shown in Figure 2-15.




## **CAUTION**

An ungrounded unit can cause electrical shock when its metallic parts are touched and give off or receive electromagnetic interference.



Tabletop type




Pedestal type

*Figure 2-15 Grounding the display unit*

### Radar buoy

Solder the radar buoy signal line to the "BUOY" connector on the VDA Board. Connect the trigger line to the corresponding connector on the INT Board.

## Signal input/output circuit (INT Board INT-9170)



*Figure 2-16 INT Board circuit*

For other input/output circuits, see the circuit diagram of the INT Board at the back of this manual.

Table 2-1 Input and output signals on the INT Board

Signal name	Name on pcb	Connector no.	Connector type	Applicable equipment	Remarks
<b>Input Signal</b>					
Gyro signal		J4* J5*	VH, 5 pin VH, 3 pin		*: On pcb A64P1106 (option)
Speed log signal	LOG	J448	NH, 3 pin		200 pulses/nm, etc.
Current indicator signal (tide)	NAV COURSE	J459	NH, 4 pin		Not used
Current indicator signal (speed)	NAV SPEED	J460	NH, 4 pin		Not used
Radar buoy signal	RADAR BUOY	J445	NH, 4 pin		
Remote display signal	EXT-RADAR or RJ-7	J458	NH, 8 pin		
Rudder angle signal	ROT RUDDER	J464	NH, 7 pin		
<b>Output Signal</b>					
External ARPA signal	EXT-ARPA	J444	NH, 8 pin	FA-2805	heading, bearing, Tx trigger
Slave display signal	SLAVE	J442 J443	NH, 8 pin	CD-140, CD-141, GD-500, FMD-800, FMD-8000 *1	heading, bearing, video, Tx trigger
				*1: Display unit for FR-2800 series radar can be used as slave display unit.	
Buzzer signal	EXT-BUZ	J451	NH, 3 pin	OP03-21-3	buzzer drive signal
Buzzer signal (AC)	EXT-BUZ (AC)	J452	NH, 2 pin	Speaker w/amp	speaker signal
Monitor signal		J449	NH, 10 pin		VER synchronous, HOR synchronous, video (NTSC format)
RJ-8	RJ-8	J456	NH, 4 pin		
<b>Input/Output Signal</b>					
INS data	INS. DATA	J455	NH, 5 pin		
RJ-7	RJ-7	J457	NH, 15 pin NH, 8 pin		
Nav data	N AV DATA	J450	NH, 8 pin		
ARPA data	ARPA DATA	J454	NH, 5 pin		





Figure 2-17 Location of connectors on the INT Board



## Grounding cables and covering unused cable slots in the cable clamp



*Figure 2-18 Cable clamp*




## CAUTION

- 1) The display unit must be grounded. Failure to ground the unit may cause electrical shock when its metallic parts are touched and give off or receive electromagnetic interference.
- 2) Cover unused cable slots in the cable clamp with aluminum tape to prevent foreign objects from falling into the display unit through the cable slots.

## 2.6 Power Supply Unit

### PSU-004



*Fig. 2-19 Power Supply Unit (PSU-004) with Cover Removed*

The table below lists the thermal relays to be used in the Power Supply Unit (PSU-004). The type of the relay and its presetting differs according to ship's mains.

Ship's Mains	Scanner Unit	Thermal Relay (K2)	
		Type	Presetting
200/220VAC, 3 $\phi$	RSB-0041/0076	TR-ONH/3 0.8A	0.8A
380/440VAC, 3 $\phi$	RSB-0042/0077	TR-ONH/3 0.36A	0.4A
100VAC, 1 $\phi$	RSB-0043	BMK9-04-8K	3.0A
220VAC, 1 $\phi$	RSB-0046	BMK9-04-8K	1.8A


## 3. INITIALIZATION AND ADJUSTMENT

### 3.1 Setting Operating Voltage of Fan Motor

The operating voltage of the fan motor inside the transceiver unit must be the same as that of ship's mains.

The primary of the transformer inside the transceiver unit is factory-wired to the #1 of RTB-3 for 100 VAC power supply. Change the connection if ship's mains is not 100 VAC.

100 VAC: #1, 110 VAC: #2, 115VAC: #3



N Photo No.2177


*Figure 3-1 Transceiver Unit (50 kW)*

### 3.2 Menus for Initialization and Adjustment

#### Accessing the menus

The menus for initialization and adjustment of this radar are locked to prevent adjustment by the user. To access them;

- 1) Turn off the power.
- 2) Turn on the #4 segment of DIP Switch S1 on the SPU Board.



*Figure 3-2 Display unit (top view, cover removed) and SPU Board*

## Menu operation

- 1) Press the [RADAR MENU] key.
- 2) Press appropriate numeric key to select menu desired.
- 3) Press numeric key to select item.
- 4) Press same numeric key pressed in step 3 to select option.
- 5) Press [ENTER] to register selection.

## Menu description and menu tree

See pages 3-8 and 3-13, respectively.

## Restoring default settings

- 1) Press [RADAR MENU] [0] [0] [2] [0] [0] [0] [0] to select FACTORY DEFAULT on the INITIAL SETTING 4 menu.
- 2) Press the [ENTER] key.
- 3) Wait for 10 seconds.
- 4) Turn power off, and on again.
- 5) Press [RADAR MENU] [0][0][2][0][0][0][2] to select MODEL on the INITIAL SETTING 4 menu.
- 6) Press the [2] key several times to select OTHER X-BAND.
- 7) Press the [ENTER] key.

## 3.3 Heading Alignment

Antenna unit mounted error (heading reed switch timing error) can be compensated at the display unit.




Figure 3-3 Heading alignment error


## **Procedure**

- 1) Turn on the power. Press [RADAR MENU] [0] [0] [2] [2] to select HD ALIGN on the INITIAL SETTING 1 menu.
- 2) Select a target echo (by gyrocompass, for example) at a range between 0.125 and 0.25nm, preferably near the heading mark.
- 3) Operate the EBL control to bisect the target echo. (The value shown on the display is antenna position in relation to ship's bow.)
- 4) Press [ENTER] to finish.

## **3.4 Adjusting Sweep Timing**

Sweep timing differs with respect to the length of the signal cable between the antenna unit and the display unit. Adjust sweep timing at installation to prevent the following symptoms:

- The echo of a "straight" target (for example, pier), on the 0.25nm range, will appear on the display as being pulled inward or pushed outward. See Figure 3-4.
- The range of target echoes will also be incorrectly shown.



*Figure 3-4 Examples of correct and incorrect sweep timings*

## **Procedure**


- 1) Turn on the power. Press [RADAR MENU] [0] [0] [2] [3] to select TIMING ADJ on the INITIAL SETTING 1 menu.
- 2) Transmit on the 0.25nm range.
- 3) Adjust radar picture controls to display picture properly.
- 4) Select a target echo which should be displayed straightly.
- 5) Adjust the VRM control to straighten the target echo.
- 6) Press the [ENTER] key.

## 3.5 Adjusting Video Signal Level

When the signal cable is very long, the video signal input level decreases, shrinking target echoes. To prevent this, confirm (and adjust if necessary) video amplifier input level.

### Procedure

- 1) Connect an oscilloscope to TP3 on the INT Board (INT-9170). Take the trigger at TP10 on the INT Board.
- 2) Transmit on the 12nm range.
- 3) Adjust VR1 on the INT Board so the value of TP3 is 4Vpp. (For secondary display, adjust VR2 for same level.)



*Figure 3-5 Location of INT Board*

## 3.6 Suppressing Main Bang

If main bang appears at the screen center, suppress it as follows.

### Procedure

- 1) Turn on the power. Transmit on a long range and then wait ten minutes.
- 2) Adjust [GAIN] control to show a slight amount of noise on the display.
- 3) Select the 0.25nm range. Adjust the [A/C SEA] control to suppress sea clutter.
- 4) Open the tuning compartment on the control unit.
- 5) Set VR901(MBS-L) at two o'clock and then slowly turn VR902 (MBS-T) clockwise to suppress main bang.
- 6) If main bang still exists, turn VR901 clockwise slightly, and then slowly turn VR902 clockwise. **Note that excessive main bang erases targets in close range.**




Figure 3-6 Control unit, location of tuning compartment

### 3.7 Confirming Tuning

The radar receiver can be tuned both automatically and manually. Confirm that the radar can be tuned both automatically and manually.

#### Procedure

- 1) Turn on the power. Set the TUNE switch in the top right hand panel to MANU.
- 2) Transmit on the 48nm range.
- 3) Adjust sensitivity and picture brilliance. Turn the [A/C SEA] and [A/C RAIN] controls fully counterclockwise (off).
- 4) While observing the picture, turn the [TUNE] control in the tuning compartment slowly counterclockwise (clockwise) more than twice to get best (worst) tuning point.
- 5) Turn the [TUNE] control slowly clockwise (counterclockwise) to display the longest tuning bar.
- 6) Set the TUNE switch to AUTO and wait about 10 seconds (about four rotations of the antenna).
- 7) Confirm that the radar found best tuning point. Peak tuning is obtained when about 80% of the tuning indicator lights.

### 3.8 Confirming Magnetron Heater Voltage


Magnetron heater voltage is adjusted at the factory. However, confirm that it is within the prescribed rating.

*Table 3-1 Magnetron heater voltage rating*

Measuring conditions	FAR/FR-2825W (25kW)	FAR/FR-2855W (50kW)	Tuning point
ST-BY, 0.25nm	8.2 V to 8.4 V	7.0 V to 7.6 V	VR801 on the TRIGGER Board (RFC-9008)
Tx on 48nm range	6.5 V to 7.5 V	4.5 V to 5.1 V	

#### 25 kW Transceiver

1. Set the item "SCANNER STOPPED" on the INITIAL SETTING menu to "TX" so that the radar can transmit with the scanner rotation suspended.
2. Set the SCAN switch on the keyboard panel to "Off".
3. Remove TX fuse (F801) on the transceiver unit.
4. Set a multimeter to 10 VDC range and connect it between #4 (+) and #6(-) of connector P9 on the 03P9189 Board.
5. With the radar set to 0.25 nm range, adjust sliding contact VR801 for multimeter reading of 8.2 to 8.4 VDC.
6. With the radar set to 48 nm range, confirm that a multimeter reading is 6.5 to 7.5 VDC.




*Fig. 3-7 Transceiver Unit (25 kW)*



## 50 kw Transceiver

1. Set the item 2 "SCANNER STOPPED" on the INITIAL SETTING menu to "TX" so that the radar can transmit with the scanner rotation suspended.
2. Set the SCAN switch on the top right-hand panel to "Off".
3. Pull on the door switch (S802) to
4. Set a multimeter to 10VDC range and connect it between #1(+) and (-) of P805 on the board 03P6666.
5. With the radar set to the 0.25 mile range, adjust sliding contact R812 for a multimeter reading of 7.0-7.6 VDC.
6. With the 48mile range, adjust sliding contact R811 for a multimeter reading of .5-5.1 VDC.
7. Replace the transmission fuse, transmit the radar, and check that magnetron current, shown on the check meter, is normal (6-9.5) on the 48 mile range.



*Fig. 3-8 Transceiver Unit (50 kW)*

## 3.9 Initial Setting Menus

The INITIAL SETTING menus (four menus) setup the radar according to expected usage, authorities specification, ship's characteristics, operator's preference, etc. Set items on each menu accordingly.

### INITIAL SETTING 1 menu

HD ALIGN: Compensates for heading error in bow direction.

TIMING ADJ: Adjusts sweep timing, which varies according to signal cable length.

ANT HEIGHT: Enter height of antenna above water.

LOG PULSE: Enter speed log's pulse rate.

OWN SHIP INFORMATION: Enter ship's characteristics; length, width, radar position, nav antenna position, turn rate, and speed rate. Those data will be used for the anchor watch alarm, docking, etc.

ON TIME, TX TIME: Shows number of hours the radar has been turned on and transmitted, respectively. Value can be change to monitor magnetron usage, etc.

### INITIAL SETTING 2 menu

KEY BEEP: Turns key response beep on or off.

SCANNER STOPPED: Set to ST-BY in normal use. TX enables transmission state without antenna rotation.

VIDEO SIGNAL: Set to ANLG (analog) for normal use. Set for DGTL to adjust QV (Quantized Video).

ALARM LEVEL: Sets echo strength which triggers guard alarm. "7" is strongest echo; "4" is medium strength echo.

DISPLAY: Select radar display function; main or sub (slave).

SECTOR BLKG: Sets area (up to 2) where no radar pulses will be transmitted. For example, set the area where an interfering object at the rear of the antenna would produce a dead sector (area where no echoes appear) on the display. To enter an area, select ON and enter relative bearing range of the area.

### INITIAL SETTING 3 menu

TRAIL RESTART: Selects whether to restart or discontinue echo trailing when changing the range. ON restarts trailing on newly selected range; OFF discontinues trailing.

ECHO AVG W/O GYRO: Echo averaging can be turned on without gyrocompass connection.

GYRO SCALE: Bearing scale may be shown in degrees or compass points.

CTR(Center) ECHO STRETCH: Turn on to enlarge echoes in the range up to the first range ring.

VIDEO CONTRAST: For factory use. Do not change setting.

MAXIMUM RANGE: For factory use. Do not change setting.

ECHO FULL COLOR: Echoes may be displayed in single or multi-color.

INDEX LINES: Selects the number of index lines to display; 2 or 6.

## **INITIAL SETTING 4 menu**

MODEL: Select radar model. Pulswidth, pulse repetition rate and STC curve change according to selection.

RJ-5, RJ-7 and RJ-8: Selects which Interswitch unit to use.

ANT A: Select model of antenna A.

ANT B: Select model of antenna B.

CABLE L: Set for "500."

FACTORY DEFAULT: Restores all menus' default settings.

## **After entering initial settings**

Turn off the #4 segment of DIP Switch S1 on the SPU Board to disable the menus for initialization and adjustment.

## **3.10 Setting the Function Keys**

This radar has four function keys which automatically set up the radar according to the conditions ascribed to them. Confer with ship owner and radar operator to determine suitable program for each key.

Assign task to each function key;

Function key #1: picture setup

Function key #2 and #3: picture setup or specific operation

Function keys #4: specific or watch function

The table below and menu on the next page show the programs available.

Table 3-2 Operation setup conditions

Picture setup	Function
RIVER	River navigation
BUOY	Detecting navigation buoys, small vessels and other small surface objects
SHIP	Detecting vessels
SHORT	Short range detection using a range of 3 nm or less on calm seas.
LONG	Long range detection using a range of 6 nm or larger
CRUISING	Cruising using a range of 1.5 nm or larger
HARBOR	Short range navigation in a harbor using range of 1.5 nm or less
COAST	Coastal navigation using range of 12 nm or less
OCEAN	Transoceanic voyage using range of 12 nm or larger
ROUGH SEA	Optimum setting for rough weather or heavy rain

[FUNCTION KEY 1]		
1	[SYSTEM SETTING 1]	
2	FUNCTION	FUNC1/RIVER/BUOY/ SHIP/SHORT/LONG/ CRUISING/HARBOR/ COAST/OCEAN/ ROUGH SEA (FLOAT/BIRD) *1
3	INT REJECT	OFF/1/2/3
4	ECHO STRETCH	OFF/1/2
5	ECHO AVERAGE	OFF/1/2/3
6	A/C AUTO	OFF/ON
7	[FUNC1 PULSE WD]	(see menu below)
8	NOISE REJ	OFF/ON

[FUNCTION KEY 2] *2		
1	[SYSTEM SETTING 1]	
2	FUNC KEY2	PICTURE/OPERATION HU/HU TB/CU/NU/ TM/TRAIL/CU, TM RESET/OFF CENTER/ ECHO STRETCH1/ ECHO STRETCH2/ PLS WD1/PLS WD2/ ECHO AVG1/ECHO AVG2/ ECHO AVG3/ECHO COLOR/TRAIL BRILL/ PANEL BRILL/CHAR BRILL/NOISE REJ
3	OPERATION	

[FUNC1 PULSE WD] *3		
1	[FUNCTION KEY 1]	
2	0.5 NM	S1/S2
3	0.75 NM	S1/S2
4	1.5 NM	S1/S2/M1
5	3 NM	S2/M1/M2
6	6 NM	M1/M2/L
7	12-24 NM	M2/L

[FUNCTION KEY 4]		
1	[SYSTEM SETTING 1]	
2	FUNC KEY4	OPERATION/WATCH ALARM
3	WATCH ALARM INTERVAL	6/10/12/15/20 MIN

**Notes**

- \*1: Available on "R" specification radar.
- \*2: Same menu appears for function key #3.
- \*3: Same menu appears for function keys #1, #2 & #3.

Shaded items are set at the factory; do not change their settings. See note on next page.

*Figure 3-9 Function key menus*

## **Procedure for setting function keys**

### **Function key #1**

- 1) Press [RADAR MENU].
- 2) Press [0].
- 3) Press [3] to select FUNCTION KEY 1.
- 4) Press [2] to select picture setup condition desired.
- 5) Press [8]. (See the note on the next page.)

### **Function key #2 & #3**

- 1) Press [RADAR MENU].
- 2) Press [0].
- 3) Press [4] to select FUNCTION KEY 2.
- 4) Press [2] to select PICTURE or OPERATION.
- 5) Press [3] to select picture setup condition (or specific operation) desired.
- 6) Press [9]. (See the note below.)

### **Function key #4**

- 1) Press [RADAR MENU].
- 2) Press [0].
- 3) Press [5] (FUNCTION KEY 3) or [6] (FUNCTION KEY 4).
- 4) Press [2] to select OPERATION or WATCH ALARM.
- 5) Press [3] to select picture setup condition (or watch alarm interval).
- 6) Press [9]. (See the note which follows.)

**Note:** Each picture setup condition is programmed with optimal settings for interference rejection, echo stretch, echo averaging, automatic clutter removal, pulsewidth, and noise rejection. Therefore, the settings for those items on the function key menus should not be changed; any adjustment may adversely affect the target detection ability of the radar. If change is absolutely necessary, consult with nearest FURUNO representative or dealer.


## **Attach label to function keys**

After setting the function keys, attach appropriate label (supplied) to them.

## 3.11 Default of Initial Setting Menus

### NOTES:

- 1) Default settings shown in boldface.
- 2) Enabling initial setting menus: Turn on DIP switch S1 #4 on the SPU Board.
- 3) Disabling initial setting menus: Turn off DIP switch S1 #4 on the SPU Board.
- 4) Restoring default settings: Select "FACTORY SETTING" on INITIAL SETTING 4 menu.




## 3.12 Adjusting ARP Board


### Procedure

- 1) Take out the SPU Board SPU-911 from the pcb compartment in the display unit.
- 2) Turn on #4 of DIP Switch S1.
- 3) Set the SPU Board in pcb compartment.
- 4) Set the rader as follows and transmit on 6 nm range.  
A/C SEA control: Fully CCW  
A/C SEA control: Fully CCW  
A/C SEA control: Fully CCW

From the back SPU,ARP  
and RP (option) Boards.



- 5) Connect the digital multimeter, set to DCV range, to the following points on the ARP Board.  
+: TP7 (VS+)  
+: TP6 (VS-)
- 6) Adjust potentiometer R104 ("OFFSET") on the ARP Board so that the multimeter reads +0.09 to 0.13V.




7) Set the controls and switches as follow.

A/C SEA control: fully CCW (same as step 4)  
A/C SEA control: fully CCW (same as step 4)  
GAIN control: fully CCW (same as step 4)  
INT REJECT key: OFF  
RANGE: 24 nm  
Echo Stretch (in menu): OFF

8) Press the RARAR MENU key followed by 0, 0, 2, 0 and 6 to select "DGTL".

9) Press the ENTER key.

10) Adjust potentiometer R103 ("LEVEL") on the ARP Board so that random noise faintly appears.




11) Repeat step 6 to select "ANLG", and press the ENTER key.

12) Turn off #4 of DIP switch S1.

## Confirmation after Installation

Transmit the radar after connection with speed log and gyrocompass.

Confirm that all red LEDs, CR9, 10, 11, 12, 15 and 16 are off, provided that the ship's speed is not zero. If any signal is not applied, the corresponding LED lights.





### 3.13 Installation Check List

Tick box to indicate completion.

- ☐ Hoist rings removed?
- ☐ Rubber mat placed between antenna unit and mounting platform?
- ☐ Waterproofing gasket on antenna unit oriented correctly?
- ☐ Heading aligned?
- ☐ Sweep timing adjusted?
- ☐ Main bang suppressed?
- ☐ Tuning checked?
- ☐ Magnetron heater voltage checked?
- ☐ Antenna height entered?
- ☐ Log pulse selected?
- ☐ GYRO CONVERTER Board set up?
- ☐ DIP Switch S1 #4 turned off?
- ☐ Function keys set and function key labels attached?
- ☐ Unused cable slots in cable clamp covered with aluminum tape?


## 4. INSTALLATION OF GYRO CONVERTER GC-8 (option)

The Gyro Converter GC-8, incorporated inside the radar display unit, converts analog gyro-compass reading into digital coded bearing data for display on the radar display.

This section explains how to install and setup the GC-8 (mainly consisting of the GYRO CONVERTER Board) and set it up according to gyrocompass connected.

### 4.1 General Procedure for Installing and Setting up the GYRO CONVERTER Board

- 1) Turn off the power.
- 2) Remove the top cover.
- 3) Connect the GYRO CONVERTER Board to the MOTHER Board (cables supplied with the GC-8) as follows:



*Table 4-1 Contents of GC-8 installation kit*

Name	Type	Code No.	Qty
GYRO CON- VERTER Board	64P1106	004-412-200	1
Spacer	SQ-10	000-801-678	4
Washerhead Screw	M3 x 8	008-456-404	4
PH-XH Connector	03-1761 (14P-6P)	008-456-130	1
NH-XH Connector	03-1762 (5P-5P)	008-456-140	1
Label	64-014-2021-1	100-132-701	1
VH Connector Assy.	03-1763 (5P)	008-456-150	1
VH Connector Assy.	03-1764 (3P)	008-456-160	1
Spare Fuses	FGMB 2A 250V	000-122-000	4

*Figure 4-1 Display unit, top view*

- 4) Connect the GYRO CONVERTER Board to the MOTHER Board (cables supplied with GC-8) as follows:

**GYRO CONV. Board      MOTHER Board**

J1 (14P) ←————→ J301 (6P)  
 J7 (5P) ←————→ J307 (4P)

- 5) Confirm gyrocompass specifications and set up the DIP switches and jumper wires on the GYRO CONVERTER Board according to gyrocompass connected;

- Confirming gyrocompass specifications: see next page
- Setting jumper wires and DIP switches by gyrocompass specifications: page 4-4
- Setting jumper wires and DIP switches by make and model of gyrocompass: page 4-6
- Location of jumper wires and DIP switches: page 4-7

- 6) Solder the gyrocompass cable to the VH connector assemblies (supplied).
- 7) Connect the VH connectors to the GYRO CONVERTER Board as shown in the table at right.
- 8) Attach instruction label (supplied) to the rear side of the top cover.
- 9) Close the panel.
- 10) Turn on and off the power to reset the CPU.

Connector		Gyrocompass	
		Step type	Synchro type
J4	#1	S1	S1
	#2	S2	S2
	#3	S3	S3
	#4		
	#5	F. G.	F. G.
J5	#1	—	R2
	#2	COM	R1
	#3	F. G.	F. G.

## 4.2 Connection of External Power Supply

Connect an external power supply when the repeater signal is step-by-step type and the step voltage is below 20V or output voltage is less than 5W.




Figure 4-2 Connection of external power supply to GYRO GYRO CONVERTER Board

## 4.3 Confirming Gyrocompass Specifications

Follow the flow chart in the figure below to confirm gyrocompass specifications.




Figure 4-3 Confirming gyrocompass specifications

## 4.4 Changing Settings on the GYRO CONVERTER Board

### Default setting

In the default setting all DIP switches are off and all jumpers wires are set to "#1." (Note that jumper wire JP1's setting is #1, #2, and #3.) In those settings the gyrocompass having the following specifications can be directly connected; modification of the GYRO CONVERTER Board is not necessary.

AC synchronous signal: 50/60Hz

Rotor voltage: 60V to 135V AC

Stator voltage: 60V to 135V AC

Gear ratio: 360x

Supply voltage: 30V to 135V AC

If the specifications of the gyrocompass differ from those mentioned above, change jumper wire and DIP switches settings on the GYRO CONVERTER Board. Settings may be changed according to gyrocompass specifications or make and model of gyrocompass (see page 4-6). For the location of DIP switches and jumper wires, see page 4-7.

### Setting method 1: by gyrocompass specifications

#### 1) Gyrocompass type

Gyrocompass type	SW 1-4	SW 1-5	SW 1-6	JP1
AC synchronous	OFF	OFF	OFF	#1, #2, #3
DC synchronous	OFF	OFF	OFF	#2, #3, #4
DC step	ON	OFF	OFF	#4, #5, #6
Full-wave pulsating current	OFF	ON	OFF	#4, #5, #6
Half-wave pulsating current	ON	ON	OFF	#4, #5, #6

#### 2) Frequency

Frequency	SW 1-7	SW 1-8	Remarks
50/60Hz	OFF	OFF	AC synchronous pulsating current
400Hz	ON	OFF	AC synchronous pulsating current
500Hz	OFF	ON	AC synchronous pulsating current
DC	ON	ON	DC synchronous DC step

#### 3) Rotor voltage (between R1 & R2)

Rotor voltage	SW 2-1	JP3
20V to 45V AC	OFF	#2
30V to 70V AC	OFF	#2
40V to 90V AC	ON	#1
60V to 135V AC	OFF	#1

#### 4) Stator voltage (between S1 and S2)

Stator voltage	SW 2-2	SW 2-3	JP3
20V to 45V AC, or 20V to 60V DC	ON	OFF	#2
20V to 45V AC, or 20V to 60V DC	OFF	OFF	#2
40V to 90V AC	ON	OFF	#1
60V to 135V AC	OFF	OFF	#1

**5) Ratio**

Ratio	SW1-1	SW 1-2	SW1-3
360x	OFF	OFF	OFF
180x	ON	OFF	OFF
90X	OFF	ON	OFF
36X	OFF	ON	OFF

**6) Supply voltage**

Supply voltage	JP4	JP5
20V to 45V AC, or 20V to 60V DC	#2	#2
30V to 135V AC, or 40V to 100V DC	#1	#1

**7) AD-10 format data  
Tx interval**

Select data transmitting interval for ports 1 to 6 by jumper wires JP6 and JP7.

**Note:** The Tx interval is available in 25 msec or 200 msec. 25 msec is for radar; 200 msec is for all other equipment.

**8) NMEA-0183  
Tx interval**

Tx interval	SW2-4
2 seconds	ON
1 second	OFF

## Setting method 2: by make and model of gyrocompass

*Table 4-2 Setting GYRO CONVERTER Board by make and model of gyrocompass*

Maker	Models	Specification	SW 1-1	SW 1-2	SW 1-3	SW 1-4	SW 1-5	SW 1-6	SW 1-7	SW 1-8	SW 2-1	SW 2-2	SW 2-3	JP1	JP2	JP3	JP4	JP5
FURUNO	GY-700	DC step 100V 180x 5-wire, open collector	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
Anschutz	Standard 2,3	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 22V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	#1, #2,#3	#2	#2	#1	#1
	Standard 4,6	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 90V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#2	#1	#1	#1
	Standard 20	DC step 35V 180x COM(-), 3-wire(+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
Yokogawa Navtec (Plaith type)	C-1/1A/2/3 A-55, B-55	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 22V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	#1, #2,#3	#2	#2	#1	#1
	CMZ-250X/ 300X/500	DC synchronous 360x	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON	-	ON	OFF	Remo- ve	#2	-	*	*
		DC step 35V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
	CMZ-100/200/ 300 C-1Jr,D-1Z/1/3 IPS-2/3	AC synchronous 50/60Hz Rotor voltage: 100V Stator voltage: 90V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
Plaith	NAVIGAT II/III	step 35V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	Remo- ve	#2	-	*	*
		AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 68V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#2	#2	#1	#1
Tokimec (Sperry type)	ES-1/2/11 GLT-101/102/ 103/106K/107	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 90V 36x	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	ES-11A/110 TG-200 PR222R/2000 PR237L/H GM 21	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 22V 90x	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	MK-14 MOD-1/2/T NK-EN,NK-EI	DC step 70V 180x COM(-), 3-wire(+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	SR-130/140	DC step 70V 180x 5-wire, open collector	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	TG-100/5000 PR-357/130/ 140, ES-17 GLT-201/202 /203	DC step 70V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	TG-6000	DC step 24V 180x	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
	GM-11	AC synchronous 50/60Hz Rotor voltage: 100V Stator voltage: 90V 90x	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	SR-120,ES-16 MK-10/20/30	DC step 35V 180x	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
Kawasaki	GX-81	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 90V 90x	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
Armabrown	MK-10,MKL-1 SERIES1351, MOD-4	DC step 50V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
Robertson	SKR-80	DC step 35V 180x COM(-), 3-wire(+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2

## After changing settings

Turn on and off the power to reset the CPU.




Figure 4-5 Location of DIP switches and jumper wires on the GYRO CONVERTER Board



## 4.5 Setting the Bearing on the Radar Display




Confirm that the gyrocompass is giving reliable readings. Then, set bearing on the radar display as shown in the procedure below.

- 1) Open the tuning compartment on the control panel. Press the HOLD switch to disengage the computing circuit from the gyrocompass. The "HOLD" LED lights.
- 2) Press [+] or [-] switch to duplicate the gyrocompass reading at the top of the radar display. (Each press of those switches changes the readout by 0.1 degrees. A switch may be pressed and held down more than two seconds to change the readout by one degree.)
- 3) Press the HOLD switch when the gyrocompass reading on the radar matches the gyrocompass reading. The "HOLD" LED goes off.

**Note:** In some cases, the gyrocompass rotation may be the opposite of the displayed bearing, in spite of correct connections. In this case try exchanging two connections among S1, S2 and S3 on the GYRO SWITCH Board.

**FURUNO**

CODE NO.		03EU-X-9414-0
TYPE		

工 事 材 料 表 INSTALLATION MATERIALS		FR/FAR-2825W/2835SW レーダー RADAR (信号ケーブル SIGNAL CABLE)			
番号 No.	名 称 N A M E	略 図 O U T L I N E	型 名 / 規 格 D E S C R I P T I O N S	数量 Q'TY	用途 / 備考 R E M A R K S
1	信号ケーブル組品 SIGNAL CABLE ASSEMBLY	 L=15m	S03-63-15 (RW-6895 *15M*) CODE NO. 008-465-230	1	選択 TO BE SELECTED
2	信号ケーブル組品 SIGNAL CABLE ASSEMBLY	 L=30m	S03-63-30 (RW-6895 *30M*) CODE NO. 008-465-240	1	
3	信号ケーブル組品 SIGNAL CABLE ASSEMBLY	 L=50m	S03-63-50 (RW-6895 *50M*) CODE NO. 008-465-250	1	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
(略図の寸法は参考値です。)					
				図 番 (1/1) DWG. NO. C3411-M01-A	

**FURUNO**

CODE NO.		03EU-X-9413
TYPE		




工事材料表 INSTALLATION MATERIALS		FR-2855W/2865SW      レーダー FAR-2855W/2865SW      RADAR			
番号 No.	名                      称 N A M E	略                      図 O U T L I N E	型 名 / 規 格 D E S C R I P T I O N S	数 量 Q ' T Y	用 途 / 備 考 R E M A R K S
1	信号ケーブル組品 SIGNAL CABLE ASSY.	 L=15m	S03-57-15 RW-5093      *15M* CODE NO. 008-461-810	1	選 択 T O B E S E L E C T E D
2	信号ケーブル組品 SIGNAL CABLE ASSY.	 L=30m	S03-57-30 RW-5093      *30M* CODE NO. 008-461-820	1	
3	信号ケーブル組品 SIGNAL CABLE ASSY.	 L=50m	S03-57-50 RW-5093      *50M* CODE NO. 008-461-830	1	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		











図 番

(1/1)

DWG. NO. C3406-M02-A

**FURUNO**

CODE NO.	008-461-760	03EU-X-9403 -2 1/2
TYPE	CP03-14602	

工事材料表 INSTALLATION MATERIALS		FR/FAR-2815/2825 2835S/2855/2855W FA-2805 船用レーダー MARINE RADAR			
番号 NO.	名称 NAME	略図 OUTLINE	型名/規格 DESCRIPTIONS	数量 Q'TY	用途/備考 REMARKS
1	スチューブ F(Z) HEAT-SHRINK TUBE		3X0.25 加 *0.10M* CODE NO. 000-105-874	2	外部機器接続用 FOR EXTERNAL EQUIPMENT
2	NHコネクタ センサイ NH CONNECTOR ASSY.		AWG24 ±0.1M* CODE NO. 000-132-342	20	外部機器接続用 FOR EXTERNAL EQUIPMENT
3	NHコネクタハウジング NH CONNECTOR HOUSING		H2P-SHF-AA CODE NO. 000-505-595	1	警報音信号 (AC) EXT-BUZZER (AC)
4	NHコネクタハウジング NH CONNECTOR HOUSING		H3P-SHF-AA CODE NO. 000-505-596	2	ジャイロ信号用 GYRO DATA ログ信号用 SPEED LOG
5	NHコネクタハウジング NH CONNECTOR HOUSING		H4P-SHF-AA CODE NO. 000-505-597	3	RJ-8 用 レータファイ用 潮流計信号用
6	NHコネクタハウジング NH CONNECTOR HOUSING		H5P-SHF-AA CODE NO. 000-505-598	2	ジャイロ信号用 GYRO DATA ログ信号用 INSTANTANEOUS DATA
7	NHコネクタハウジング NH CONNECTOR HOUSING		H7P-SHF-AA CODE NO. 000-505-600	1	舵角信号用 FOR PORT RUDDER
8	特殊ラグ LUG		7x7x14 SS CODE NO. 000-536-100	2	
9	圧着端子 CRIMP-ON LUG		FV5.5-4 CODE NO. 000-538-123	2	
10	ナナヘ セムスネジ B WASHER HEAD SCREW		M3X8 C2700 MBN12 CODE NO. 000-881-404	2	




C3418-M03-D

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

**FURUNO**

CODE NO.	008-461-760	03EU-X-9403 -2
TYPE	CP03-14602	2/2

工事材料表 INSTALLATION MATERIALS		FR/FAR-2815/2825 2835S/2855/2855W FA-2805		船用レーダー MARINE RADAR		
番号 NO.	名称 NAME	略図 OUTLINE	型名/規格 DESCRIPTIONS		数量 Q'TY	用途/備考 REMARKS
11	VHコネクタ組品 NH CONNECTOR ASSY.		03-1737(5P)		1	シミュロコンバータ FOR GYRO CONVERTER
			CODE NO.	008-454-380		
12	VHコネクタ組品 NH CONNECTOR ASSY.		03-1738(3P)		1	シミュロコンバータ FOR GYRO CONVERTER
			CODE NO.	008-454-390		
13	VHコネクタ組品 NH CONNECTOR ASSY.		03-1778(2P)		1	パフォーマンスモニター PM-30/50 用 FOR PERFORMANCE MONITOR
			CODE NO.	008-460-050		











C3418-M04-C

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

**FURUNO**

CODE NO.	008-452-510	03EP-X-9402 -4 1/2
TYPE	CP03-13904	

工事材料表						
INSTALLATION MATERIALS						
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS		数量 Q' TY	用途／備考 REMARKS
1	六角ナット 1種 HEX. NUT		M12 SUS304		4	
	CODE NO.		000-863-112			
2	ミガキ平座金 FLAT WASHER		M12 SUS304		4	
	CODE NO.		000-864-132			
3	バネ座金 SPRING WASHER		M12 SUS304		4	
	CODE NO.		000-864-263			
4	六角ボルト (全紗) HEX. BOLT		M12X60 SUS304		4	
	CODE NO.		000-862-191			
5	7-ス線 GROUNDING WIRE		RW-4747-1 03S4747		1	
	CODE NO.		000-566-000			
6	六角ナット 1種 HEX. NUT		M6 SUS304		1	7-ス線取付用 FOR GROUNDING WIRE
	CODE NO.		000-863-109			
7	ミガキ平座金 FLAT WASHER		M6 SUS304		3	7-ス線取付用 FOR GROUNDING WIRE
	CODE NO.		000-864-129			
8	バネ座金 SPRING WASHER		M6 SUS304		1	7-ス線取付用 FOR GROUNDING WIRE
	CODE NO.		000-864-260			
9	六角ボルト HEX. BOLT		M6X25 SUS304		1	7-ス線取付用 FOR GROUNDING WIRE
	CODE NO.		000-862-180			
10	圧着端子 CRIMP-ON LUG		FV1.25-M3 7カ		9	スキャナ端子台用 FOR TERMINAL BOARD CONNECT
	CODE NO.		000-538-110			

DWG NO.




C3385-M02- E

FURUNO ELECTRIC CO., LTD.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

**FURUNO**

CODE NO.	008-452-510	03EP-X-9402 -4 2/2
TYPE	CP03-13904	

工事材料表 INSTALLATION MATERIALS					
番号 NO.	名称 NAME	略図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
11	圧着端子 CRIMP-ON LUG		FV1.25-4 CODE NO. 000-538-114	3	スキヤ端子台用 FOR TERMINAL BOARD CONNECT
12	防蝕ゴム.1. CORROSION- PROOF RUBBER MAT		03-001-3001-0 CODE NO. 300-130-010	1	電蝕防止用 FOR PREVENION OF CORROSION
13	シールワッシャ SEAL WASHER		03-001-3002-0 CODE NO. 300-130-020	4	電蝕防止用 FOR PREVENION OF CORROSION

DWG NO.





C3385-M03- E

FURUNO ELECTRIC CO., LTD.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

**FURUNO**

CODE NO.	008-465-220	03EU-X-9416 -3
TYPE	CP03-15801	1/1

<b>工事材料表</b> INSTALLATION MATERIALS		FR/FAR-2825W/2835W 船用レーダー FR-2125W FR-2135SW/-MSA RADAR			
番号 NO.	名称 NAME	略図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	圧着端子 CRIMP-ON LUG		FV1.25-3 7カ	16	
			CODE NO. 000-538-113		
2	圧着端子 CRIMP-ON LUG		FV5.5-4	4	
			CODE NO. 000-538-123		
3	圧着端子 CRIMP-ON LUG		FVD1.25-3	1	
			CODE NO. 000-116-634		
4	端子板カバー PANEL BOARD COVER		ZM-47A	2	
			CODE NO. 000-532-491		

 DWG NO.  
 C3411-M02- D




FURUNO ELECTRIC CO., LTD.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)



**FURUNO**

CODE NO.	008-461-850	03EU-X-9410-4 1/1
TYPE	CP03-14802	

<b>工事材料表</b> INSTALLATION MATERIALS		FR-2150W FR-2855W/2865SW FAR-2855W/2865SW 船舶用レーダー MARINE RADAR			
番号 NO.	名称 NAME	略図 OUTLINE	型名/規格 DESCRIPTIONS	数量 Q'TY	用途/備考 REMARKS
1	コネクタ CONNECTOR		BNC-P-3	1	
			CODE NO. 000-500-396		
2	圧着端子 CRIMP-ON LUG		FV1.25-M3 7カ	16	
			CODE NO. 000-538-110		
3	圧着端子 CRIMP-ON LUG		FV5.5-4	4	
			CODE NO. 000-538-123		





 DWG NO.  
 C3406-M01- C

FURUNO ELECTRIC CO., LTD.

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

**FURUNO**

CODE NO.	008-452-540	03EP-X-9405 -4 1/1
TYPE	CP03-13907	

工事材料表 INSTALLATION MATERIALS		FR/FAR-2125W FR-2135S/-B FR-2135SW/-MSA FR-2155/-B/2165DS FR/FAR-2825W FR/FAR-2835S/SW FR/FAR-2855/W FR/FAR-2865SW	船舶用レーダー MARINE RADAR		
番号 NO.	名称 NAME	略図 OUTLINE	型名/規格 DESCRIPTIONS	数量 Q'TY	用途/備考 REMARKS
1	特殊 LUG		7x7x14 スス	2	
			CODE NO. 000-536-100		
2	圧着端子 CRIMP-ON LUG		FV1.25-M3 7カ	16	
			CODE NO. 000-538-110		
3	圧着端子 CRIMP-ON LUG		FV1.25-4	11	
			CODE NO. 000-538-114		
4	圧着端子 CRIMP-ON LUG		FV5.5-4	19	
			CODE NO. 000-538-123		

DWG NO.









C3387-M01- E

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

**FURUNO**

CODE NO	008-470-020	03CQ-X-9420-
TYPE	CP03-16411	

工事材料表 INSTALLATION MATERIALS		レーダー RADAR	フレックサイト®(FR-9)工事用 FOR FR-9 RECTGUIDE (FLEXIBLE WAVEGUIDE)		
番号 No	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	リング O-RING		AS568-128 1115-70 CODE NO 000-851-842	3	
2	六角ボルトスリ割付 HEX.BOLT(SLOTTED WASHER HEAD)		M4X16 SUS304 CODE NO 000-882-042	4	
3	グラウンド本体 THRU-DECK CABLE GLAND		03-009-0521-1 CODE NO 100-207-551	1	
4	座金 WASHER		03-009-0522-0 CODE NO 100-207-560	2	
5	パッキン (1) RUBBER PACKING (1)		03-009-0523-0 CODE NO 100-207-570	2	
6	パッキン (2) RUBBER PACKING (2)		03-009-0524-0 CODE NO 100-207-580	2	
7	防水フィルム WATERTIGHT FILM		03-009-0368-0 CODE NO 300-903-680	1	
8	締付グラウンド GLAND		JIS F8801 A45 CODE NO 000-806-094	1	
			CODE NO		
			CODE NO		




(略図の寸法は、参考値です。)

図番 (1/1)  
DWG. NO. C3006-M01-D

FURUNO ELECTRIC CO., LTD

**FURUNO**

CODE NO.		03CQ-X-9414-
TYPE		

工事材料表 INSTALLATION MATERIALS		レーダーレクタカイト <sup>®</sup> (FR-9) RADAR RECTGUIDE			
番号 No.	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	FR-9レクタカイト <sup>®</sup> RECTGUIDE		FR-9-20 *20M* CODE NO. 000-805-738	1	選択 TO BE SELECTED
1	FR-9レクタカイト <sup>®</sup> RECTGUIDE		FR-9-30 *30M* CODE NO. 000-805-739	1	
1	FR-9レクタカイト <sup>®</sup> RECTGUIDE		FR-9-50 *50M* CODE NO. 000-805-740	1	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		











\*1 別梱包  
\*1 PACKED SEPARATELY

(略図の寸法は、参考値です。)

図番 (1/1)  
DWG. NO. C3006-M03-B

**FURUNO**

CODE NO.	000-086-743	03EP-X-9405-
TYPE	CP03-16400	

工事材料表 INSTALLATION MATERIALS		WRJ-9	レーダー方形導波管工事用 FOR RADAR RECTANGULAR WAVEGUIDE INSTALLATION		
番号 No.	名 称 N A M E	略 図 OUTLINE	型 名 / 規 格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	六角ボルトスリ割付 HEX. BOLT (SLOTTED WASHERHEAD)		M4X16 SUS304 CODE NO. 000-881-912	80	
2	Oリング O-RING		AS568-128 1115-70 CODE NO. 000-851-842	20	
3	コウシヨウWG. Hバント WAVEGUIDE H-BEND		RWA-1040 B-108 CODE NO. 310-100-160	2	
4	チョークフランジ WAVEGUIDE FLANGE (CHOKE)		WRJ-9 BRASS CODE NO. 000-879-242	7	
5	カバーフランジ WAVEGUIDE FLANGE (PLAIN)		WRJ-9 BRASS CODE NO. 000-879-262	7	
6	導波管保護ゴム RUBBER CUSHION		RWA-1011-0 CODE NO. 310-110-110	15	
7	防水フィルム WATERTIGHT FILM		03-009-0368-0 CODE NO. 300-903-680	1	
8	導波管押え(3)E型 WAVEGUIDE CLAMP (3) E-TYPE		RSB-2007-0 CODE NO. 360-220-070	15	
9	六角ボルトスリ割付 HEX. BOLT (SLOTTED HEAD)		M4X35 SUS304 CODE NO. 000-862-118	35	
10	ミカキ平座金 FLAT WASHER		M4 SUS304 CODE NO. 000-864-126	65	





FR-1222X/1622X/2020X  
FR-2822X/FAR-2822X  
FR-2120W/2150W  
FR-2825W/FAR-2825W  
FR-2855W/FAR-2855W

(略図の寸法は、参考値です。)

図 番 (1/2)  
DWG. NO. C3006-M06-D

**FURUNO**

CODE NO.	000-086-743	03EP-X-9406-2
TYPE	CP03-16400	





工事材料表 INSTALLATION MATERIALS		WRJ-9 レーダー方形導波管工事用 FOR RADAR RECTANGULAR WAVEGUIDE INSTALLATION			
番号 No.	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
11	ハネ座金 SPRING WASHER		M4 SUS304 CODE NO. 000-864-256	35	
12	六角ナット HEX. NUT		M4 SUS304 CODE NO. 000-863-106	35	
13	WG貫通金物組立 THRU-DECK WAVEGUIDE		RWG-1000-0 CODE NO. 310-710-000	1	
14	導波管*1 WAVEGUIDE STRAIGHT		RWA-1020 A-107A CODE NO. 310-100-420	4	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		

\*1別梱包 PACKED SEPARATELY.  
 FR-1222X/1622X/2020X  
 FR-2822X/FAR-2822X  
 FR-2120W/2150W  
 FR-2825W/FAR-2825W  
 FR-2855W/FAR-2855W  
 (略図の寸法は、参考値です。)

図 番 (2/2)  
 DWG. NO. C3006-M07-D

**FURUNO**

CODE NO.	008-254-170	03CQ-X-9501 -6 1/1
TYPE	FP03-02710	

付属品表		FR-2135S/2135SW FR-2135S-B FR/FAR-2835S FR/FAR-2835SW FR/FAR-2865SW FR-2135SW-MSA	船舶用レーダー  MARINE RADAR		
ACCESSORIES					
番号 NO.	名称 NAME	略図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	六角レンチ HEX. WRENCH		対辺6	1	
			CODE NO. 000-830-134		
2	つり上げ金具 LIFTING FIXTURE		03-015-3233-0	2	
			CODE NO. 100-090-720		
3	取付用カラー COLLAR FOR LIFTING FIXTURE		03-015-3234-0	2	
			CODE NO. 100-090-730		
4	ボルト BOLT		03-029-0403-0	1	
			CODE NO. 100-091-140		







 DWG NO.  
 C3407-F01- F

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

**FURUNO**

CODE NO.	008-459-790	03EU-X-9502-4
TYPE	FP03-05701	

付 属 品 表 ACCESSORIES		FR/FAR-2815/2825/2835S /2855/2855W 船用レーダー /2865SW/2825W/2835SW MARINE RADAR FA-2805			
番号 No.	名 称 N A M E	略 図 O U T L I N E	型 名 / 規 格 D E S C R I P T I O N S	数量 Q'TY	用途 / 備考 R E M A R K S
1	キーシート(E) KEY LABEL(E)		03-133-1802-1 CODE NO. 100-233-420	1	
2	システム銘板 NO.1 NAME PLATE NO.1		03-009-0343-0 CODE NO. 300-903-430	2	
3	システム銘板 NO.2 NAME PLATE NO.2		03-009-0344-0 CODE NO. 300-903-440	2	
4	端子板カバー PANEL BOARD COVER		ZM-47A CODE NO. 000-532-491	2	
5	ホールプラグ HOLE PLUG		NO. 4567 CODE NO. 000-800-729	4	
6	RPフライントフィルム RP BRIND FILM		03-133-1636-0 CODE NO. 100-244-490	1	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		

英文 / 操作パネル一体型  
ENGLISH / PANEL FITTED

(略図の寸法は、参考値です。)

図 番 (1/1)  
DWG. NO. C3418-F02-F



# FURUNO

CODE NO.	000-807-203	03EU-X-9504-2
TYPE	03-133-1811-0	

[illegible]




(略図の寸法は参考値です。)

図 番 (1/1)  
DWG. NO. C3418-F04-E



**FURUNO**



CODE NO.	008-464-880	03EU-X-9302 -2
TYPE	SP03-11701	BOX NO. P

SHIP NO.		SPARE PARTS LIST FOR		U S E			SETS PER VESSEL	
		FR/FAR-2800シリーズ FR-2100シリーズ  RADAR		送受信部予備品  SPARE PARTS FOR TRANSCEIVER UNIT				
ITEM NO.	NAME OF PART	OUTLINE	DWG. NO. OR TYPE NO.	QUANTITY			REMARKS/CODE NO.	
				WORKING		SPARE		
				PER SET	PER VES			
1	ヒューズ FUSE		FGB0 0.5A AC125V	2		2		
							000-549-060	
2	ヒューズ FUSE		FGB0-A 5A AC125V	1		2		
							000-549-064	
3	ヒューズ FUSE		FGB0-A 2A AC125V	*		2	*25/30KW用1個 50/60KW用2個	
							000-549-062	
MFR'S NAME		FURUNO ELECTRIC CO.,LTD		DWG NO.		C3412-P01- D		
						1/1		

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

**FURUNO**

CODE NO.	008-452-700	03EP-X-9301 -3
TYPE	SP03-10320	BOX NO. P

SHIP NO.		SPARE PARTS LIST FOR		U S E			SETS PER VESSEL
		FR-2155/2155-B 船舶用レーダー FR-2125W/2165DS FR-2135S/2135SW FR-2135S-B/2825W FR-2855/2855W MARINE RADAR FR-2865SW FR-2835S/2835SW			電源制御部用 FOR POWER CONTROL UNIT		
ITEM NO.	NAME OF PART	OUTLINE	DWG. NO. OR TYPE NO.	QUANTITY			REMARKS/CODE NO.
				WORKING		SPARE	
				PER SET	PER VES		
1	ヒューズ FUSE		FG80-A 2A AC125V	1		2	
							000-549-062
2	ヒューズ FUSE		FG80 10A AC125V	2		4	
							000-549-065
MFR'S NAME		FURUNO ELECTRIC CO., LTD		DWG NO.		C3387-P01- D	1/1


(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

- 注 記 1) 装備ケーブルはサービス時、指示部を前方に十分引き出せるよう余裕を持たせること。  
2) 取付用ネジはM10ボルト又は コーチボルト呼び径9を使用のこと。  
3) #印寸法は最小サービス空間寸法とする。

- NOTE 1) SUFFICIENT EXTRA CABLINGS SHOULD BE ALLOWED AT THE BACK OF THE UNIT SO THAT THE UNIT CAN BE DRAWN OUT WITH THE CABLES CONNECTED FOR MAINTENANCE.  
2) USE M10 BOLTS OR  $\phi 9$  COACH SCREWS FOR FIXING THE UNIT.  
3) #:RECOMMENDED SERVICING CLEARANCE.

範囲 DIMENSION	公差 TOL.
$L \leq 50$	$\pm 1 \text{ mm}$
$50 < L \leq 100$	$\pm 2 \text{ mm}$
$100 < L \leq 500$	$\pm 3 \text{ mm}$
$500 < L \leq 1000$	$\pm 4 \text{ mm}$
$1000 < L \leq 2000$	$\pm 5 \text{ mm}$
$2000 < L \leq 4000$	$\pm 7 \text{ mm}$
$4000 < L \leq 8000$	$\pm 10 \text{ mm}$
$8000 < L$	$\pm 15 \text{ mm}$

表 1  
TABLE 1




DRAWN Oct. 7 '97 T. YAMASAKI		TITLE RDP-115
CHECKED Oct. 7 '97 K. HIRASAKI		名 稱 指示器 (卓上型)
APPROVED Oct. 7 '97 H. HIRASAKI	FR/FAR-2805 SER.	外 寸 図
SCALE 1/20	MASS 85 kg	NAME DIAPLAY UNIT (TABLETOP)
DWG. No. C3418-G02-C	03-133-1000-G2	OUTLINE DRAWING

- 注 記 1) 装備ケーブルはサービス時、指示部を前方に十分引き出せるよう余裕を持たせること。  
2) 取付用ネジはM10ボルト又は コーチボルト呼び径9を使用のこと。  
3) #印寸法は最小サービス空間寸法とする。


- NOTE 1) SUFFICIENT EXTRA CABLINGS SHOULD BE ALLOWED AT THE BACK OF THE UNIT SO THAT THE UNIT CAN BE DRAWN OUT WITH THE CABLES CONNECTED FOR MAINTENANCE.  
2) USE M10 BOLTS OR  $\phi 9$  COACH SCREWS FOR FIXING THE UNIT.  
3) #:RECOMMENDED SERVICING CLEARANCE.

範囲 DIMENSION	公差 TOL.
$L \leq 50$	$\pm 1 \text{ mm}$
$50 < L \leq 100$	$\pm 2 \text{ mm}$
$100 < L \leq 500$	$\pm 3 \text{ mm}$
$500 < L \leq 1000$	$\pm 4 \text{ mm}$
$1000 < L \leq 2000$	$\pm 5 \text{ mm}$
$2000 < L \leq 4000$	$\pm 7 \text{ mm}$
$4000 < L \leq 8000$	$\pm 10 \text{ mm}$
$8000 < L$	$\pm 15 \text{ mm}$


表 1  
TABLE 1



DRAWN Oct. 7 '97 T. YAMASAKI		TITLE RDP-115
CHECKED Oct. 7 '97 K. Kusunoki		名 稱 指示器 (卓上・パネル分離型)
APPROVED Oct. 7 '97 K. Kusunoki	FR/FAR-2805 SER.	外 寸 図
SCALE 1/20	MASS 82 kg	NAME DIAPLAY UNIT (TABLETOP W/O KEYBOARD)
DWG. No. C3418-G01- C	03-133-1100-G2	OUTLINE DRAWING



取付寸法図 (矢視 A)  
FLAT MOUNTING DIMENSION (VIEWING A)



DRAWN July 6, 1995 Morimoto		TYPE RDP-115
CHECKED July 6, '95 T. Mahe	FR2805SER	名称 操作部外寸図
APPROVED July 6, '95 K. Okamoto	FAR2805SE FA2805	NAME CONTROL UNIT
SCALE 1/5	MASS 3 kg	DWG NO. C3418-G04- A 03-133-1600- G0
	APPLICABLE TO; (MODEL)	BLOCK NO.


- 注 記 1) 装備ケーブルはサービス時、指示部を前方に十分引き出せるよう余裕を持たせること。  
2) 取付用ネジはM10ボルト又は コーチボルト呼び径9を使用のこと。  
3) #印寸法は最小サービス空間寸法とする。

- NOTE 1) SUFFICIENT EXTRA CABLINGS SHOULD BE ALLOWED AT THE BACK OF THE UNIT SO THAT THE UNIT CAN BE DRAWN OUT WITH THE CABLES CONNECTED FOR MAINTENANCE.  
2) USE M10 BOLTS OR  $\phi 9$  COACH SCREWS FOR FIXING THE UNIT.  
3) #: RECOMMENDED SERVICE CLEARANCE.


寸法範囲 (mm) DIMENSION	公差 (mm) TOLERANCE
$0 < L \leq 50$	$\pm 1.5$
$50 < L \leq 100$	$\pm 2.5$
$100 < L \leq 500$	$\pm 3$
$500 < L \leq 1000$	$\pm 4$
$1000 < L \leq 2000$	$\pm 5$

表 1  
TABLE 1


銘板  
NAMEPLATE




A



ケーブル押さえ金具上のネジより接地  
GROUND THRU CABLE CLAMP SCREW



取付寸法図 (矢視 A)  
MOUNTING DIMENSION (VIEWING A)



DRAWN July 27 '00 T. YAMASAKI  
CHECKED July 27 '00 Y. KIM  
APPROVED July 27 '00 T. KIM

SCALE 1/20 MASS  $\pm 10\%$  120 kg

DWG. No. C3418-G03- H

FR/FAR-2805 SERIES

03-133-1200-G1

TITLE RDP-115



名称 指示器 (コンソール型)

外寸図


NAME DIAPLAY UNIT (CONSOLE)

OUTLINE DRAWING





取付寸法  
MOUNTING DIMENSIONS




NOTE 1. 推奨サービス空間  
RECOMMENDED SERVICING CLEARANCE

種類※ ANT. TYPE	200cm 型 TYPE (XN-3A)	240cm 型 TYPE (XN-4A)	300cm 型 TYPE (XN-5A)
空中線長 ANT. LENGTH (A)	2070mm	2570mm	3210mm
回転直径 DIA. OF ROTATION (B)	2200mm	2700mm	3340mm
質量 MASS	39.5kg	42kg	44.5kg

※選択可能な空中線部種類はレーダー型式により異なる。各仕様を参照のこと。  
SELECTABLE ANTENNA TYPE DEPENDS ON RADAR MODEL. SEE INDIVIDUAL SPECIFICATIONS.

NOTE 3. 取付台の平面度は±1mm以内のこと。  
THE SURFACE OF PLATFORM SHOULD BE EVEN WITHIN ±1mm.

REMARKS XN3A/4A/5A		TYPE RSB0041/RSB0042/RSB0043/RSB0046	
DRAWN M. IKEDA Feb 9, '97		名称 空中線部	
SCALE 1/10		NAME RADAR SCANNER UNIT	
MASS kg	APPLICABLE TO; (MODEL)	BLOCK NO.	DWG NO. C 3 3 3 2 - G 0 1 - K



## 注意:

1. 電蝕防止のため、組立時にボルト、ナット、ワッシャ及びフランジ面の  
Oリング溝外側の部分に支給のシリコンシール剤(無酸性)を塗布する。  
Oリング及びOリングの溝には塗布しないこと。
2. Oリングに傷をつけたり、ゴミを付着させないように注意のこと。
3. Oリング及びスキャナカバーのパッキンにはグリースを使用すること。  
シリコンシール剤は使用不可。

## NOTE:

1. APPLY SILICONE SEALANT (SUPPLIED, NON-ACID TYPE) ON  
BOLTS, NUTS, WASHER AND WAVEGUIDE FLANGE OUTSIDE  
O-RING GROOVE TO AVOID ELECTRICAL CORROSION. (DO NOT  
APPLY SEALANT TO O-RINGS AND O-RING GROOVES.)
2. DO NOT PINCH O-RING AND KEEP IT CLEAN.
3. FOR PACKINGS OF SCANNER COVERS AND O-RINGS, DO NOT  
USE SILICONE SEALANT, BUT RATHER USE GREASE.

No.	名称 NAME	型式 SPECIFICATION	数量 Q'TY
1	Oリング O-RING	ASS68-125	2
2	六角セムス(B) HEX. BOLT(B) (WASHER HEAD)	M4x16 (SUS304)	8
3	六角ボルト HEX. BOLT	M8x35 (SUS304)	4
4	バネ座金 SPRING WASHER	FOR M8用(SUS304)	4
5	平座金 FLAT WASHER	FOR M8用(SUS304)	4
6	六角ボルト HEX. BOLT	M8x30 (SUS304)	4
7	平座金 FLAT WASHER	FOR M8用(SUS304)	8
8	バネ座金 SPRING WASHER	FOR M8用(SUS304)	4
9	六角ナット HEX. NUT	M8 (SUS304)	4
10	六角ボルト HEX. BOLT	M4x30 (SUS304)	2
11	バネ座金 SPRING WASHER	FOR M4用(SUS304)	2
12	平座金 FLAT WASHER	FOR M4用(SUS304)	2
13	導波管押え W/G CLAMP	RSB-2006-1	1
14	導波管間座 W/G PACKING	03-003-4003-0	1

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	MAY. 25. '79	三角法 THIRD ANGLE PROJECTION	名称 TITLE	空中線部組立図 SCANNER UNIT ASSEMBLING (XN3A/XN4A)	
検 CHECKED	MAY. 25. '79	尺度 SCALE			
製 DRAWN	25. 5. 79 H. Kusumoto	重量 WEIGHT	kg	図番 DWG. NO.	C3249-017-H

4

3

2

1

NOTE 1. ※ 推奨サービス空間

RECOMMENDED SERVICE CLEARANCE

NOTE 2.

種類 **	200cm型 TYPE (XN20AF)	240cm型 TYPE (XN24AF)
ANT. TYPE	(A)	(B)
空中線長	2,040 ± 10 mm	2,550 ± 10 mm
回転安全スペース (B) ANT. CLEARANCE	2,200 mm	2,700 mm
質量 MASS	39.5 kg	42 kg

\*\*選択可能な空中線部種類はレーダー型式により異なる。  
各仕様を参照のこと。

SELECTABLE ANTENNA TYPE DEPENDS ON RADAR MODEL.  
SEE INDIVIDUAL SPECIFICATIONS.

NOTE 3. 取付台の平面度は±1 mm以内のこと。  
THE SURFACE OF PLATFORM SHOULD BE EVEN WITHIN ±1 mm.



NOTE 4. 指定外の寸法公差は表1による  
REFER DIMENSION TOLERANCE TO TABLE 1.

範囲 DIMENSION	公差 TOL.
0 < L ≤ 50	±1.5 mm
50 < L ≤ 100	±2.5 mm
100 < L ≤ 500	±3 mm
500 < L ≤ 1000	±4 mm
1000 < L ≤ 2000	±5 mm
2000 < L ≤ 4000	±7 mm
4000 < L ≤ 8000	±10 mm
8000 < L	±15 mm

表 1 TABLE 1

DRAWN Aug 20 1997 T. YAMASAKI	CHECKED Apr 26 1998 K. KAWADA	TITLE RSB-0076/0077/0078
APPROVED May 26 1998 K. KAWADA	SCALE 1/10	名称 空中線部
DMC No. C3466-G01-B	MASS kg	外寸図
03-145-3200-G1		NAME ANTENNA UNIT
		OUTLINE DRAWING


FURUNO ELECTRIC CO., LTD.



A

B

C



DRAWN Nov. 22 '95 T. NISHINO				TYPE RTR-046
CHECKED Nov. 22 '95 K Okamoto				名称
APPROVED Nov. 22 '95 K Okamoto		FAR-2825W FR-2825W		外寸図
SCALE x	MASS 13.5 kg	APPLICABLE TO; (MODEL)	BLOCK NO.	NAME
DWG NO. C3405-G03- A		03-130-5000- GO		OUTLINE DRAWING

3



3

2

1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
0 < L ≤ 50	± 1.5
50 < L ≤ 100	± 2.5
100 < L ≤ 500	± 3
500 < L ≤ 1000	± 4

表 1 TABLE 1




## 注 記


- 1) 壁面と吸排気口の空間は100mm以上とすること。
- 2) ケーブル導入口はどちらか一方を選択し、工事前にケーブルクランプを取付けておく。
- 3) 指定外の寸法公差は表 1 による。
- 4) # : 推奨する最小サージス空間寸法。

## NOTE:

1. KEEP CLEARANCE MORE THAN 100mm FOR AIR INLET/OUTLET.
2. SELECT EITHER ONE OF CABLE ENTRANCES. GANGE THE CABLE CLAMP IN POSITION BEFORE MOUNTING IF NECESSARY.
3. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.
4. #: RECOMMENDED SERVICE CLEARANCE.

(選択)  
ケーブル導入口  
CABLE ENTRANCE  
(SELECT)


DRAWN Aoyagi Co. T. YAMASAKI	CHECKED Aoyagi Co. Y. K.	APPROVED Aoyagi Co. Y. K.	SCALE 1/7	MASS 35 kg	DWG. No. C3300-002-E	03-017-500G-1	OUTLINE DRAWING
TITLE 名称	RTR-010 送受信部	FR-1252X/2050X FR/FAR-1652X FR/FAR-2852X	外寸図	NAME TRANSCIVER UNIT			



## 注記

- 1) 指定なき寸法公差は表1による。
- 2) #: 推奨する最小サービス空間寸法。
- 3) 取付ネジはトラスタッピンネジ呼び径5×20を使用のこと。


## NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.
2. #: RECOMMENDED SERVICE CLEARANCE.
3. USE TAPPING SCREWS 5x20 FOR FIXING THE UNIT.

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
0 < L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3

DRAWN June 27 '00 T. YAMASAKI	TITLE PSU-004
CHECKED June 27 '00 Y. Kuni	名称 電源制御部
APPROVED June 27 '00 Y. Kuni	外寸図
SCALE 1/4	NAME POWER SUPPLY UNIT
MASS 2.3 kg	OUTLINE DRAWING
DWG. No. C3385-G02- D	




注記

1) 指定なき寸法公差は表 1 による。

NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.

DRAWN June 28 '00 T. KAMASAKI		TITLE RU-1758/1803
CHECKED June 28 '00 Y. K.		名称 トランスユニット
APPROVED June 28 '00 Y. K.		外寸図
SCALE 1/5	MASS ±10% 12 kg	NAME TRANSFORMER UNIT
DWG. No. C3003-001- E		OUTLINE DRAWING



DRAWN Aug 16 '00 T. YAMASAKI		TITLE RU-5466-1, RU-6764/5693
CHECKED Aug 17 '00 Y. K.		名称 トランスユニット
APPROVED Aug 17 '00 Y. K.		外寸図
SCALE 1/3	MASS $\pm 10\%$ 12 kg	NAME TRANSFORMER UNIT
DWG. No. C3003-006- F		OUTLINE DRAWING






A

B

C

D




DRAWN Aug 16 '00 T. YAMASAKI	TITLE RU-6347/6522
CHECKED Aug 17 '00 Y. K.	名称 トランスユニット
APPROVED Aug 17 '00 Y. K.	外寸図
SCALE 1/3	NAME TRANSFORMER UNIT
MASS 12 kg ±10%	OUTLINE DRAWING
DWG. No. C3003-007- C	

A

B

C

D




コンパス安全距離 COMPASS SAFE DISTANCE

スタンダード STANDARD	2.1 m
ステアリング STEERING	1.5 m

DRAWN  
Aug 16 '00 T. YAMASAKI  
CHECKED  
Aug 17 '00 T. Kuni  
APPROVED  
Aug 17 '00 T. Kuni  
SCALE  
1/5  
MASS ±10%  
12.2 kg  
DWG. No.  
C3003-004- D

TITLE  
RU-3305  
名称  
トランスユニット  
外寸図  
NAME  
TRANSUFORMER UNIT  
OUTLINE DRAWING



注意: NOTE:


- \* 99: コネクタ  
CONNECTOR  
 \* 99: ツイストペア線  
TWISTED-PAIR  
 \* 銅板にて接地  
GROUNDING COPPER STRAP  
 \* 1V-8sq. 或いは同等品にて接地  
GROUNDING WIRE 1V-8sq.  
 ---: オプション支給  
OPTIONAL SUPPLY


- \* 1: 造船所取手配  
SHIPYARD SUPPLY  
 \* 2: 工場にて取付済  
FITTED AT FACTORY.  
 \* 3: コネクタのクランプでアースに落とす。  
GROUND THROUGH CONNECTOR CLAMP.  
 \* 4: [太] は太線を示す。  
[B] REPRESENTS THICKER WIRES.

CO-0.2x2P: CO-SPEVV-SB-C 0.2x2P, #10.5  
 CO-0.2x5P: CO-SPEVV-SB-C 0.2x5P, #13.5  
 CO-0.2x10P: CO-SPEVV-SB-C 0.2x10P, #16.5

承認 APPROVED	Sept 5 '96 K. C. H.	名称 TITLE	FR-2825W FAR-2825W 船舶用レーダー MARINE RADAR
検図 CHECKED	Sept 5 '96 K. Kawano	図番 DWG. NO.	C3405C03B000
製図 DRAWN	Sept 5 '96 Y. F. T. S. U.		








B7INT9170  
(1/2)

DRAWN July 18, 1995 Morimoto		TYPE INT9170	
CHECKED July 18, '95 Maki		名称 INT基板 (1/2)	
APPROVED July 18, 95 Okamoto		NAME INT BOARD (1/2)	
SCALE	MASS kg	APPLICABLE TO: (MODEL)	DWG NO. C3418-K01- A 03-131-6004- 1



DRAWN July 18, 1995 Norimoto		TYPE INT9170
CHECKED July 18, '95 Maki	FR2805SER FAR2805SE FA2805	名称 INT基板 (2/2)
APPROVED July 18 '95 Okamoto	1B 7	NAME INT BOARD (2/2)
SCALE /	MASS kg	APPLICABLE TO: (MODEL)
		BLOCK NO.
		DWG NO. C3418-K02- A 03-131-6004- 1


A

B


C

D


MOTOR SPEC.		ANTENNA TYPE	
TYPE	POWER SUPPLY	XN-204F/244F	XN-34F/4A
RM-8123	200V, 3 $\phi$ , 50Hz	RSB-0076	RSB-0041
RM-8124	380V, 3 $\phi$ , 50Hz	RSB-0077	RSB-0042
RM-8247	440V, 3 $\phi$ , 60Hz	RSB-0078	RSB-0043
RM-8628	100V, 1 $\phi$ , 50Hz		
	100V, 1 $\phi$ , 60Hz		
	220V, 1 $\phi$ , 50Hz		RSB-0046







DRAWN NOV. 2 '95 E. KISHIMA		TYPE RTR046
CHECKED NOV. 2 '95 T. SAITO		名称 送受信部
APPROVED NOV. 2 '95 K. OHTA	FR-2825W FAR-2825W	回路図
SCALE /	MASS kg	NAME TRANSCIEVER UNIT
DWG NO. C3405-K01- B	03-130-6008- 0	SCHEMATIC DIAGRAM



DRAWN APR 24 '76 E. KISHIMA	FAR2855W	TYPE RTR-010
CHECKED APR 24 '76 T. SAITO	FR2855W	名称 送受信部総合回路図
APPROVED APR 24 '76 K. ITO	FR2150W	回路図
SCALE 1/10	FR2050X	NAME TRANSCIVER UNIT
DWG NO. C3300-005-N	FR2852X	SCHEMATIC DIAGRAM
	APPLICABLE TO: (MODEL)	BLOCK NO.




表1 TABLE 1

船内電源 SHIP'S MAINS	空中線部 SCANNER UNIT	サーマルリレー THERMAL RELAY (K2)
200/220VAC, 3φ	RSB-0026/0027	TR-0NH/3, 1.7A
220VAC, 3φ	RSB-0088/0089	TR-0NH/3, 1.7A
380/440VAC, 3φ	RSB-0031/0032	TR-0NH/3, 0.8A
440VAC, 3φ	RSB-0090	TR-0NH/3, 0.8A
200/220VAC, 3φ	RSB-0041	TR-0NH/3, 0.8A
380/440VAC, 3φ	RSB-0042	TR-0NH/3, 0.36A
200/220VAC, 3φ	RSB-0049	TR-0NH/3, 0.8A
100VAC, 1φ	RSB-0043/0078	TR-0NH/3, 0.8A
220VAC, 1φ	RSB-0046	TR-0NH/3, 0.8A
24VDC	RSB-0050	TR-0NH/3, 0.8A
	RSB-0051	TR-0NH/3, 0.8A

注記  
\*1) 設定値は表1を参照。  
\*2) FR-2160DSのときはPTB-14Dと#6を現型で短絡すること

NOTE  
\*1. REFER TO TABLE 1 FOR THERMAL RELAY SETTINGS.  
\*2. FOR FR-2160DS, PUT A JUMPER BETWEEN #4 AND #6 OF PTB-14 AT INSTALLATION.

DRAWN JUN. 20 '01 T. YAMASAKI	CHECKED T. YAMASAKI	APPROVED T. YAMASAKI	SCALE 1/100	DWG. NO. C3385-K01-F
-------------------------------------	------------------------	-------------------------	----------------	-------------------------

TITLE PSU-004	名称 電源制御部
回路図	NAME POWER SUPPLY UNIT
SCHMATIC DIAGRAM	FURUNO ELECTRIC CO., LTD.