

FURUNO

INSTALLATION MANUAL

MARINE RADAR/ARPA

MODEL FR/FAR-2855



FURUNO ELECTRIC CO., LTD.
NISHINOMIYA, JAPAN

© **FURUNO ELECTRIC CO., LTD.**

9-52, Ashihara-cho,
Nishinomiya, Japan

Telephone: 0798-65-2111
Telefax: 0798-65-4200

•Your Local Agent/Dealer

All rights reserved.

Printed in Japan

FIRST EDITION : DEC. 2000
D : JUL. 18, 2000

(TATA)

PUB. No. IME-34190-D
FAR/FR-2855



* 00080726600 *

SAFETY INSTRUCTIONS

"**DANGER**", "**WARNING**" and "**CAUTION**" notices appear throughout this manual. It is the responsibility of the installer of the equipment to read, understand and follow these notices. If you have any questions regarding these safety instructions, please contact a FURUNO agent or dealer.



DANGER

This notice indicates a potentially hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

This notice indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

This notice indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or property damage.



DANGER



Hazardous voltage.
Can shock, burn, or cause death.

Only qualified personnel should work in the units of a radar system.

Turn off the power at the ship's mains switchboard before beginning the installation. Post a warning sign near the switchboard to ensure the power will not be applied while the radar system is being installed.

Electrical shock, fire, serious injury or death can result if the power is not turned off, or is applied while the equipment is being installed.



WARNING



Microwave radiation can be harmful to the human body, particularly the eyes.

Distances at which radiation level of 100 and 10 W/m² exist are;

Model	Radiation level	XN3A	XN4A	XN5A
FR-2855 (X-band, 50kW)	100W/m ² 10W/m ²	Nil 2.0 m	Nil 1.9 m	Nil 1.8 m



WARNING



Turn off the radar power switch before working on the antenna unit. Post a warning sign near the switch to ensure it will not be turned on while the antenna unit is being installed.

Serious injury or death can result if the radiator starts rotating and strikes someone near the scanner unit.



Wear a safety belt and hard hat when working on the antenna unit.

Serious injury or death can result if someone falls from the scanner mast.



WARNING

The neck of the scanner unit becomes VERY HOT when the de-icer is working.

Before beginning any work on the scanner unit, turn off the breaker for the de-icer line at the main switchboard to remove the power (100VAC, 1Ø) to the de-icer.
(Turning off the power to the display unit has no effect.)



CAUTION



Ground both the display unit and the antenna unit.

Ungrounded equipment can give off or receive interference or cause electrical shock.

Confirm that the power supply voltage is compatible with the voltage rating of the equipment.

Connection to the wrong power supply can cause fire or equipment damage. The voltage rating appears on the label at the rear of the display unit.

Use only the supplied power cable.

Use of other power cables (particularly a cables whose diameter is smaller than the supplied cable) can cause fire or short circuit.

Use the correct fuse.

Use of a wrong fuse can cause fire or equipment damage.

TABLE OF CONTENTS

1. MOUNTING

1.1 Assembling the Scanner Unit	1-2
1.2 Mounting the Scanner Unit on the Mounting Platform	1-4
1.3 Mounting the Display Unit	1-8
1.4 Mounting the Separate Type Control Panel	1-9
1.5 Power Supply Unit	1-10

2. CONNECTIONS

2.1 Antenna Unit Connections	2-1
2.2 Power Supply Unit PSU-001	2-5
2.3 Power Supply Unit PSU-004	2-7
2.4 Display Unit Connection	2-8

3. INITIALIZATION AND ADJUSTMENT


3.1 Preparation for Initialization and Adjustment	3-1
3.2 Heading Alignment	3-2
3.3 Adjusting Sweep Timing	3-2
3.4 Adjusting Video Signal Level	3-3
3.5 Suppressing Main Bang	3-4
3.6 Confirming Tuning	3-4
3.7 Adjustment	3-5
3.8 Initial Settings Menus	3-6
3.9 Setting the Function Keys	3-8
3.10 Menus for Initialization and Adjustment	3-11
3.11 Adjusting the ARP Board	3-12
3.12 Installation Check List	3-14

4. INSTALLATION OF GYRO CONVERTER GC-8 (option)

4.1 General Procedure for Installing and Setting up the GYRO CONVERTER Board	4-1
4.2 Connection of External Power Supply	4-3
4.3 Confirming Gyrocompass Specifications	4-3
4.4 Changing Settings on the GYRO CONVERTER Board	4-4
4.5 Setting the Bearing on the Radar Display	4-8

LIST OF INSTALLATION MATERIALS,	
ACCESORIES AND SPARE PARTS	L-1
OUTLINE DRAWINGS	D-1
INTERCONNECTION DIAGRAMS	S-1
SCHEMATIC DIAGRAMS	S-2

FR/FAR-2855 System Configuration



----- Optional Supply

1. MOUNTING



DANGER



Hazardous voltage.
Can shock, burn, or cause death.

Only qualified personnel should work in the units of a radar system.

Turn off the power at the ship's mains switchboard before beginning the installation. Post a warning sign near the switchboard to ensure the power will not be applied while the radar system is being installed.

Electrical shock, fire, serious injury or death can result if the power is not turned off, or is applied while the equipment is being installed.



WARNING



Turn off the radar power switch before working on the antenna unit. Post a warning sign near the switch to ensure it will not be turned on while the antenna unit is being installed.

Serious injury or death can result if the radiator starts rotating and strikes someone near the scanner unit.



Wear a safety belt and hard hat when working on the antenna unit.

Serious injury or death can result if someone falls from the scanner mast.

1.1 Assembling the Scanner Unit

The antenna unit consists of the antenna radiator and the antenna unit chassis. They are packed separately to prevent damage during shipment. Assemble them as shown in the procedure which follows.

Radiator XN3A (200 cm)/XN4A (240 cm)/XN5A (300 cm)




Fig. 1-1 Assembling antenna radiator XN3A/XN4A/XN5A

Table 1-1 XN3A/XN4A/XN5A antenna assembly materials

No.	Name	Specification	Qty
1	O-ring	AS568-125	2
2	Washerhead Hex. Bolt (B)	M4 x 16(SUS304)	8
3	Hex. Bolt (B)	M8 x 35(SUS304)	4
4	Spring Washer	M8(SUS304)	4
5	Flat Washer	M8(SUS304)	4
6	Hex. Bolt	M8 x 30(SUS304)	4
7	Flat Washer	M8(SUS304)	8
8	Spring Washer	M8(SUS304)	4
9	Hex. Nut	M8(SUS304)	4
10	Hex. Bolt	M4 x 30(SUS304)	2
11	Spring Washer	M4(SUS304)	2
12	Flat Washer	M4(SUS304)	2
13	W/G Clamp	RSB-2006-1	1
14	W/G Gasket	03-003-4003-1	1

Procedure

- 1) Remove the radiator joint flange cap. The cap may be discarded.
- 2) Wipe the feeder waveguide and radiator joint with a clean cloth.
- 3) Coat the waveguide flange with silicone sealant as shown in the figure below.




Fig. 1-2 Coating the waveguide flange with silicone sealant

- 4) Insert the O-ring (1) into the O-ring groove of the radiator flange of the rotary joint. Fix the feeder waveguide with hex. bolts (2).
- 5) Loosely fasten the antenna radiator to the radiator bracket with hex. bolts (3) and (6), flat washers (5) and (7), spring washers (4) and (8), and hex. nuts (9).
- 6) Insert the O-ring (1) into the O-ring groove of the flange section of the feeder waveguide. Fix the feeder waveguide with hex. bolts (2).
- 7) Fix the feeder waveguide at the bottom of the antenna radiator with the W/G clamp (13), W/G gasket (14), hex. bolts (10), flat washers (12), and spring washers (11).
- 8) Securely fasten the antenna radiator to the radiator bracket.

1.2 Mounting the Scanner Unit on the Mounting Platform

General considerations

- The antenna radiator may be fastened to the rotating bracket before mounting the antenna unit. However, DO NOT lift the antenna unit by its housing. When using a crane or hoist, lift the unit by the hoist rings which should be fastened to the bolt fixing the covers of the antenna housing.
- The antenna unit is constructed of aluminum and therefore subject to galvanic corrosion if improperly fastened to steel structures. To prevent galvanic corrosion, fasten the unit to the mounting platform using the rubber mat and washers (supplied).
- Do not paint the radiator. Performance will be affected.

Siting considerations

- A magnetic compass will be affected if placed too close to the antenna unit. Below are the minimum compass safe distances for magnetic compasses.

Radar model	Standard compass	Steering compass
FR/FAR-2855	4.2 m	3.2 m

- No funnel, mast or derrick should be within the vertical beamwidth of the antenna (XN3A/XN4A/XN5A, 20°) in the bow direction, especially zero degrees $\pm 5^\circ$, to prevent blind sectors and false echoes on the radar picture.
- Fumes from the funnel or other exhaust vent can adversely affect performance and hot gas can distort the radiator. The antenna unit must not be mounted in a place where the temperature may exceed 70°C.
- Leave sufficient space around the unit for maintenance and servicing. See the antenna unit outline drawing for recommended maintenance space.
- Locate the unit well away from the aerial of a radiotelephone or navigation receiver to prevent interference. Separation of more than two meters is recommended.

How to change orientation

The scanner unit is normally mounted with the cable gland (cable entry side) facing the ship's stern. If this is not practical, the direction can be changed in multiples of 90°. In this case, the synchronous gear magnet, which produces the heading signal, should be remounted. Fix the magnet according to scanner unit attitude.




Fig. 1-3 Remounting the synchronous gear magnet

Mounting procedure

- 1) Drill four mounting holes of 15mm diameter in the mounting platform.
- 2) Lay the rubber mat (supplied) on the mounting platform.




Fig. 1-4 Antenna unit, front view




Fig. 1-5 How to lift the antenna unit

- 3) Place the antenna unit on the rubber mat and orient the unit so the bow mark on its base is facing the ship's bow.
- 4) Fasten the antenna unit to the mounting platform with M12 x 60 bolts, nuts, flat washers and seal washers.
- 5) Establish the ground on the mounting platform as shown in Figure 1-6. The location must be within 300mm of the ground terminal on the antenna unit. Use hex bolt (M6 x 25), M6 nut and M6 flat washer.
- 6) Connect the ground wire (RW-4747, 320 mm) between the ground point and the ground terminal on the antenna unit.
- 7) Coat the ground point and the ground terminal with silicone sealant (supplied) as shown in Figure 1-6 to prevent corrosion.





Fig. 1-6 Fastening the antenna unit to the mounting location



1.3 Mounting the Display Unit

The display unit is designed to be mounted on a tabletop or on a pedestal (option).

Before mounting the display unit

If Gyro Converter GC-8 (option) is to be used, install and setup the GYRO PROCESSOR Board before mounting the display unit, because of the difficulty involved if done after the unit is mounted. Instructions for installation and setup are in Chapter 4.

Siting considerations

Locate the display unit on the bridge in a place where it can be viewed and operated conveniently. In addition, consider the points which follow.

- A magnetic compass will be affected if placed too close to the display unit. The minimum compass safe distances for magnetic compasses are
standard compass: 1.6 m
steering compass: 1.2 m
- The orientation of the display unit should be so the operator views the screen while facing the bow. This makes determination of position much easier.
- The location should be free of water spray.
- The daylight bright type radar display provides excellent visibility even in direct sunlight. However, locate the unit out of direct sunlight and away from heat sources because of heat that can build up inside the cabinet.
- The mounting location should be determined considering the length of the signal cable between the antenna unit and the display unit. (The signal cable comes in length of 15, 30 or 50 meters; maximum 100 meters.)
- Leave sufficient space around the unit for maintenance and servicing. See the display unit outline drawing for recommended maintenance space.

Mounting procedure

Tabletop

- 1) Unfasten the three M10 bolts at the front of the display unit and separate the mounting base from the display unit.
- 2) Drill five holes of 12mm diameter in the tabletop.
- 3) Secure the mounting base to the tabletop by using M10 nuts, bolts and flat washers.
- 4) Place the display unit on the mounting base and fasten it to the mounting base with the bolts removed in step 1.

Pedestal

Fix the pedestal to the mounting location with M12 nuts, bolts and washers. (The cable gland is at the bottom of the pedestal.)

1.4 Mounting the Separate Type Control Panel

The separate type control panel connects to the display unit with a connection cable. Non-slip rubber feet (supplied) can be attached to the bottom of the control panel. The panel can be permanently fixed to a tabletop with the control panel fixing plate kit (option).




Fig. 1-7 Mounting dimensions for tabletop mount display unit

1.5 Power Supply Unit

The power supply unit can be installed almost anywhere provided the location is dry and well-ventilated, the compass safe distances are observed, and sufficient maintenance space is provided. The compass safe distances are;

Power unit	Standard compass	Steering compass
PSU-001	1.2 m	0.9 m
PSU-004	0.7 m	0.5 m

The unit may be installed inside the display unit console type.

2. CONNECTIONS

2.1 Antenna Unit Connections

Two cables are connected to the antenna unit: signal cable and power cable.

Signal cable RW-6895

- 1) Shorten the cable to a suitable length, extending the length actually required by 800mm. Strip off about 800mm of the anti-corrosive vinyl sheath, and 790mm of the armor and the inner vinyl sheath.




Fig. 2-1 Fabricating the signal cable RW-6895

- 2) Untwine the outer braided shield with a screwdriver or the like to expose the cores under the outer shield.
- 3) Similar to step 2, expose the cores under the inner shield. Appropriately mark all cores for future identification.
- 4) Slide the clamping gland, washers and rubber packing onto the cable.




Fig. 2-2 Assembling the cable gland

- 5) Determine the length of each core considering their location on STB-1 in the antenna unit. Trim conductors as necessary.




Fig. 2-3 Terminal boards inside scanner unit

- 6) Trim the shields considering their location on the earth terminal inside the scanner unit. Fasten crimp-on lugs (yellow, FV5.5-4) to each shield, then connect them to the ground terminal in the antenna unit.
- 7) Remove the outer sheath of the coaxial cable (2C-2V) by 75mm. Remove the shield of each core by 6mm and fold back each conductor as illustrated below. Fasten crimp-on lugs to each conductor and shield.




Fig. 2-4 Processing the cores of the coaxial cables

- 8) Slip the cable gland over the cable and tighten the cable gland nut. Ground the armor through the two washers. Seal the cable gland nut with putty to maintain watertightness.
- 9) Connect the conductors to terminal STB-1 according to the interconnection diagram.

Power supply cable MPYCY-16

Note that connections are different according to type of antenna motor.

- 1) Loosen the clamping gland of the upper cable gland, and remove the rubber packing and flat washers from the scanner unit.
- 2) Shorten the cable to a suitable length. Remove the vinyl sheath by 600mm. Cut off the armor by 590mm.




Fig. 2-5

- 3) Slide the clamping gland, washers and rubber gasket over the cable. Fold back the armor by 5mm, then put it between washer and cable gland body.




Fig. 2-6

- 4) Determine the length of the cores considering their location on STB-3. Trim conductors as necessary.
- 5) Remove the sheath of each core by 6mm. Fix crimp-on lugs (blue, FV1.25-4) to each conductor. Make sure each connection is secure both electrically and mechanically.
- 6) Secure the clamping gland to the body; then seal with putty.
- 7) Connect the conductors to STB-3, referring to the interconnection diagram.

Power supply cable 660V-DPYCY-1.25

This cable is fabricated the same as the MPYCY-16. Pass the cable into the right side cable gland. Fasten crimp-on lugs (blue, FV1.25-4) to the cores and connect them to STB-2.

Final preparations inside the scanner unit

After all wiring has been completed, check for loose screws and poor contact on crimp-on lugs. Apply grease to scanner cover fixing screws and packing; then replace the scanner cover.

Fixing the scanner cover

Fasten the scanner cover tightly to maintain watertightness. Apply grease to the fixing bolts and tapped holes.




Fig. 2-7

2.2 Power Supply Unit PSU-001

Location of terminal boards

The figure below shows the location of the terminal boards inside the PSU-001.




Fig. 2-8 Power supply unit (PSU-001), cover removed

Changing power supply voltage

The PSU-001 is factory-set for ship's mains of 100VAC, 1 ϕ , 100VAC. For other supply voltage and frequency, follow the instructions shown below.

- 1) Set voltage by transformer T804.
- 2) Set frequency (50Hz or 60Hz) by slide switch behind the hour meter HM801.




Fig. 2-9 Power supply unit (PSU-001)

2.3 Power Supply Unit PSU-004

Location of terminal boards

The figure below shows the location of the terminal boards inside the PSU-004.




Photo N 3148

Fig. 2-10 Power supply unit (PSU-004), cover removed

Changing supply voltage

The table below lists the terminal relays used in the PSU-004. The type of the relay and its presetting differs according to ship's mains.

Ship's Mains	Scanner Unit	Thermal Relay (K2)	
		Type	Presetting
200/220VAC, 3Ø	RSB-0049	T20A-Q1A	0.8A
24VDC	RSB-0050	RAC101505D	5A

Refer to Fig. 2-11 for the fabrication of the TPYCY (DPYCY) cables. The maximum cable length between the cable clamp and the terminal board is 350mm.

2.4 Display Unit Connection

Two cables are terminated at the display unit: the signal cable RW-6895 and the power cable DPCY-3.5. The signal cable, available in lengths of 15m, 20m, or 30m, comes with a connector preattached to it for connection to the display unit.

Fabricating power cable DPYCY-3.5

- 1) Remove the vinyl jacket by 150mm.
- 2) Cut off jute tape wrapped around the braided shield.
- 3) Unravel the braided shield to expose the cores by about 10mm.
- 4) Slip the terminal cap onto the core.
- 5) Remove insulation of cores by about 10mm.
- 6) Fix crimp-on lugs to the cores.
- 7) Cover the braided shield with vinyl tape, leaving the portion which will lie inside the cable clamp untaped.




Fig. 2-11 How to fabricate power cable DPYCY-3.5

Leading in cables to the display unit

To lead in cables easily, unfasten the cable clamp at the right side of the display unit.




Figure 2-12 Location of cable clamp inside the display unit

Tabletop

Cables can be led in through the cable gland at the rear or underside of the unit.

Pedestal

Lead in cables through the cable gland at the bottom right-hand side of the pedestal. Pass cables through the cable clamp and tighten the cable clamp. Fix cables to the pedestal frame with cable ties as shown in Figure 2-13. Finally, pass cables through the cable clamp at the right side of the display unit and then tighten the cable clamp.




Figure 2-13 How to lead in cables through the pedestal

Connections

Power cable

Connect the power cable to the filter at the right hand side of the display unit. Cover the filter terminals with the terminal caps (supplied) to insulate the terminals.




Fig. 2-14 Location of filter inside the display unit

Gyro signal

Solder the 5 pin and 3 pin VH connectors (supplied) to the gyrocompass cable. Plug in the connectors on the GYRO CONVERTER Board. For further details, see page 4-2.




Fig. 2-15 Location of GYRO CONVERTER Board

HOW TO ATTACH NH CONNECTOR TO SIGNAL CABLE

-
- The diagram illustrates the process of attaching an NH connector to a signal cable in four steps:
- ① Insert NH connector wire into NH connector housing.** The diagram shows an 'NH connector wire' being inserted into an 'NH connector housing'.
 - ② Cut shrink tubing in 20 mm lengths and slip onto each wire.** The diagram shows 'Shrink tubing' being cut into a '20mm' length and being slipped onto the wires.
 - ③ Solder connector to signal cable.** The diagram shows the 'Solder' being applied to the connection between the connector and the signal cable.
 - ④ Heat shrink tubing with soldering iron.** The diagram shows the 'Heat shrink tubing' being applied to the connection using a soldering iron, indicated by wavy lines representing heat.


Grounding

The display unit must be grounded at the point circled shown in Fig. 2-16.




CAUTION

Ground the display unit to prevent electrical shock and mutual interference.



Tabletop type



Pedestal type

Fig. 2-16 Grounding the display unit

Radar buoy

Solder the radar buoy signal line to the "BUOY" connector on the VDA Board. Connect the trigger line to the corresponding connector on the INT Board.

Signal input/output circuit (INT Board INT-9170)




Fig. 2-17 INT Board circuit

For other input/output circuits, see the circuit diagram of the INT Board at the back of this manual.

Table 2-1 Input and output signals on the INT Board

Signal name	Name on pcb	Connector no.	Connector type	Applicable equipment	Remarks
Input Signal					
Gyro signal		J4* J5*	VH, 5 pin VH, 3 pin		*: On pcb A64P1106 (option)
Speed log signal	LOG	J448	NH, 3 pin		200 pulses/nm, etc.
Current indicator signal (tide)	NAV COURSE	J459	NH, 4 pin		Not used
Current indicator signal (speed)	NAV SPEED	J460	NH, 3 pin		Not used
Radar buoy signal	RADAR BUOY	J445	NH, 4 pin		
Remote display signal	EXT-RADAR or RJ-7	J458	NH, 8 pin		
Rudder angle signal	ROT RUDDER	J464	NH, 7 pin		
Output Signal					
External ARPA signal	EXT-ARPA	J444	NH, 8 pin	FA-2805	heading, bearing, Tx trigger
Slave display signal	SLAVE	J442 J443	NH, 8 pin	CD-140, CD-141, GD-500, FMD-800, FMD-8000, FR-2800 series	heading, bearing, video, Tx trigger
Buzzer signal	EXT-BUZ	J451	NH, 3 pin	OP03-21-3	buzzer drive signal
Buzzer signal (AC)	EXT-BUZ (AC)	J452	NH, 2 pin	Speaker w/amp	speaker signal
Monitor signal		J449	NH, 10 pin		VER synchronous, HOR synchronous, video (NTSC)
RJ-8	RJ-8	J456	NH, 4 pin		
PM-30	PM-30	J105	VH, 2pin		
Input/Output Signal					
INS data	INS. DATA	J455	NH, 5 pin		
RJ-7	RJ-7	J457	NH, 15 pin		
		J458	NH, 8 pin		
Nav data	N AV DATA	J450	NH, 8 pin		
ARPA data	ARPA DATA	J454	NH, 5 pin		




Fig. 2-18 Location of connectors on the INT Board

Grounding cables





Fig. 2-19 Cable clamp

Covering unused cable slots in the cable clamp



3. INITIALIZATION AND ADJUSTMENT

3.1 Preparation for Initialization and Adjustment

Accessing the menus

The menus for initialization and adjustment of this radar are locked to prevent adjustment by the user. To access them;

- 1) Turn off the power.
- 2) Turn on the #4 segment of DIP Switch S1 on the SPU Board.




Figure 3-1 Display unit (top view, cover removed) and SPU Board

Menu operation

- 1) Press the [RADAR MENU] key.
- 2) Press appropriate numeric key to select menu desired.
- 3) Press numeric key to select item.
- 4) Press same numeric key pressed in step 3 to select option.
- 5) Press [ENTER] to register selection.

Menu description and menu tree

See pages 3-9 and 3-11, respectively.

Restoring default settings

- 1) Press [RADAR MENU] [0] [0] [2] [0] [0] [0] [0] to select FACTORY DEFAULT on the INITIAL SETTING 4 menu.
- 2) Press the [ENTER] key.
- 3) Wait for 10 seconds.
- 4) Turn power off, and on again.
- 5) Press [RADAR MENU] [0] [0] [2] [0] [0] [0] [2] to select MODEL on the INITIAL SETTING 4 menu.
- 6) Press the [2] key to select OTHER X-BAND.
- 7) Press the [ENTER] key.

3.2 Heading Alignment

Antenna unit mounted error (heading reed switch timing error) can be compensated at the display unit.




Fig. 3-2 Heading alignment error

Procedure

- 1) Turn on the power. Press [RADAR MENU] [0] [0] [2] [2] to select HD ALIGN on the INITIAL SETTING 1 menu.
- 2) Select a target echo (by gyrocompass, for example) at a range between 0.125 and 0.25nm, preferably near the heading mark.
- 3) Operate the EBL control to bisect the target echo with the EBL. (The value shown on the display is antenna position in relation to ship's bow.)
- 4) Press [ENTER] to finish.

3.3 Adjusting Sweep Timing

Sweep timing differs with respect to the length of the signal cable between the antenna unit and the display unit. Adjust sweep timing at installation to prevent the following symptoms:

- The echo of a "straight" target (for example, pier), on the 0.25nm range, will appear on the display as being pulled inward or pushed outward. See Figure 3-3.
- The range of target echoes will also be incorrectly shown.




Fig. 3-3 Examples of correct and incorrect sweep timings

Procedure

- 1) Turn on the power. Press [RADAR MENU] [0] [0] [2] [3] to select TIMING ADJ on the INITIAL SETTING 1 menu.
- 2) Transmit on the 0.25nm range.
- 3) Adjust radar picture controls to display picture properly.
- 4) Select a target echo which should be displayed straightly.
- 5) Adjust the VRM control to straighten the target echo.
- 6) Press the [ENTER] key.

3.4 Adjusting Video Signal Level

When the signal cable is very long, the video amplifier input level decreases, shrinking target echoes. To prevent this, confirm (and adjust if necessary) video amplifier input level.

Procedure

- 1) Connect an oscilloscope to TP3 on the INT Board (INT-9170). Take trigger at TP10 on the same board.
- 2) Transmit on the 12nm range.
- 3) Adjust VR1 on the INT Board so the value of TP3 is 4Vpp. (For slave display, adjust VR2 on the INT Board so the value of TP3 is 4Vpp.)




Fig. 3-4 Location of INT Board

3.5 Suppressing Main Bang

If main bang appears at the screen center, suppress it as follows.

Procedure

- 1) Turn on the power. Transmit on a long range and then wait ten minutes.
- 2) Adjust [GAIN] control to show a slight amount of noise on the display.
- 3) Select the 0.25nm range. Adjust the [A/C SEA] control to suppress sea clutter.
- 4) Open the tuning compartment on the control unit.
- 5) Set VR901(MBS-L) at two o'clock and then slowly turn VR902 (MBS-T) clockwise to suppress main bang.
- 6) If main bang still exists, turn VR901 clockwise slightly, and then slowly turn VR902 clockwise. **Note that excessive main bang erases targets in close range.**




Fig. 3-5 Control unit, location of tuning compartment

3.6 Confirming Tuning

The radar receiver can be tuned both automatically and manually. Confirm that the radar can be tuned both automatically and manually.

Procedure

- 1) Turn on the power. Set the TUNE switch in the top right hand panel to MANU.
- 2) Transmit on the 48nm range.
- 3) Adjust sensitivity and picture brilliance. Turn the [A/C SEA] and [A/C RAIN] controls fully counterclockwise (off).

- 4) While observing the picture, turn the [TUNE] control in the tuning compartment slowly counterclockwise (clockwise) more than twice to get best (worst) tuning point.
- 5) Turn the [TUNE] control slowly clockwise (counterclockwise) to display the longest tuning bar.
- 6) Set the TUNE switch to AUTO and wait about 10 seconds (about four rotations of the antenna).
- 7) Confirm that the radar found best tuning point. Peak tuning is obtained when about 80% of the tuning indicator lights.

3.7 Adjustment

Magnetron heater voltage

Magnetron heater voltage is adjusted at the factory. However, confirm that it is within the prescribed rating.

Procedure

1. Press [RADAR MENU] [0] [0] [2] [0] [5] to set "SCANNER STOPPED" to "TX".
2. Set the radar to stand-by, 0.25nm range, CRT brilliance control fully ccw, and the ANTENNA switch to OFF position.
3. Remove the fuse F801(5 A) on the power supply unit.
4. Connect a multimeter, set to 10 VDC range, between #1(+) and #2(-) of J829.
5. Adjust the position of the sliding contact of R812 for a multimeter reading between 7.0 and 7.5V.
6. Transmit the radar on the 48 nm range.
7. Adjust R811 for a multimeter reading between 4.5 and 5.0V.

NOTE: If the length of multicore cable (MPYCY-16) between the scanner unit and power supply unit exceeds 60m, the magnetron heater voltage may not reach the lower limit due to voltage drop. In that case, increase the voltage by R813 (variable resistor in the power supply unit, coarse adjustment) and readjust the R811/R813 in the scanner unit.




Photo N2914

Fig. 3-6 Scanner unit




Photo N 2880

Fig. 3-7 Power supply unit

3.8 Initial Setting Menus

The INITIAL SETTING menus (four menus) setup the radar according to expected usage, authorities specification, ship's characteristics, operator's preference, etc. Set items on each menu accordingly.

INITIAL SETTING 1 menu

HD ALIGN: Compensates for heading error in bow direction.

TIMING ADJ: Adjusts sweep timing, which varies according to signal cable length.

ANT HEIGHT: Enter height of antenna above water.

LOG PULSE: Enter speed log's pulse rate.

OWN SHIP INFORMATION: Enter ship's characteristics; length, width, radar position, nav antenna position, turn rate, and speed rate. Those data will be used for the anchor watch alarm, docking, etc.

ON TIME, TX TIME: Shows number of hours the radar has been turned on and transmitted, respectively. Value can be changed to monitor magnetron usage, etc.

INITIAL SETTING 2 menu

KEY BEEP: Turns key response beep on or off.

SCANNER STOPPED: Set to ST-BY in normal use. TX enables transmission state without antenna rotation.

VIDEO SIGNAL: Set to ANLG (analog) for normal use. Set for DGTL to adjust QV (Quantized Video).

ALARM LEVEL: Sets echo strength which triggers guard alarm. "7" is strongest echo; "4" is medium strength echo.

DISPLAY: Select radar display function; main or sub (slave).

SECTOR BLKG: Sets area (up to 2) where no radar pulses will be transmitted. For example, set the area where an interfering object at the rear of the antenna would produce a dead sector (area where no echoes appear) on the display. To enter an area, select ON and enter relative bearing range of the area.

INITIAL SETTING 3 menu

TRAIL RESTART: Selects whether to restart or discontinue echo trailing when changing the range. ON restarts trailing on newly selected range; OFF discontinues trailing.

ECHO AVG W/O GYRO: Echo averaging can be turned on without gyrocompass connection.

GYRO SCALE: Bearing scale may be shown in degrees or compass points.

CTR ECHO STRETCH: Turn on to enlarge echoes in the range up to the first range ring.

VIDEO CONTRAST: For factory use. Do not change setting.

MAXIMUM RANGE: For factory use. Do not change setting.

ECHO FULL COLOR: Echoes may be displayed in single or multi-color.

INDEX LINES: Selects the number of index lines to display; 2 or 6.

INITIAL SETTING 4 menu

MODEL: Select radar model. Pulsewidth, pulse repetition rate and STC curve change according to selection.

RJ-5, RJ-7 and RJ-8: Selects which Interswitch unit to use.

ANT A: Select model of antenna A.

ANT B: Select model of antenna B.

CABLE L: Set for "500."

FACTORY DEFAULT: Restores all menus' default settings.

After entering initial settings

Turn off the #4 segment of DIP Switch S1 on the SPU Board to disable the menus for initialization and adjustment.

3.9 Setting the Function Keys

This radar has four function keys which automatically set up the radar according to the conditions ascribed to them. Confer with ship owner and radar operator to determine suitable program for each key.

Assign task to each function key;

Function key #1: picture setup

Function key #2 and #3: picture setup or specific operation

Function keys #4: specific or watch function

The table below and menu on the next page show the programs available.

Table 3-2 Operation setup conditions

Picture setup	Function
RIVER	River navigation
BUOY	Detecting navigation buoys, small vessels and other small surface objects
SHIP	Detecting vessels
SHORT	Short range detection using a range of 3 nm or less on calm seas.
LONG	Long range detection using a range of 6 nm or larger
CRUISING	Cruising using a range of 1.5 nm or larger
HARBOR	Short range navigation in a harbor using range of 1.5 nm or less
COAST	Coastal navigation using range of 12 nm or less
OCEAN	Transoceanic voyage using range of 12 nm or larger
ROUGH SEA	Optimum setting for rough weather or heavy rain

[FUNCTION KEY 1]		
1	[SYSTEM SETTING 1]	
2	FUNCTION	FUNC1/RIVER/BUOY/ SHIP/SHORT/LONG/ CRUISING/HARBOR/ COAST/OCEAN/ ROUGH SEA/ (FLOAT/BIRD) *1
3	INT REJECT	OFF/1/2/3
4	ECHO STRETCH	OFF/1/2
5	ECHO AVERAGE	OFF/1/2/3
6	A/C AUTO	OFF/ON
7	[FUNC1 PULSE WD]	(see menu below)
8	NOISE REJ	OFF/ON

[FUNCTION KEY 2] *2		
1	[SYSTEM SETTING 1]	
2	FUNC KEY2	PICTURE/OPERATION HU/HU TB/CU/NU/ TM/TRAIL/CU, TM RESET/OFF CENTER/ ECHO STRETCH1/ ECHO STRETCH2/ PLS WD1/PLS WD2/ ECHO AVG1/ECHO AVG2/ ECHO AVG3/ECHO COLOR/TRAIL BRILL/ PANEL BRILL/CHAR BRILL/NOISE REJ TARGETDATA/ CANCEL/
3	OPERATION	

[FUNC1 PULSE WD] *3		
1	[FUNCTION KEY 1]	
2	0.5 NM	S1/S2
3	0.75 NM	S1/S2
4	1.5 NM	S1/S2/M1
5	3 NM	S2/M1/M2
6	6 NM	M1/M2/L
7	12-24 NM	M2/L

[FUNCTION KEY 4]		
1	[SYSTEM SETTING 1]	
2	FUNC KEY4	OPERATION/WATCH ALARM
3	WATCH ALARM INTERVAL	6/10/12/15/20 MIN

Notes

*1: Available on "R" specification radar.

*2: Same menu appears for function key #3.

*3: Same menu appears for function keys #1, #2 & #3.

Shaded items are set at the factory; do not change their settings. See note on next page.

Fig. 3-8 Function key menus

Procedure for setting function keys

Function key #1

- 1) Press [RADAR MENU].
- 2) Press [0].
- 3) Press [3] to select FUNCTION KEY 1.
- 4) Press [2] to select picture setup condition desired.
- 5) Press [8]. (See the note on the next page.)

Function key #2 & #3

- 1) Press [RADAR MENU].
- 2) Press [0].
- 3) Press [4] to select FUNCTION KEY 2.

- 4) Press [2] to select PICTURE or OPERATION.
- 5) Press [3] to select picture setup condition (or specific operation) desired.
- 6) Press [9]. (See the note below.)

Function key #4

- 1) Press [RADAR MENU].
- 2) Press [0].
- 3) Press [5] (FUNCTION KEY 3) or [6] (FUNCTION KEY 4).
- 4) Press [2] to select OPERATION or WATCH ALARM.
- 5) Press [3] to select picture setup condition (or watch alarm interval).
- 6) Press [9]. (See the note which follows.)

Note: Each picture setup condition is programmed with optimal settings for interference rejection, echo stretch, echo averaging, automatic clutter removal, pulsewidth, and noise rejection. Therefore, the settings for those items on the function key menus should not be changed; any adjustment may adversely affect the target detection ability of the radar. If change is absolutely necessary, consult with nearest FURUNO representative or dealer.


Attach label to function keys

After setting the function keys, attach appropriate label (supplied) to them.

3.10 Menus for Initialization and Adjustment

NOTES:

- 1) Default settings shown in boldface.
- 2) Enabling initial setting menus: Turn on DIP switch S1 #4 on the SPU Board.
- 3) Disabling initial setting menus: Turn off DIP switch S1 #4 on the SPU Board.
- 4) Restoring default settings: Select "FACTORY SETTING" on INITIAL SETTING 4 menu.




3.11 Adjusting the ARP Board

Procedure


- 1) Take out the SPU Board SPU-9111 from the pcb compartment in the display unit.
- 2) Turn on #4 of DIP Switch S1.
- 3) Set the SPU Board in pcb compartment.
- 4) Set the radar as follows and transmit on 6nm range.

A/C SEA control: fully CCW
A/C RAIN control: fully CCW
GAIN control: fully CCW

From the rear, SPU, ARP
and RP(option) Boards.



- 5) Connect a digital multimeter, set to DCV range, to the following points on the ARP Board.
 - +: TP7 (VS+)
 - : TP6 (VS -)
- 6) Adjust potentiometer R104 ("OFFSET") on the ARP Board so that the multimeter reads +0.09 to 0.13V.




7) Set the controls and switches as follow.

A/C SEA control: fully CCW (same as step 4)
A/C RAIN control: fully CCW (same as step 4)
GAIN control: fully CW
INT REJECT key: OFF
RANGE: 24 nm
Echo Stretch (in menu): OFF

8) Press the RADAR MENU key followed by 0, 0, 2, 0 and 6 to select "DGTL".

9) Press the ENTER key.

10) Adjust potentiometer R103 ("LEVEL") on the ARP Board so that random noise faintly appears.




11) Repeat step 6 to select "ANLG", and press the ENTER key.

12) Turn off #4 of DIP switch S1.

Confirming proper operation

Connect speed log and gyro to radar. Transmit the radar. Confirm that all red LEDs (CR9, 10, 11, 12, 15 and 16) are off, provided that the ship's speed is not zero. If any signal is not applied, the corresponding LED lights.



3.12 Installation Check List

Tick box to indicate completion.

- ☐ Hoist rings removed?
- ☐ Rubber mat placed between antenna unit and mounting platform?
- ☐ Waterproofing gasket on antenna unit oriented correctly?
- ☐ Heading aligned?
- ☐ Sweep timing adjusted?
- ☐ Main bang suppressed?
- ☐ Tuning checked?
- ☐ Magnetron heater voltage checked?
- ☐ Antenna height entered?
- ☐ Log pulse selected?
- ☐ GYRO CONVERTER Board set up?
- ☐ DIP Switch S1 #4 turned off?
- ☐ Function keys set and function key labels attached?
- ☐ Unused cable slots in cable clamp covered with aluminum tape?

4. INSTALLATION OF GYRO CONVERTER GC-8 (option)

The Gyro Converter GC-8 converts analog gyrocompass reading into digital coded bearing data for display on the radar display.

This section explains how to install the GC-8 (mainly consisting of the GYRO CONVERTER Board) and set it up according to the type of gyrocompass connected.

4.1 General Procedure for Installing and Setting up the GYRO CONVERTER Board

- 1) Turn off the power.
- 2) Remove the top cover.




Fig. 4-1 Display unit, top view

Table 4-1 Contents of GC-8 installation kit

Name	Type	Code No.	Qty
GYRO CON- VERTER Board	64P1106	004-412-200	1
Spacer	SQ-10	000-801-678	4
Washerhead Screw	M3 x 8	008-456-404	4
PH-XH Connector	03-1761 (14P-6P)	008-456-130	1
NH-XH Connector	03-1762 (5P-5P)	008-456-140	1
Label	64-014-2021-1	100-132-701	1
VH Connector Assy.	03-1763 (5P)	008-456-150	1
VH Connector Assy.	03-1764 (3P)	008-456-160	1
Spare Fuses	FGMB 2A 250V	000-122-000	4

- 3) Connect the GYRO CONVERTER Board to the MOTHER Board (cables supplied with GC-8) as follows:

<u>GYRO CONV. Board</u>		<u>MOTHER Board</u>
J1 (14P)	←————→	J301 (6P)
J7 (5P)	←————→	J307 (4P)

- 4) Confirm gyrocompass specifications and set up the DIP switches and jumper wires on the GYRO CONVERTER Board according to gyrocompass connected;
 - Confirming gyrocompass specifications: see next page
 - Setting jumper wires and DIP switches by gyrocompass specifications: page 4-4
 - Setting jumper wires and DIP switches by make and model of gyrocompass: page 4-6
 - Location of jumper wires and DIP switches: page 4-7
- 5) Solder the gyrocompass cable to the VH connector assemblies (supplied).
- 6) Connect the VH connectors to the GYRO CONVERTER Board as shown in the table below.

Connector		Gyrocompass	
		Step type	Synchro type
J4	#1	S1	S1
	#2	S2	S2
	#3	S3	S3
	#4		
	#5	F. G.	F. G.
J5	#1	—	R2
	#2	COM	R1
	#3	F. G.	F. G.

- 7) Attach instruction label (supplied) to the rear side of the top cover.
- 8) Close the panel.
- 9) Turn on and off the power to reset the CPU.

4.2 Connection of External Power Supply

Connect an external power supply when the repeater signal is step-by-step type and the step voltage is below 20V or output voltage is less than 5W.




Fig. 4-2 Connection of external power supply to GYRO GYRO CONVERTER Board

4.3 Confirming Gyrocompass Specifications

Follow the flow chart in the figure below to confirm gyrocompass specifications.




Fig. 4-3 Confirming gyrocompass specifications

4.4 Changing Settings on the GYRO CONVERTER Board

Default setting

In the default setting all DIP switches are off and all jumpers wires are set to "#1." (Note that jumper wire JP1's setting is #1, #2, and #3.) In those settings the gyrocompass having the following specifications can be directly connected; modification of the GYRO CONVERTER Board is not necessary.

AC synchronous signal: 50/60Hz

Rotor voltage: 60V to 135V AC

Stator voltage: 60V to 135V AC

Gear ratio: 360x

Supply voltage: 30V to 135V AC

If the specifications of the gyrocompass differ from those mentioned above, change jumper wire and DIP switches settings on the GYRO CONVERTER Board. Settings may be changed according to gyrocompass specifications or make and model of gyrocompass (see page 4-6). For the location of DIP switches and jumper wires, see page 4-7.

Setting method 1: by gyrocompass specifications

1) Gyrocompass type

Gyrocompass type	SW 1-4	SW 1-5	SW 1-6	JP1
AC synchronous	OFF	OFF	OFF	#1, #2, #3
DC synchronous	OFF	OFF	OFF	#2, #3, #4
DC step	ON	OFF	OFF	#4, #5, #6
Full-wave pulsating current	OFF	ON	OFF	#4, #5, #6
Half-wave pulsating current	ON	ON	OFF	#4, #5, #6

2) Frequency

Frequency	SW 1-7	SW 1-8	Remarks
50/60Hz	OFF	OFF	AC synchronous pulsating current
400Hz	ON	OFF	AC synchronous pulsating current
500Hz	OFF	ON	AC synchronous pulsating current
DC	ON	ON	DC synchronous DC step

3) Rotor voltage (between R1 & R2)

Rotor voltage	SW 2-1	JP3
20V to 45V AC	OFF	#2
30V to 70V AC	OFF	#2
40V to 90V AC	ON	#1
60V to 135V AC	OFF	#1

4) Stator voltage (between S1 and S2)

Stator voltage	SW 2-2	SW 2-3	JP3
20V to 45V AC, or 20V to 60V DC	ON	OFF	#2
20V to 45V AC, or 20V to 60V DC	OFF	OFF	#2
40V to 90V AC	ON	OFF	#1
60V to 135V AC	OFF	OFF	#1

5) Ratio

Ratio	SW1-1	SW 1-2	SW1-3
360x	OFF	OFF	OFF
180x	ON	OFF	OFF
90X	OFF	ON	OFF
36X	OFF	ON	OFF

6) Supply voltage

Supply voltage	JP4	JP5
20V to 45V AC, or 20V to 60V DC	#2	#2
30V to 135V AC, or 40V to 100V DC	#1	#1

**7) AD-10 format data
Tx interval**

Select data transmitting interval for ports 1 to 6 by jumper wires JP6 and JP7.

Note: The Tx interval is available in 25 msec or 200 msec. 25 msec is for radar; 200 msec is for all other equipment.

**8) NMEA-0183
Tx interval**

Tx interval	SW2-4
2 seconds	ON
1 second	OFF

Setting method 2: by make and model of gyrocompass

Table 4-2 Setting GYRO CONVERTER Board by make and model of gyrocompass

Maker	Models	Specification	SW 1-1	SW 1-2	SW 1-3	SW 1-4	SW 1-5	SW 1-6	SW 1-7	SW 1-8	SW 2-1	SW 2-2	SW 2-3	JP1	JP2	JP3	JP4	JP5
FURUNO	GY-700	DC step 100V 180x 5-wire, open collector	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
Anschutz	Standard 2,3	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 22V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	#1, #2,#3	#2	#2	#1	#1
	Standard 4,6	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 90V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#2	#1	#1	#1
	Standard 20	DC step 35V 180x COM(-), 3-wire(+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
Yokogawa Navtec (Plaith type)	C-1/1A/2/3 A-55, B-55	AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 22V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	#1, #2,#3	#2	#2	#1	#1
	CMZ-250X/ 300X/500	DC synchronous 360x	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON	-	ON	OFF	Remo- ve	#2	-	*	*
		DC step 35V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
	CMZ-100/200/ 300 C-1Jr,D-12/1/3 IPS-2/3	AC synchronous 50/60Hz Rotor voltage: 100V Stator voltage: 90V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
Plaith	NAV GAT II/III	step 35V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	Remo- ve	#2	-	*	*
		AC synchronous 50/60Hz Rotor voltage: 50/60V Stator voltage: 68V 360x	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#2	#2	#1	#1
Tokimec (Sperry type)	ES-1/2/11 GLT-101/102/ 103/106K/107	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 90V 36x	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	ES-11A/110 TG-200 PR222R/2000 PR237L/H GM 21	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 22V 90x	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	MK-14 MOD-1/2/T NK-EN,NK-EI	DC step 70V 180x COM(-), 3-wire(+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	SR-130/140	DC step 70V 180x 5-wire, open collector	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	TG-100/5000 PR-357/130/ 140, ES-17 GLT-201/202 /203	DC step 70V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
	TG-6000	DC step 24V 180x	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
	GM-11	AC synchronous 50/60Hz Rotor voltage: 100V Stator voltage: 90V 90x	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
	SR-120,ES-16 MK-10/20/30	DC step 35V 180x	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2
Kawasaki	GX-81	AC synchronous 50/60Hz Rotor voltage: 100/110V Stator voltage: 90V 90x	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	#1, #2,#3	#1	#1	#1	#1
Armabrown	MK-10,MKL-1 SERIES1351, MOD-4	DC step 50V 180x COM(+), 3-wire(-)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	OFF	OFF	#4, #5,#6	#2	-	#1	#1
Robertson	SKR-80	DC step 35V 180x COM(-), 3-wire(+)	ON	OFF	OFF	ON	OFF	OFF	ON	ON	-	ON	OFF	#4, #5,#6	#2	-	#2	#2

After changing settings

Turn on and off the power to reset the CPU.




Fig. 4-4 Location of DIP switches and jumper wires on the GYRO CONVERTER Board

4.5 Setting the Bearing on the Radar Display

Confirm that the gyrocompass is giving reliable readings. Then, set bearing on the radar display as shown in the procedure below.

- 1) Open the tuning compartment on the control panel. Press the HOLD switch to disengage the computing circuit from the gyrocompass. The "HOLD" LED lights.
- 2) Press [+] or [-] switch to duplicate the gyrocompass reading at the top of the radar display. (Each press of those switches changes the readout by 0.1 degrees. A switch may be pressed and held down more than two seconds to change the readout by one degree.)
- 3) Press the HOLD switch when the gyrocompass reading on the radar matches the gyrocompass reading. The "HOLD" LED goes off.

Note: In some cases, the gyrocompass rotation may be the opposite of the displayed bearing, in spite of correct connections. In this case try exchanging two connections among S1, S2 and S3 on the GYRO SWITCH Board.

FURUNO

CODE NO.		03EU-X-9412
TYPE		



工事材料表 INSTALLATION MATERIALS		FR-2855 FAR-2855		レーダー RADAR		
番号 No.	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS		数量 Q'TY	用途 / 備考 REMARKS
1	信号ケーブル組品 SIGNAL CABLE ASSY.	 L=15m	S03-58-15 RW-6895-0	*15M*	1	選択 TO BE SELECTED
			CODE NO.	008-461-710		
2	信号ケーブル組品 SIGNAL CABLE ASSY.	 L=20m	S03-58-20 RW-6895-0	*20M*	1	
			CODE NO.	008-461-720		
3	信号ケーブル組品 SIGNAL CABLE ASSY.	 L=30m	S03-58-30 RW-6895-0	*30M*	1	選択 TO BE SELECTED
			CODE NO.	008-461-730		
4	信号ケーブル組品 SIGNAL CABLE ASSY.	 L=60m	S03-58-60 RW-6895-0	*60M*	1	
			CODE NO.	008-461-740		
			CODE NO.			
			CODE NO.			
			CODE NO.			
			CODE NO.			
			CODE NO.			
			CODE NO.			










図 番

(1/1)

DWG. NO. C3419-M01-A

FURUNO

CODE NO.	008-461-760	03EU-X-9403 -2 1/2
TYPE	CP03-14602	




工事材料表 INSTALLATION MATERIALS		FR/FAR-2815/2825 2835S/2855/2855W FA-2805		船用レーダー MARINE RADAR	
番号 NO.	名称 NAME	略図 OUTLINE	型名/規格 DESCRIPTIONS	数量 Q'TY	用途/備考 REMARKS
1	スチューブ F(Z) HEAT-SHRINK TUBE		3X0.25 加 *0.10M*	2	外部機器接続用 FOR EXTERNAL EQUIPMENT
2	NHコネクタ センサイタ NH CONNECTOR ASSY.		AWG24 ±0.1M*	20	外部機器接続用 FOR EXTERNAL EQUIPMENT
3	NHコネクタハウジング NH CONNECTOR HOUSING		H2P-SHF-AA	1	警報音信号 (AC) EXT-BUZZER (AC)
4	NHコネクタハウジング NH CONNECTOR HOUSING		H3P-SHF-AA	2	ジャイロ信号用 GYRO DATA ログ信号用 SPEED LOG
5	NHコネクタハウジング NH CONNECTOR HOUSING		H4P-SHF-AA	3	RJ-8 用 レータファイ用 潮流計信号用
6	NHコネクタハウジング NH CONNECTOR HOUSING		H5P-SHF-AA	2	ジャイロ信号用 GYRO DATA ログ信号用 INST-データ用 INS DATA
7	NHコネクタハウジング NH CONNECTOR HOUSING		H7P-SHF-AA	1	舵角信号用 FOR PORT RUDDER
8	特殊ラグ LUG		7x4x14 スズ	2	
9	圧着端子 CRIMP-ON LUG		FV5.5-4	2	
10	ワッシャーヘッドネジ B WASHER HEAD SCREW		M3X8 C2700 MBN1/2	2	

C3418-M03-D

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO

		CODE NO.	008-461-760	03EU-X-9403 -2	
		TYPE	CP03-14602	2/2	
工事材料表 INSTALLATION MATERIALS		FR/FAR-2815/2825 2835S/2855/2855W FA-2805		船用レーダー MARINE RADAR	
番号 NO.	名称 NAME	略図 OUTLINE	型名/規格 DESCRIPTIONS	数量 Q'TY	用途/備考 REMARKS
11	VHコネクタ組品 NH CONNECTOR ASSY.		03-1737(5P) CODE NO. 008-454-380	1	ジヤイロコンバータ FOR GYRO CONVERTER
12	VHコネクタ組品 NH CONNECTOR ASSY.		03-1738(3P) CODE NO. 008-454-390	1	ジヤイロコンバータ FOR GYRO CONVERTER
13	VHコネクタ組品 NH CONNECTOR ASSY.		03-1778(2P) CODE NO. 008-460-050	1	パフォーマンスモニター PM-30/50用 FOR PERFORMANCE MONITOR









C3418-M04-C

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO

CODE NO.	008-461-750	03EU-X-9406 -5 1/2
TYPE	CP03-14601	

工事材料表 INSTALLATION MATERIALS		FR/FAR-2855/2150 FR-2160DS/2155 FR-2165DS		レーダー RADAR			
番号 NO.	名称 NAME	略図 OUTLINE	型名/規格 DESCRIPTIONS		数量 Q'TY	用途/備考 REMARKS	
1	防蝕ゴム CORROSION-PROOF RUBBER MAT		03-029-0301-2		2		
			CODE NO.	100-091-112			
2	六角ボルト HEX. BOLT		M6X25 SUS304		1		
			CODE NO.	000-862-180			
3	シールワッシャー SEAL WASHER		03-001-3002-0		4		
			CODE NO.	300-130-020			
4	ハネ座金 SPRING WASHER		M6 SUS304		1		
			CODE NO.	000-864-260			
5	六角ナット 1種 HEX. NUT		M6 SUS304		1		
			CODE NO.	000-863-109			
6	アース線 GROUNDING WIRE		RW-4747-1 03S4747		1		
			CODE NO.	000-566-000			
7	圧着端子 CRIMP-ON LUG		FV5. 5-4		2		
			CODE NO.	000-538-123			
8	圧着端子 CRIMP-ON LUG		FV1. 25-4		18		
			CODE NO.	000-538-114			
9	圧着端子 CRIMP-ON LUG		FV1. 25-M3 7ヶ		26		
			CODE NO.	000-538-110			
10	六角ナット 1種 HEX. NUT		M12 SUS304		4		
			CODE NO.	000-863-112			




DWG NO. C3407-M01- C

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO

CODE NO.	008-461-750	03EU-X-9406 -5 2/2
TYPE	CP03-14601	

工事材料表 INSTALLATION MATERIALS		FR/FAR-2855/2150 FR-2160DS/2155 FR-2165DS	レーダー RADAR		
番号 NO.	名称 NAME	略図 OUTLINE	型名/規格 DESCRIPTIONS	数量 Q'TY	用途/備考 REMARKS
11	六角ボルト (全長) HEX. BOLT		M12X60 SUS304	4	
			CODE NO. 000-862-191		
12	ハネ座金 SPRING WASHER		M12 SUS304	4	
			CODE NO. 000-864-263		
13	ミカキ平座金 FLAT WASHER		M12 SUS304	4	
			CODE NO. 000-864-132		
14	圧着端子 CRIMP-ON LUG		FVD1. 25-3	1	
			CODE NO. 000-116-634		
15	ミカキ平座金 FLAT WASHER		M6 SUS304	3	
			CODE NO. 000-864-129		

DWG NO.

C3407-M02- C

FURUNO ELECTRIC CO., LTD




(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO

FURUNO

CODE NO.	008-452-790	03EP-X-9409 -3 1/1
TYPE	CP03-13916	

工事材料表 INSTALLATION MATERIALS	FR-2155/2155-B FR-2155DS FR/FAR-2855	船舶用レーダー MARINE RADAR
--	--	-----------------------------

番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q' TY	用途／備考 REMARKS
1	圧着端子 CRIMP-ON LUG		FV1.25-M3 7本	9	
			CODE NO. 000-538-110		
2	圧着端子 CRIMP-ON LUG		FV2-4A 7本	11	
			CODE NO. 000-538-118		
3	圧着端子 CRIMP-ON LUG		FV5.5-4	5	
			CODE NO. 000-538-123		

DWG NO.





C3390-M03- D

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO

CODE NO.	008-452-540	03EP-X-9405 -4 1/1
TYPE	CP03-13907	

工事材料表 INSTALLATION MATERIALS		FR/FAR-2125W FR-2135S/-B FR-2135SW/-MSA FR-2155/-B/2165DS FR/FAR-2825W FR/FAR-2835S/SW FR/FAR-2855/W FR/FAR-2865SW	船舶用レーダー MARINE RADAR		
番号 NO.	名称 NAME	略図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	特殊ラグ LUG		7ヶ14 ス CODE NO. 000-536-100	2	
2	圧着端子 CRIMP-ON LUG		FV1.25-M3 7ヶ CODE NO. 000-538-110	16	
3	圧着端子 CRIMP-ON LUG		FV1.25-4 CODE NO. 000-538-114	11	
4	圧着端子 CRIMP-ON LUG		FV5.5-4 CODE NO. 000-538-123	19	

DWG NO.







C3387-M01- E

FURUNO ELECTRIC CO., LTD

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)


FURUNO

CODE NO.	008-459-790	03EU-X-9502-4
TYPE	FP03-05701	

付 属 品 表 ACCESSORIES		FR/FAR-2815/2825/2835S /2855/2855W 船用レーダー /2865SW/2825W/2835SW MARINE RADAR FA-2805			
番号 No.	名 称 N A M E	略 図 OUTLINE	型 名 / 規 格 DESCRIPTIONS	数量 Q'TY	用 途 / 備 考 REMARKS
1	キーマークシート(E) KEY LABEL(E)		03-133-1802-1 CODE NO. 100-233-420	1	
2	システム銘板 NO.1 NAME PLATE NO.1		03-009-0343-0 CODE NO. 300-903-430	2	
3	システム銘板 NO.2 NAME PLATE NO.2		03-009-0344-0 CODE NO. 300-903-440	2	
4	端子板カバー PANEL BOARD COVER		ZM-47A CODE NO. 000-532-491	2	
5	ホールプラグ HOLE PLUG		NO. 4567 CODE NO. 000-800-729	4	
6	RPフライントフィルム RP BRIND FILM		03-133-1636-0 CODE NO. 100-244-490	1	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
英文 / 操作パネル一体型 ENGLISH / PANEL FITTED					
(略図の寸法は、参考値です。)			図 番 (1/1) DWG. NO. C3418-F02-F		

FURUNO

CODE NO.	000-807-203	03EU-X-9504-2
TYPE	03-133-1811-0	





付 属 品 表 ACCESSORIES		FR/FAR-2815/2825/2835S /2855/2855W 船用レーダー /2865SW/2825W/2835SW MARINE RADAR FA-2805			
番号 No.	名 称 N A M E	略 図 O U T L I N E	型 名 / 規 格 D E S C R I P T I O N S	数 量 Q'TY	用 途 / 備 考 R E M A R K S
1	ダストカバー DUST COVER		03-133-1811 CODE NO. 000-807-203	1	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		

(略図の寸法は参考値です。)

図 番 (1/1)
DWG. NO. C3418-F04-E

FURUNO

CODE NO.	008-459-740	03EU-X-9301-3
TYPE	SP03-11301	BOX NO. P

SHIP NO.		SPARE PARTS LIST FOR		U S E			SETS PER VESSEL	
		FR/FAR-2815/2825/2835S/ FA-2805/2855/2855W/2865SW FR-2120W/2130W レーダー FR-2150W/2160SW RADAR						
ITEM NO.	NAME OF PART	O U T L I N E	DWG. NO. OR TYPE NO.	Q U A N T I T Y			REMARKS/CODE NO.	
				WORKING		SPARE		
				PER SET	PER VES.			
1	管入りヒューズ GLASS TUBE FUSE		FGB0 0.5A AC250V	3		6	TCT9106 F3 000-549-018	
2	管入りヒューズ GLASS TUBE FUSE		FGB0 5A AC250V	3		6	F1/F2/F3 (230V) 000-549-022	
3	管入りヒューズ GLASS TUBE FUSE		FGB0 10A AC125V	2		4	F1/F2(100V) 000-549-065	
4	ヒューズ FUSE		FGMB 2A AC250V	4		4	64P1106 000-122-000	
MFR'S NAME		FURUNO ELECTRIC CO., LTD		DWG NO		C3418-P01-C		1/1



FURUNO

CODE NO.	008-424-380	03DZ-X-9303 -6
TYPE	SP03-09203	BOX NO. P

[illegible]

FURUNO

CODE NO.	008-424-370	03DZ-X-9302 -8
TYPE	SP03-09202	BOX NO. P

SHIP NO.		SPARE PARTS LIST FOR		U S E			SETS PER VESSEL
		FR-1460DS/1760DS 船舶用レーダー FR-2155/2155-B FR-2165DS FR/FAR-2855 MARINE RADAR					
ITEM NO.	NAME OF PART	OUTLINE	DWG. NO. OR TYPE NO.	QUANTITY			REMARKS/CODE NO.
				WORKING		SPARE	
				PER SET	PER VES		
1	ヒューズ FUSE		FG80-A 2A AC125V	2		4	
							000-549-062
2	ヒューズ FUSE		FG80-A 5A AC125V	1		2	
							000-549-064
MFR'S NAME		FURUNO ELECTRIC CO.,LTD		DWG NO.		C3357-P02- J	
						1/1	

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

FURUNO

CODE NO.	008-452-700	03EP-X-9301 -3
TYPE	SP03-10320	BOX NO. P

[illegible]

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)



- 注 記 1) 装備ケーブルはサービス時、指示部を前方に十分引き出せるよう余裕を持たせること。
2) 取付用ネジはM10ボルト又は コーチボルト呼び径9を使用のこと。
3) #印寸法は最小サービス空間寸法とする。

- NOTE 1) SUFFICIENT EXTRA CABLINGS SHOULD BE ALLOWED AT THE BACK OF THE UNIT SO THAT THE UNIT CAN BE DRAWN OUT WITH THE CABLES CONNECTED FOR MAINTENANCE.
2) USE M10 BOLTS OR $\phi 9$ COACH SCREWS FOR FIXING THE UNIT.
3) #:RECOMMENDED SERVICING CLEARANCE.


範囲 DIMENSION	公差 TOL.
$L \leq 50$	$\pm 1 \text{ mm}$
$50 < L \leq 100$	$\pm 2 \text{ mm}$
$100 < L \leq 500$	$\pm 3 \text{ mm}$
$500 < L \leq 1000$	$\pm 4 \text{ mm}$
$1000 < L \leq 2000$	$\pm 5 \text{ mm}$
$2000 < L \leq 4000$	$\pm 7 \text{ mm}$
$4000 < L \leq 8000$	$\pm 10 \text{ mm}$
$8000 < L$	$\pm 15 \text{ mm}$

表 1
TABLE 1



銘板
NAME PLATE



取付寸法図(矢視 A)
MOUNTING DIMENSION (VIEWING A)



矢視 B
VIEWING B



DRAWN Det. 7/92 T. YAMASAKI		TITLE RDP-115
CHECKED Det. 7/92 K. KUSUNOKI		名 稱 指示器 (卓上型)
APPROVED Det. 7/92 K. KUSUNOKI	FR/FAR-2805 SER.	外寸図
SCALE 1/20	MASS 85 kg	NAME DIAPLAY UNIT (TABLETOP)
DWG. No. C3418-G02-C	03-133-1000-G2	OUTLINE DRAWING



- 注 記 1) 装備ケーブルはサービス時、指示部を前方に十分引き出せるよう余裕を持たせること。
2) 取付用ネジはM10ボルト又は コーチボルト呼び径9を使用のこと。
3) #印寸法は最小サービス空間寸法とする。

- NOTE 1) SUFFICIENT EXTRA CABLING SHOULD BE ALLOWED AT THE BACK OF THE UNIT SO THAT THE UNIT CAN BE DRAWN OUT WITH THE CABLES CONNECTED FOR MAINTENANCE.
2) USE M10 BOLTS OR $\phi 9$ COACH SCREWS FOR FIXING THE UNIT.
3) #:RECOMMENDED SERVICING CLEARANCE.

範囲 DIMENSION	公差 TOL.
$L \leq 50$	$\pm 1 \text{ mm}$
$50 < L \leq 100$	$\pm 2 \text{ mm}$
$100 < L \leq 500$	$\pm 3 \text{ mm}$
$500 < L \leq 1000$	$\pm 4 \text{ mm}$
$1000 < L \leq 2000$	$\pm 5 \text{ mm}$
$2000 < L \leq 4000$	$\pm 7 \text{ mm}$
$4000 < L \leq 8000$	$\pm 10 \text{ mm}$
$8000 < L$	$\pm 15 \text{ mm}$


表 1
TABLE 1

銘板
NAME PLATE





取付寸法図 (矢視 A)
MOUNTING DIMENSION (VIEWING A)


ルーバ
AIR VENT




矢視 B
VIEWING B



DRAWN Oct. 2 '97 T. YAMASAKI		TITLE RDP-115
CHECKED Oct 7 '97 K. Kusumoto		名 稱 指示器 (卓上・パネル分離型)
APPROVED Oct 7 '97 K. Kusumoto	FR/FAR-2805 SER.	外寸図
SCALE 1/20	MASS 82 kg	NAME DIAPLAY UNIT (TABLETOP W/O KEYBOARD)
DWG. No. C3418-G01- C	03-133-1100-G2	OUTLINE DRAWING



取付寸法図 (矢視 A)
FLAT MOUNTING DIMENSION (VIEWING A)



DRAWN July 6, 1995 Morimoto			TYPE RDP-115
CHECKED July 6, '95 T. Mahe	FR2805SER		名称 操作部外寸図
APPROVED July 6, '95 K. Okamoto	FAR2805SE		NAME CONTROL UNIT
SCALE 1/5	MASS 3 kg	APPLICABLE TO: (MODEL)	BLOCK NO.
			DWG NO. C3418-G04- A 03-133-1600- G0


- 注 記 1) 装備ケーブルはサービス時、指示部を前方に十分引き出せるよう余裕を持たせること。
2) 取付用ネジはM10ボルト又は コーチボルト呼び径9を使用のこと。
3) #印寸法は最小サービス空間寸法とする。

- NOTE 1) SUFFICIENT EXTRA CABLING SHOULD BE ALLOWED AT THE BACK OF THE UNIT SO THAT THE UNIT CAN BE DRAWN OUT WITH THE CABLES CONNECTED FOR MAINTENANCE.
2) USE M10 BOLTS OR $\phi 9$ COACH SCREWS FOR FIXING THE UNIT.
3) #:RECOMMENDED SERVICING CLEARANCE.


範囲 DIMENSION	公差 TOL.
$L \leq 50$	$\pm 1 \text{ mm}$
$50 < L \leq 100$	$\pm 2 \text{ mm}$
$100 < L \leq 500$	$\pm 3 \text{ mm}$
$500 < L \leq 1000$	$\pm 4 \text{ mm}$
$1000 < L \leq 2000$	$\pm 5 \text{ mm}$
$2000 < L \leq 4000$	$\pm 7 \text{ mm}$
$4000 < L \leq 8000$	$\pm 10 \text{ mm}$
$8000 < L$	$\pm 15 \text{ mm}$

表 1
TABLE 1


銘板
NAME PLATE



A




ケーブル押さえ金具上のネジより接地
GROUND THRU CABLE CLAMP SCREW




取付寸法図(矢視 A)

MOUNTING DIMENSION (VIEWING A)



DRAWN Oct. 2 '97 T. YAMASAKI		TITLE RDP-115
CHECKED Oct 7 '97 H. Kusunoki		名 称 指示器 (コンソール型)
APPROVED Oct 7 '97 H. Kusunoki	FR/FAR-2805 SER.	外寸図
SCALE 1/20	MASS 120 kg	NAME DIAPLAY UNIT (CONSOLE)
DWG. No. C3418-G03-G	03-133-1200-G1	OUTLINE DRAWING



取付寸法
MOUNTING DIMENSIONS

アンテナ型名 ANTENNA TYPE	XN3A	XN4A	XN5A
空中線長 (A) ANT LENGTH (mm)	2070	2570	3210
回転半径 (B) RADIUS (mm)	1100	1350	1670
総質量 TOTAL MASS (kg)	71.5	74	77


DRAWN Sep. 2 '98 T. YAMASAKI	FR-2855	TYPE RSB-0049/0050
CHECKED Sep. 2 '98 K. Kusunoki	FR-2150	名称 空中線部
APPROVED Sep. 2 '98 K. Kusunoki	FAR-2852	外寸図
SCALE 1/10	FR-2852	NAME SCANNER UNIT
MASS kg	FR-2050T	OUTLINE DRAWING
DWG NO. C3353-G02-D	APPLICABLE TO; (MODEL)	BLOCK NO.

A

B

C

D



注意:


1. 電蝕防止のため、組立時にボルト、ナット、ワッシャ及びフランジ面の
Oリング溝外側の部分に支給のシリコンシーラント(無酸性)を塗布する。
Oリング及びOリングの溝には塗布しないこと。
2. Oリングに傷をつけたり、ゴミを付着させないように注意のこと。
3. Oリング及びスキャナカバーのパッキンにはグリースを使用すること。
シリコンシーラントは使用不可。

NOTE:


1. APPLY SILICONE SEALANT (SUPPLIED, NON-ACID TYPE) ON
BOLTS, NUTS, WASHER AND WAVEGUIDE FLANGE OUTSIDE
O-RING GROOVE TO AVOID ELECTRICAL CORROSION. (DO NOT
APPLY SEALANT TO O-RINGS AND O-RING GROOVES.)
2. DO NOT PINCH O-RING AND KEEP IT CLEAN.
3. FOR PACKINGS OF SCANNER COVERS AND O-RINGS, DO NOT
USE SILICONE SEALANT, BUT RATHER USE GREASE.

No.	名称 NAME	型式 SPECIFICATION	数量 Q'TY
1	Oリング O-RING	ASS68-125	2
2	六角セムス(B) HEX. BOLT(B) (WASHER HEAD)	M4x16 (SUS304)	8
3	六角ボルト HEX. BOLT	M8x35 (SUS304)	4
4	バネ座金 SPRING WASHER	FOR M8用(SUS304)	4
5	平座金 FLAT WASHER	FOR M8用(SUS304)	4
6	六角ボルト HEX. BOLT	M8x30 (SUS304)	4
7	平座金 FLAT WASHER	FOR M8用(SUS304)	8
8	バネ座金 SPRING WASHER	FOR M8用(SUS304)	4
9	六角ナット HEX. NUT	M8 (SUS304)	4
10	六角ボルト HEX. BOLT	M4x30 (SUS304)	2
11	バネ座金 SPRING WASHER	FOR M4用(SUS304)	2
12	平座金 FLAT WASHER	FOR M4用(SUS304)	2
13	導波管押え W/G CLAMP	RSB-2006-1	1
14	導波管間座 W/G PACKING	03-003-4003-0	1

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	MAY. 25. '79	三角法 THIRD ANGLE PROJECTION	名称 TITLE	空中線部組立図 SCANNER UNIT ASSEMBLING (XN3A/XN4A)	
検 CHECKED	MAY. 25. '79	尺 SCALE			
製 DRAWN	25. 5. 79	重 WEIGHT	kg	図番 DWG. NO.	C3249-017-H



DRAWN Aug 28 '98 T. YAMASAKI			TYPE PSU-001/002
CHECKED Aug 28 '98 K. Kusunoki			名称 空中線電源部
APPROVED Aug 28 '98 K. Kusunoki			外寸図
SCALE 1 / 5	MASS 7 kg	APPLICABLE TO; (MODEL)	BLOCK NO.
DWG NO. C3353-G01- D			NAME POWER SUPPLY UNIT
			OUTLINE DRAWING



注記

- 1) 指定なき寸法公差は表 1 による。
- 2) #: 推奨する最小サービス空間寸法。
- 3) 取付ネジはトラスタッピンネジ呼び径 5 × 20 を使用のこと。


NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.
2. #: RECOMMENDED SERVICE CLEARANCE.
3. USE TAPPING SCREWS 5x20 FOR FIXING THE UNIT.



表 1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
0 < L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3


DRAWN June 27 '00 T. YAMASAKI	TITLE PSU-004
CHECKED June 27 '00 Y. K.	名称 電源制御部
APPROVED June 27 '00 Y. K.	外寸図
SCALE 1/4	NAME POWER SUPPLY UNIT
MASS 2.3 kg	
DWG. No. C3385-G02- D	OUTLINE DRAWING





取付穴
4-7φ FIXING HOLES



DRAWN June 18 '96 Y. EBISU		TITLE RU-1758/1803
CHECKED June 18 '96 K. Kusunoki		名称 トランスユニット
APPROVED June 18 '96 K. VTA		外 寸 図
SCALE 1/5 MASS 12 kg		NAME TRANSFORMER UNIT
DWG No C3003-001-D		



品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG.NO.	摘要 REMARKS
承認 APPROVED	58.7.15 池谷	三角法 THIRD ANGLE PROJECTION		名称 TITLE	RU-5466-1
検図 CHECKED	58.8.11 不矢	尺 SCALE	度 X	トランスユニット TRANSFORMER UNIT	RU-6764
製図 DRAWN		重量 WEIGHT	約 12 kg	図番 DWG.NO.	RU-5693
				C 3 0 0 3 - 0 0 6 - E	




RU-6347

AC110/115V
1φ
50/60Hz


AC100V
1φ
50/60Hz

入力側
INPUT



出力側
OUTPUT


RU-6522

AC220V
3φ
50Hz

AC200V
3φ
50Hz

FR-1222/1222X/1622/1622X
FR-1252X/1652X
FAR-1622X/1652X



品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG.NO.	摘要 REMARKS
承認 APPROVED	JUNE 2 '57 T. YAKANO	三角法 THIRD ANGLE PROJECTION	名称 TITLE	RU-6347 トランスユニット	
検図 CHECKED	JUNE 2 '57 Z. Amano	尺度 SCALE	RU-6522 TRANSFORMER UNIT		
製図 DRAWN		重量 WEIGHT	約12kg kg	図番 DWG.NO.	C3003-007-B





コンパス安全距離 COMPAS SAFE DISTANCE

スタンダード STANDARD	2.1 M
ステアリング STEERING	1.5 M

承認 APPROVED	品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG.NO.	摘要 REMARKS
検図 CHECKED	19. Aug. '83	三角法 THIRD ANGLE PROJECTION	名称 TITLE トランスユニット RU-3305 TRANSFORMER UNIT			
製図 DRAWN	19. Aug. '83 H.R.	尺度 SCALE	重量 WEIGHT	12.2 kg	図番 DWG.NO.	C3003-004-C



NOTE 1. $\times$: 推奨サービス空間
RECOMMENDED SERVICING CLEARANCE.



注 AC220V入力に対してはT1401の一次巻線を直列に接続する。

NOTE FOR 220VAC INPUT, CONNECT T1401 PRIMARY WINDINGS IN SERIES.

DRAWN	Apr. 11 '97 T. YAMASAKI			TYPE	RU-3423
CHECKED	Apr. 15 '97 K. KUSUNOKI			名称	整流器
APPROVED				外寸図	
SCALE	1/5	MASS	16.5 kg	APPLICABLE TO; (MODEL)	BLOCK NO.
DWG NO.	C3002-005- K			NAME	RECTIFIER UNIT
					OUTLINE DRAWING


A

B


C


- 注) 1. アンテナケーブル (RW-6895) のカラーコード
で () は内側シールド内の線を示す
2. シールドは両端で完全にアースすること
3. *印と※1~※5は造船所支給 (現地手配)


NOTE 1. WIRE COLOR CODE OF ANT CABLE (RW-6895)
() : INSIDE WIRE, B : LARGE WIRE,
L : LIGHT COLOR
2. SHIELD SHOULD BE EFFECTIVELY
GROUNDED AT BOTH ENDS.
3. *MARK & ※1~※4: SHIPYARD SUPPLY
(PREPARED LOCALLY)



DRAWN Dec. 4 '95 H. Maki		TYPE FR/FAR-2855
CHECKED Dec. 4 '95 K. Okamoto		名称 相互結線図
APPROVED Dec. 4 '95 K. Okamoto	FR2855 FAR2855	NAME INTERCONNECTION DIAGRAM
SCALE MASS kg	APPLICABLE TO: (MODEL)	BLOCK NO.
DWG. NO. C3421-C01-A		








DRAWN July 18, 1995 Morimoto		TYPE INT9170	
CHECKED July 18, '95 Maki		名称 INT基板 (2/2)	
APPROVED July 18 '95 Okamoto		NAME INT BOARD (2/2)	
SCALE	MASS kg	APPLICABLE TO; (MODEL)	BLOCK NO. 1B 7
		DWG NO. C3418-K02-A 03-131-6004-1	


A
B
C
D
E
F

A
B
C
D
E
F



NOTE 1.
特記なき抵抗の単位は全てΩ, 0.25W 又 コンデンサはμF.
ALL RESISTANCE IN OHMS, 0.25W, CAPACITANCE IN MICROFARADS UNLESS NOTED OTHERWISE.

DRAWN APR 29 '96 E. KISHIMA	TYPE RSB-0049/0050
CHECKED APR 29 '96 T. SAITO	名称 空中線継合回路図
APPROVED APR 24 '96 K. ITO	回路図
SCALE 1/1	SCANNER UNIT
DWG NO. C3353-K03-D	SCHEMATIC DIAGRAM



1) 注1/NOTE 1

船内電源 SHIP'S MAINS	空中線部 SCANNER UNIT	サーマルリレー THERMAL RELAY (K2)	
		型式 / TYPE	設定値 / SETTING
200/220VAC, 3φ	RSB-0026/0026A	TR-0NH/3, 1.7A	2.3A
200/220VAC, 3φ	RSB-0027	TR-0NH/3, 1.7A	2.3A
380/440VAC, 3φ	RSB-0031/0031A	TR-0NH/3, 0.8A	1.0A
380/440VAC, 3φ	RSB-0032	TR-0NH/3, 0.8A	1.0A
200/220VAC, 3φ	RSB-0041	TR-0NH/3, 0.8A	0.8A
380/440VAC, 3φ	RSB-0042	TR-0NH/3, 0.36A	0.4A
200/220VAC, 3φ	RSB-0049	TR-0NH/3, 0.8A	0.8A
100VAC, 1φ	RSB-0043	BMK9-04-8K	3.0A
220VAC, 1φ	RSB-0046	BMK9-04-8K	1.8A
24VDC	RSB-0050	BAC101505D	5A (not adjustable)
	RSB-0051	BAC101505D	5A (not adjustable)


注2
SEE NOTE 2.

DRAWN	DATE	TITLE	PSU-004
CHECKED	DATE	名称	電源制御部
APPROVED	DATE	回路図	
SCALE	DATE	NAME	POWER SUPPLY UNIT
DWG No.	DATE	SCHEMATIC DIAGRAM	

2) 注2/NOTE 2

FR-2160DSのときはPTB-14の#4と#6を現地で短絡すること

FOR FR-2160DS, PUT A JUMPER BETWEEN #4 AND #6 OF PTB-14 AT INSTALLATION.



*2. PSU-001 標準品には、K801は使用しない。

*2 K801 IS NOT USED FOR STANDARD SET

FURUNO ELECTRIC CO., LTD.