




Chevrolet S10 (1995-2004) Chevrolet S10 Blazer (1995-2004) GMC Sonoma (1995-2004) GMC Jimmy (1995-2004)

Placement	Seat Configurations	Drilling Required	Pole	Weight	Height	Width	Depth
Passenger side on the floor, under seat	Bucket/Bench	No - attaches seat studs: Chevrolet S10 (1995-2004) Chevrolet S10 Blazer (1995-2004) GMC Sonoma (1995-2004) GMC Jimmy (1995-2004)	Ordered separately	8.0 lbs	11.25″	16.25″	6.75″

Features

- Heavy gauge steel construction for long-term durability
- Black powdercoat finish for maximum corrosion resistance
- Installs in minutes with no drilling required
- Angled step moves pole away from passenger leg space
- Won't interfere with levers or factory-installed console or 4WD lever on floor
- One *Offset Universal Mounting Step* (Item No. DS-STEP) is already included with this vehicle base. However, additional *Offset Universal Mounting Steps* can be ordered to stack on top of each other if needed.

Item No. DS-120







3001 Borham Ave Stevens Point, WI 54481 Phone: 800-456-6868

Fax: 715-344-8845

Email: gamberj@gamberjohnson.com Website: www.gamberjohnson.com