


# PARTS LIST MODEL U3815



| No. | Description             | Part No.  |
|-----|-------------------------|-----------|
| 1   | Knob                    | 09347P-15 |
| 2   | Shaft Seal Nut          | 13145P-05 |
| 3   | Volume Control          | 09349P-30 |
| 4   | Connector (4 socket)    | 00084M-04 |
| 5   | Guard, Push Button      | 26553P-01 |
| 6   | Neoprene Washer (10/pk) | 18900G-39 |
| 7   | Push-To-Talk Switch     | 09851P-28 |
| 8   | Jack Cover (with Nut)   | 09518P-04 |
| 9   | Neoprene Washer (10/pk) | 18900G-39 |

| No. | Description             | Part No.  |
|-----|-------------------------|-----------|
| 10  | Headset Jack            | 09228P-03 |
| 11  | Connector (5 Socket)    | 00121M-01 |
| 12  | Gasket                  | 13176P-03 |
| 13  | Screws and Nuts (4 ea.) | 18900G-01 |
| 14  | Cap (and nylon cord)    | 13238P-01 |
| 15  | Connector (6 Socket)    | 00084M-05 |
| 16  | Mounting Kit            | 09865P-03 |
| 17  | Grommet (4 ea.)         | 18900G-08 |
| 18  | Box                     | 26497P-21 |