



# **PUSH-BACK INTERCOM**

## U9920-GPB

# LINKING INSTRUCTIONS



The Push-Back Gateway...

Model U9920.GPB Push Back Galkway PNA 1993G.41

... is capable of linking up to <u>six (6)</u> <u>Belt Stations</u> at a time...

...the <u>first four (4)</u> of which being connected with full-duplex audio





The <u>last two (2)</u> Belt Stations will each remain linked in **stand-by mode**...

... until one of the connected Belt Stations <u>drops out</u> of the system...

...at which time the Gateway automatically connects to the first stand-by unit it finds within range.













The following shows how to link an unconnected Belt Station to a Gateway that has less than six (6) Belt Stations currently linked:





The LED indicator will turn solid red for a few seconds, then blink slowly on orange, indicating an idle, disconnected state.



Model U9920-GPB Push Back Gateway

P/N 40993G-01





1-3 feet -

... being careful not to place the units too close together, as this may cause saturation and prove unsuccessful.



Finally, <u>press and immediately release</u> the <u>PTT button</u> <u>on the Belt Station</u> and the <u>PTT button on the</u> <u>Gateway</u> at the same time.



The LED indicator will now turn <u>solid red</u> when linked, blink fast on <u>orange</u> while searching, then blink slow on <u>green</u> briefly, indicating an established connection.





The Gateway's LED will slowly blink <u>green</u> once for each Belt Station linked.





A voice prompt can now be heard through the users headset, "Connection Established"





If there were less than four (4) Belt Stations connected prior to linking, your Belt Station will now be connected with full-duplex audio.



You have now achieved a "<u>strong link</u>". Each time your Belt Station is shut down and powered back up again, your link to the Gateway will remain until deliberately purged.

