

HEATER

FOR COMPLETE SYSTEM SHELTER OR MULTI-PURPOSE SHELTER


The heater may be used with the Complete System Shelter (CSS) or the Multi-Purpose Shelter (MPS). Used with either shelter, it will protect the contents of the shelter from damage due to cold weather or condensation. Use the heater if you expect temperatures below 0°F (-18°C) or condensation.

Please note that we have made every attempt to design and manufacture a safe product, but Davis Instruments assumes no liability for any injury or damage caused directly or indirectly by the installation or use of this product.

CAUTION:Although the nominal heater voltage is not hazardous, a short in the wall transformer could cause hazardous voltage to appear on the heater wires. For safety, you should always turn the heater's power unit to the "OFF" position before opening the shelter. We also recommend that you unplug the wall transformer before opening the shelter.

COMPONENTS


The heater includes components pictured below as well as the insulation blankets pictured on the following page. Please make sure you have all listed components before continuing.




Page 2 Heater

Insulation Blankets

Included in your heater package will be the insulation blankets appropriate for either the Complete System Shelter or the Multi-Purpose Shelter, as pictured below.



CSS HEATER INSULATION BLANKETS



MPS HEATER INSULATION BLANKETS

TOOLS AND MATERIALS NEEDED FOR INSTALLATION

In addition to the components listed above, you will need some of the following tools and materials. Please be sure you have everything you need before beginning the installation.

- **♦** Medium Phillips Screwdriver
- **♦** Wire Cutter
- **Wire Stripper or Knife**
- **♦** Cable Clips or Weather-Resistant Cable Ties

Choosing Cable for the Heater

The heater comes with a 50-foot (15 m) length of 22 gauge, two twisted-pair cable. When using this cable, the red and white wires are joined and used as one wire and the two black wires are joined and used as one wire. You may use 22 gauge, two-twisted pair wire in this manner for cable lengths up to 120 feet (36 m). If you want to use single pair cable, use the following table to determine the minimum wire size for the desired length of cable run.

LENGTH OF CABLE RUN	MINIMUM WIRE SIZE
Up to 60 feet (18 m)	22AWG (0.50 mm ²)
60-100 feet (18-30 m)	20AWG (0.75 mm ²)
100-160 feet (30-50 m)	$18AWG (1.0 \text{ mm}^2)$
160-250 feet (50-80 m)	$16AWG (1.50 \text{ mm}^2)$

If the heater cable is routed with a system signal cable, be aware that for cable runs over 50 feet (15 m), you need to do at least one of the following to prevent the heater cable's voltage from interfering with sensor voltages.

- **♦** Use twisted pair for the heater cable or the signal cable.
- **♦** Use shielded cable for the heater cable or signal cable (shield must be grounded).
- ♦ Keep the heater cable and the signal cable separated by several inches (at least 8 cm) over most of the length of the cable run.


Page 4 Heater

INSTALLING THE INSULATION BLANKETS AND HEATER

Follow the instructions below to install the insulation blankets and the heater in the appropriate shelter.


Installing in the Complete System Shelter

- 1. Remove the panel from the back of the CSS. Consult your CSS manual for instructions.
- Crease and fold the CSS insulation blankets as shown below.Make sure the adhesive strips on the blanket are on the back of the blanket (the side not shown below).




CREASE AND FOLD CSS INSULATION BLANKETS

- 3. Try inserting the blankets into the CSS to make sure they fit. Adjust the folding as necessary to make them fit.
- 4. Once you are sure the blankets will fit, remove the backing from the adhesive strips on the insulation blankets and secure the blankets in the CSS.
 Make sure the blankets do not cover the four screw holes in the corner of the CSS.




INSTALLING BLANKET INTO CSS

5. Reattach the panel to the back of the CSS as shown below.



REATTACH PANEL TO BACK OF CSS

6. Attach the heater to the panel using the #6 screws as shown below.




ATTACH HEATER TO CSS

Installing in the Multi-Purpose Shelter

1. Crease and fold the MPS insulation blankets as shown below.


Make sure the adhesive strips on the blanket are on the back of the blanket (the side not shown below).



CREASE AND FOLD MPS INSULATION BLANKETS

Page 6 Heater


- 2. Try inserting the blankets into the MPS to make sure they fit. Adjust the folding as necessary to make them fit.
- 3. Once you are sure the blankets will fit, remove the backing from the adhesive strips on the insulation blankets and secure the blankets in the MPS.



INSTALLING BLANKET INTO MPS

4. You may install the heater in one of three locations in the MPS, as shown below. Secure the heater to the MPS using the #6 screws.

Consult your MPS manual to determine the best mounting location for the heater in your case.



INSTALLING THE HEATER IN THE MPS

ROUTING THE HEATER CABLE

Follow the instructions below to route the heater cable from the heater to the power unit.


Attaching Heater Cable to Heater

- 1. Route the cable into the shelter through one of the cable boots at the base of the shelter.
- 2. If using the provided cable, twist the Red & White wires together to create a single wire and twist the two Black wires together to create a single wire.

 The bare wire may simply be cut off.


3. Bend each bare wire into a U-shape and secure each one under a screw head on the terminal block as shown below.

It does not matter which wire goes to each screw as long as only one wire goes to each screw.



ATTACHING CABLES TO TERMINAL BLOCK


4. Secure the cable to the heater assembly by placing the π " cable clamp over the cable and securing it to the heater assembly as shown below.



SECURING CABLE TO HEATER ASSEMBLY

Page 8 Heater

5. For strain relief, attach the self-adhesive mounting pad to the wall of the shelter and use a cable tie to secure the heater cable, as shown below.



SECURING HEATER CABLE INSIDE SHELTER

Routing the Cables

Route the heater cable to the location at which you plan to plug in the wall transformer/power unit. To prevent fraying or cutting of the cable where it is exposed to weather, it is very important that you secure it so it doesn't whip about in the wind. Use cable clips or weather resistant cable ties to secure the cable outside the shelter. Place clips or ties approximately every 3 to 5 feet (1 to 1.6 m). Do not use metal staples or a staple gun to secure cables. Metal staples—especially when installed with a staple gun—have a tendency to cut the cables.

Note: If your cable run extends more than 50 feet (15 m), keep the heater cable and any signal cable separated by at least a few inches, as discussed in "Choosing Cable for the Heater" on page 4.

Attaching Cable to Power Unit


- 1. Remove the base of the power unit by removing the four screws in the base.
- 2. Loosen the screw heads on the terminal block.

 You will eventually secure the heater cable wires underneath these screw heads
- 3. Using wire strippers or a knife, strip 3/8" (10 mm) of insulation from the heater cable wires.
- 4. Feed the cable through the hole in the power unit.
- 5. If using the provided cable, twist the Red & White wires together to create a single wire and twist the two Black wires together to create a single wire.

 The bare wire may simply be cut off or connected to ground if you wish to make use of the shield in the cable.


6. Bend each bare wire into a U-shape and secure under a screw head on the terminal block, as shown below.

It does not matter which wire goes to each screw as long as only one wire goes to each screw.



POWER UNIT TERMINAL BLOCK

7. To provide strain relief for the cable, place a cable tie around the cable just inside the hole through which this cable is running as shown below. You may need to cut off the excess cable tie in order to close the power unit.



PROVIDING STRAIN RELIEF

- 8. Replace the base of the power unit.
- 9. You may now plug the wall transformer into an outlet.
- 10.To insure that the heater is working, you may want to set the power unit to the "ON" setting and then go to the Rain Collector to insure that the heater element is hot.

DO NOT TOUCH THE HEATER ELEMENT OR ANY METALLIC PORTION OF THE HEATER. You should be able to feel the heat at a short distance from the heater element.

Page 10 Heater

USING THE HEATER

You may switch the heater on and off from the power unit.


♦ OFF

When the heater is off, the indicator light on the power unit is also off.

♦ ON

When the heater is set to "ON," the indicator light on the power unit is also on.

The heater assembly includes a thermostat switch. If the temperature at the thermostat reaches $80^{\circ}F$ ($27^{\circ}C$) the thermostat will interrupt power to the heater element. When the temperature at the thermostat drops to about $50^{\circ}F$ ($10^{\circ}C$) power flow to the heater element will be resumed.



LOCATION OF THERMOSTAT

Using the Heater Page 11

Product Numbers: 7726, 7730

Davis Instruments Part Number: 7395-097 Complete System Shelter Heater, Multi-Purpose Shelter Heater Rev. B Manual (7/7/99)

Controlled Online: Weather: Accessories: Shelter Heaters

This product complies with the essential protection requirements of the EC EMC Directive 89/336/EC.

© Davis Instruments Corp. 1998. All rights reserved.



3465 Diablo Avenue, Hayward, CA 94545-2778 510-732-9229 • Fax: 510-732-9188 E-mail: info@davisnet.com • www.davisnet.com