Intellian i3/i4/i4P Serial Number

This serial number will be required for all troubleshooting or service calls made regarding this product.

Notice

All Right Reserved

Intellian i3/i4/i4P[®] and Intellian[®] are the registered trademarks of Intellian Technologies, Inc., and should not be appropriated without permission by Intellian Technologies, Inc., and the information contained in this manual is the property of Intellian Technologies, Inc. Any and all parts of this manual shall not be reproduced and distributed in any form without prior written consent by Intellian Technologies, Inc. The information contained in this manual shall be subject to change at any time without notice due to the functional upgrades of the product.

Copyright© Intellian Technologies, Inc.

Doc. No. I3I4-DC V100

CONTENTS

INTRODUCTION1
INTRODUCTION TO INTELLIAN 13/14/14P
FEATURES OF INTELLIAN 13/14/14P2
BASIC SYSTEM CONFIGURATION OF INTELLIAN 13/14/14P
INSTALLATION4
SYSTEM COMPONENTS
TOOLS REQUIRED FOR INSTALLATION
PLANNING THE INSTALLATION
SELECTION OF INSTALLATION SITE
INSTALLATION AND MOUNTING OF ANTENNA10
INSTALLING THE ACU
CONNECTING THE SYSTEM CABLES
CONNECTING THE SYSTEM TO A GPS
TARGET SATELLITE SETTING
ADJUSTING THE LNB SKEW ANGLE (LINEAR POLARIZATION ONLY)
OPERATION INSTRUCTION24
INTRODUCTION
OPERATION USING THE ACU25
ACU SOFT KEYS
NORMAL MODE
SET UP MODE
OPERATION USING PC CONTROLLER PROGRAM
INTRODUCTION
PROGRAM INITIALING AND SERIAL PORT SETUP
MAIN MENU – USING DEFAULT DUAL-SAT MODE
SET SATELLITE INFORMATION
MAIN MENU- USING ADVANCED TRI-SAT MODE
SET SATELLITE INFORMATION
CONTROLLER MENU
TROUBLESHOOTING
PREPARATION FOR TRANSPORTATION67
WARRANTY
APPENDIX : TECHNICAL SPECIFICATION
INTELLIAN I4/I4P
INTELLIAN 1370

INTRODUCTION

Introduction to Intellian i3/i4/i4P

Intellian i3/i4/i4P is a digital satellite antenna system designed specifically for all types of vessels (Anchored or transit) to automatically identify, track and capture satellite signals from the Digital Video Broadcasting (DVB: the international standard for digital TV transmissions) compatible satellites.

Specifically, Intellian i3/i4/i4P has Wide Range Search (WRS) algorithm, which minimizes the search time during initialization, and Dynamic Beam Tilting (DBT) technology, which dynamically shapes the antenna beam to utilize stabilization. Once the satellite is acquired, the antenna DBT continuously measures the heading, pitch, and roll of the vessel by obtaining the satellite signal level around the antenna point, and transmits commands to the antenna motors to keep the antenna pointed at the satellite at all times. This active stabilization is enhanced by a conical scan tracking function to detect and lock onto the strongest signal, resulting in the clearest reception possible. The i3/i4/i4P has a built-in GPS system which enhances the speed of satellite signals acquisitions. In addition, the i4P provides the embedded auto skew angle control system to maintain the optimal signal strength and increase the quality of satellite receptions in weak satellite single coverage area.

2

i3/i4/i4P Satellite Antenna System – Install and User Manual

Features of Intellian i3/i4/i4P

Enjoy satellite broadcasts at sea

Intellian i3/i4/i4P is the most modern antenna system that enables you to receive a high quality broadcasting signal at sea, where the atmospheric and environmental condition are very harsh.

Fully automatic control system

Fully automatic control system allows you to simply turn the power switch on, and have crystal clear, high quality satellite television in motion or at anchor.

High quality antenna

High tech parabolic antenna technology has been adopted for this antenna system, which is optimal for marine conditions. This enables you to receive the optimal signal level even when it is raining or snowing.

Fast and efficient search for the satellite

The WRS (Wide Range Search) algorithm allows for the antenna system to search the satellite within the shortest amount of time and to detect the satellite signal under any position and with any directional movement of the ship.

Easy installation and outstanding reliability

Intellian i3/i4/i4P uses only one RF cable for installation. This makes installation easy. Power, RF and Data signals transfer from the antenna the ACU through this single cable. In addition, Intellian i3/i4/i4P provides highly reliable system through the implementation of a modularized design, and the usage of strictly proven components.

Built-in GPS

Intellian i3/i4/i4P has imbedded GPS, which allows for the system to upload the GPS data automatically into the system for an even faster and stable system.

Built-in automatic skew angle control system

The automatic skew control system allows Intellian i4P to maintain the optimal skew angle at all times and ensure maximum level of satellite signal level.

Introduction

3

Basic System Configuration of Intellian i3/i4/i4P

For your satellite TV system to work properly, the system will have to be connected with all of the provided components properly, as shown in the figure below (Refer to next chapter 'Installation' in this manual for more detailed connection instructions). Separate purchase of a satellite receiver and a TV is required.



i3/i4/i4P Satellite Antenna System – Install and User Manual

Installation

4

The components of the Intellian i3/i4/i4P have been designed to be modular so that it is suitable for simple installation on all types of vessels.

System Components

Antenna Unit

The antenna of Intellian i3/i4/i4P is composed with the following components for the optimum search and reception of the satellite signal.

- Mechanical Unit manipulates the antenna to receive the optimal satellite signal regardless of the movement of the vessel.
- Control Unit controls mechanical operation of the antenna.
- RF Unit transmits the optimum satellite signal to the receiver.
- Radome protects the antenna from the severe marine environment.



6

i3/i4/i4P Satellite Antenna System - Install and User Manual

Antenna Control Unit (ACU)

The Antenna Control Unit (ACU) provides the power to the antenna and controls the various settings of the antenna. Additionally, VFD (Vacuum Fluorescent Display) allows for you to operate the ACU in the dark.

The functions of the ACU are as follows:

- · Provide power for the antenna unit
- · Monitor the antenna status
- · Change the target satellite
- · Set up the user environment
- · Set the current GPS information
- · Set satellite information
- Move antenna manually
- · Perform self-diagnosis of the antenna
- · Set up the interface with a PC





Installation Kit

Contain the items required for securing the antenna unit and ACU to your boat.



Other Components

No	Component	Size	Q'ty	
1	ACU Bracket		-	2EA
2	RG6 (Antenna – ACU	RG6 (Antenna – ACU RF Cable)		1EA
3	RG6 (ACU – IRD Cab	le)	3m	1EA
4	Power Cable		10m	1EA
5	PC Serial Cable		1.8m	1EA
6	NMEA Connector		AK950-2	1EA
7	Power Connector		AK950-3	1EA
	Hex Bolt		M8x35L	5EA
	Tapping Screw		ø4x16L	5EA
8				
	Flat Washer		M8	5EA
	Spring Washer		M8	5EA
9	Install CD		-	1EA
10	Manual		-	1EA
11	Mounting Tomplete	i3	-	154
	wounting remplate	i4/i4P	-	IEA
12	Quick Installation Guide		-	1EA



7



Φ80mm

Hole Saw



Pencil



Planning the installation

8

Selection of Installation Site

Install the antenna in accordance with the following procedures to insure maximum performance of the antenna.

The ideal antenna site has a clear view of the horizon/satellite all around.

Please be sure there are no obstacles within 15 degrees above the antenna. Any obstacles located above a 15 degree elevation can prevent the antenna from tracking the satellite signal (Refer to the drawing).



Keep the antenna out of line with nearby radars, as their energy levels may overload the antenna front-end circuits. If necessary, position the antenna unit so it is at least four feet (1.2 meters) above or below the level of the radar.

Make sure that the mounting surface is rigid, so that it will not flex when the vessel vibrates. If necessary, add a stiffening member to the mounting site to strengthen it.

The movement of the antenna can be minimized by installing it at the center of the ship. For optimal performance of the antenna, it is not recommended to install at any corner of the ship, where the movement of the ship is the greatest.

Install the bottom of the antenna parallel to the surface of the sea and fix tightly to the structure of the ship.

When setting the antenna down, be careful not to have the RF connector. Striking the connector on the bottom directly will damage the connector and make connection impossible.

Cables

Before installing the system cables, you need to take the follow -ing points into consideration.

 All cables need to be well clamped and protected from physical damage and exposure to heat and humility.

9

- · Cable with an acute bend is not allowed.
- Where a cable passes through an exposed bulkhead or deckhead, a watertight gland or swan neck tube should be used.

Power requirements

You need to follow the power requirements to avoid damage the system.

Intellian i3/i4/i4P has been designed to work on a boat's power supply rated at 12VDC (acceptable range: 10.8~15.6 V DC).

If your IRD(s) and television(s) require a 110V/240V AC power supply, you will need to install a suitable DC to AC converter to operate the unit(s) from your boat's DC power supply.

Extending the cables

The cables that have been supplied with your Intellian system should be of adequate length to complete the installation on most boats.

Power Cable

This cable supplied at a length of 10m.

RF Cable

This cable is supplied at a length of 15m. If a longer length is required you should replace this cable with an extended RF cable supplied by Intellian Technologies.

Exceeding the indicted cable lengths will result in reduced performance of your system. 10

i3/i4/i4P Satellite Antenna System – Install and User Manual

Installation and Mounting of antenna

The method of installation and mounting of antenna may vary with vessel design but the following procedures are applicable in most situations, and will result in a secure and effective installation.

Confirmation of size and installation of power tower

- Confirm the height and diameter of the bottom surface of the antenna before installing it.
- The space must be sufficient for installing the antenna unit considering the height and diameter of the antenna.
- The height and the diameter of the bottom surface of the antenna are as shown in the following drawing. If possible, install the antenna using a power tower.



Intellian i4/i4P

44 (17.3') 943 (17') 11

Untellian i3

Before installing the antenna you have to dismantle the radome with a hexagon wrench tool and remove the foam fixation from the antenna interior. You have to reassemble the radome before installation. The system functions will be abnormal if the radome is off.

Mark of the antenna mounting position

Referring to the mounting template, mark where antenna is to be mounted on board the ship (it must be a flat surface) or on a separate power tower by the drawing below.



Intellian i4/i4P



If a power tower is not sued to mount the antenna, separate cable shock and waterproofing measures must be taken to protect the RF connector from begin exposed to the sea water and external shocks. An exposed cable may cause electric shock and cause serious damage to the equipment.

13

i3/i4/i4P Satellite Antenna System – Install and User Manual

Securing hole for bolts and cable way



Make 4 bolt holes of 10mm diameter, one at each corner of a rectangle drawn as above, and make a circular hole of 80mm diameter at the center of the rectangle through which the cable will run.

Connection of RF cable

Remove the rubber protector from RF connector. Connect the RF cable to the RF connector under the base plate through the access hole using a 11mm spanner. Be careful not to tighten it too much, as you may damage the connector.





Do not use excessive force when using the spanner, this will damage the threads. Be careful that the connectors do not contact the mounting surface of the antenna, this may cause a critical malfunction and serious damage to the equipment.

Mounting the antenna

Attach the antenna by using the hex head bolts (M8X35L), M8 spring washers, and M8 flat washers supplied.



15

i3/i4/i4P Satellite Antenna System – Install and User Manual

To Install the ACU

1. The ACU should be installed using the two supplied mounting brackets which allow for a top or bottom mounting configuration.

2. Using the self tapping screws supplied, attach the mounting brackets to the sides of the ACU.

- 3. Place the ACU in the location where it is going to be installed.
- 4. Connect the cables to the rear of the ACU.
- Using a pencil to mark the 4 hole positions (2 each side), and use the appropriate drill bit to drill them.



Installing the ACU

ACU dimensions



Installation Site

The ACU should be installed below decks, in a location that is:

- Dry, cool, and ventilated.
- Easy accessible from your main TV viewing area.

Connecting the System Cables

After installation and fixation of the antenna, connect the ACU to the antenna. Refer the drawing below to connect cables.

SINGLE IRD Connection



- Connect the RF Cable (15m) from the RF 1 connector on the antenna to the ANT. RF1 connector on the rear of ACU.
- Connect the ACU-IRD Cable (3m) from the RECEIVER connector on the rear of the ACU to RF on the IRD.
- Connect the power cable (10m) from DC power connector on the rear of ACU to a power source at 12V DC.
- Press the POWER ON switch in front of the ACU to start the operation of the antenna system automatically.



i3/i4/i4P Satellite Antenna System - Install and User Manual

DC Power Cable NMEA GPS PC Cable

18

You can connect two IRDs for your antenna as shown in the following diagram. However, only one of the IRDs can be configured as a two satellite receiver.

The other IRD needs to be configured as a one satellite receiver. The two satellite receiver determines which satellite is tracked, while the other receiver can watch any channel which is available from the tracked satellite.

As in the single IRD option the RF cables from the antenna base plate should be connected to 'LNB', 'ANT', or 'Satellite In' on the rear panel of IRD.

Multiple IRDs Connection

In order to connect multiple IRDs to the antenna, you will need to purchase a suitable LNB multiswitch. The multiswitch has to be installed between the antenna unit and the IRDs as shown in the following diagram.



IRD 1~4 : Not supplied

20

i3/i4/i4P Satellite Antenna System – Install and User Manual

Connecting the system to a GPS

For improved satellite tracking, you can connect your satellite TV system directly to your boat's NMEA 0183 GPS system. To do this you will need lengths of cable suitable for connecting to your GPS system and the green 2-way ACU GPS connector supplied with your Intellian i3/i4/i4P Satellite TV System.

To connect the system to a GPS

- 1. Strip back the insulation of each cable and connect a cable to each terminal of the 2-way connector.
- 2. Tighten the locking screws.
- Connect the cable from the +ve (positive) terminal of the ACU GPS connector to the NMEA OUT wire of the boat's GPS system.
- 4. Connect the cable from the **-ve** (negative) terminal of the ACU GPS connector to the **ground wire** of the boat's GPS system.
- 5. Refit the ACU GPS connector to the rear of the ACU.





You can select the target satellite to receive satellite signal from. If the target satellite is not on the list you will have to register the target satellite.

21

GPS Setting

You can input the GPS information through the ACU or the PC Program. To setting the GPS information, the antenna system has to be in 'SET UP mode'. For detailed instructions, please refer to page 40; 'Setting the GPS', and page 60; 'Set Antenna GPS and find Antenna Angle'.

Satellite registration

You can register the target satellite through the ACU or the PC Program. To register the target satellite, the antenna system has to be in 'SET UP mode' and the required information is, Satellite Name, Satellite Longitude, Method of Satellite Identification, Frequency of each of the band, Symbol Rate, Network ID, Power Change method. For detailed instructions, please refer to page 33; 'Edit Satellite Information', page 55; 'Set Satellite Information', and page 61; 'Set Tracking Information of Satellite'.

Satellite Pair Selection

You can select the Satellite Pair from the list through the ACU or the program. You can easily select the target satellite from the satellite pair. For detailed instructions please refer to page 31; 'Setting the Satellite pair', page 55; 'Set Satellite Information'.

Target Satellite Selection

Choose the target satellite from the Satellite Pair. When selecting through the ACU, you have to press the left button to select the target satellite while the antenna system is in either 'Searching Mode' or 'Tracking Mode'. When using the PC program you can select either satellite 'A' or satellite 'B' from 'Tracking Satellite' at anytime.

Adjusting the LNB Skew Angle (Linear polarization only)

LNB Skew Angle

The LNB skew angle only needs to be adjusted when the target satellite uses linear polarization. In order to receive the maximized satellite signal level, the LNB skew angle must be adjusted according to the calculation of current GPS location and target satellite.

It only needs to be adjusted when changing from satellite to another, or when the boat has traveled a significant geographic distance. It should NOT need to be readjusted if the boat stays in the same location and is operating on the same satellite.

Skew Angle Adjustment for i3/i4

Polarization of your Intellian i3/i4 antenna must be accomplished manually by the following steps.

- Remove the upper part of Radome after switching power OFF.
- Loosen 4 bolts of the connection of LNB and feed horn.
- Turn LNB to place it to the angle indication of the back of the feed horn.
- Tighten the 4 bolts.



Auto Skew Angle Adjustment for i4P

Intellian i4P with an embedded auto skew angle control system. Therefore, manual adjustment of skew angle by user is not required. The skew angle is continuously adjusted automatically through the calculation of the optimum skew angle by using the information of the targeted satellite and the output value from the GPS sensor. Together with such location information of the ship as ship's longitudinal and latitudinal position change from movement the skew angle will be adjusted accordingly. The skew angle of LNB is shown from the ACU and GUI Program.



24

Operation Instruction

Introduction

This section of the handbook describes how to set up your Satellite TV System after installation using the ACU or PC controller program and includes the following functions:

- System start up.
- · Changing the default satellite.
- Monitoring the antenna status.
- · Setting sleep mode.
- · Entering setup mode.
- Setting the satellite pair.
- Editing satellite information.
- Setting the antenna parameter.
- Setting the LNB local frequency.
- Setting GPS.
- Setting the DiSEqC method.
- · Display versions.
- Display power status.
- Setting antenna go position.
- Setting antenna move step.
- · Setting remote control.
- Setting the factory default parameters.
- Performing diagnostic tests.

Note: Many of the above functions will only be required only after initial installation of your system. Refer to the Quick Installation Guide before operating the system.

25

Operation Using the ACU

ACU Soft Keys

Normal Mode

Start Up

With the system installed and power applied, the ACU screen will show the following sequence:

1.Communication is being established between the antenna and the ACU. The ACU initialized.

2. The antenna is initialized.

3. The antenna is searching for Satellite A.

4. The antenna has located the satellite and is now tracking.

26

i3/i4/i4P Satellite Antenna System – Install and User Manual

Change of Target Satellite

Your antenna is programmed with two candidates of target satellites as default Dual-sat mode. Use advanced Tri-sat mode for targeting three satellites. To change the target satellite, press LEFT soft key. The target satellite is changed and is automatically tracked by the antenna.

Default Dual-sat Mode

1. Press LEFT soft key for tracking Satellite B.

TRACKING B:DTV119 A:DTV101 SETUP 2. The antenna is tracking Satellite B.

Advanced Tri-sat Mode

1. Press LFET soft key for tracking Satellite B.

3. Press LFET soft key for tracking Satellite C.

4. The antenna is tracking Satellite C.

 \ast Register a key on your remote control to track alternative target satellites. See page 45.

i3/i4/i4P Satellite Antenna System – Install and User Manual

Monitoring the current status of the antenna

While POWER ON to Intellian i3/i4/i4P, ACU displays the status of the antenna. The various ACU displays may be shown according to the current status of the antenna.

1. The antenna is searching for Satellite A.

 TRACKING A: DTV101

 B: DTV119

 SETUP

 O

2. The antenna is tracking Satellite A.

3. The antenna is unwrapping the cable.

 TRACKING A: DTV101

 B: DTV119

 SETUP

 O

 A

4. The antenna is again tracking satelliteA.
Press center soft key to display position detail.

5. Antenna position detail and signal strength are displayed.

 Press center soft key to display current GPS information. Press SETUP to return to main setup mode.

Sleep Mode

If the antenna lost the tracking satellite in sleep mode, sleep mode is cancelled.

1. Press BACK to enter sleep mode.

2. Press Back again for exiting sleep mode.

* Register a key on your remote control to change sleep mode. See page 45.

i3/i4/i4P Satellite Antenna System – Install and User Manual

Set Up Mode

Begin Set-Up Mode

To enter the Set-up Mode simply follow the instructions below:

1. With the antenna tracking . Press SETUP.

2. Press YES to enter setup mode.

3. Press Yes to set the satellite pair.

YES

0

0

NO \cap

0

i3/i4/i4P Satellite Antenna System - Install and User Manual

Example2. Changing the target satellite using DiSEgC: 1. Press YES to enter setup mode. SETUP MODE? С YES NO R \bigcirc 2. Press YES to set satellite pair. SET SAT PAIR ? 0 PREV NEXT YES \mathcal{D} 3. Set satellite A SAT A : DTV101 00 Press PREV to show previous satellite name. PREV SELECT NEXT Press SELECT to set chosen satellite to SATA. 0 Press NEXT to show next satellite name. \bigcirc 4. Set satellite B SAT B : DTV119 \bigcirc Press PREV to show previous satellite name. PREV SELECT NEXT ŏ Press SELECT to set chosen satellite to SAT B. Press NEXT to show next satellite name. 0 \mathcal{D} Ο 5. Set satellite A* when DiSEqC is active from IRD. SAT A* : DTV101 C Press PREV to show previous satellite name. PREV SELECT NEXT Press SELECT to set chosen satellite to SATA*. \bigcirc 0 Press NEXT to show next satellite name. \bigcirc 6. Set satellite B* when DiSEqC is active from IRD. SAT B* : DTV119 00 Press PREV to show previous satellite name. PREV SELECT NEXT Press SELECT to set chosen satellite to SAT B*. Press NEXT to show next satellite name. \bigcirc 0 R 7. Press YES to save selections. 0 SAVE ? Press NO to cancel and return to main setup mode. YES NO Ο

0

0

19. Press YES to save the input information.

18. Select the DISEQC method³⁾

(AUTO recommended)

Press NO to cancel and return to main setup mode.

- 1) Verification method
 - SIGNAL use only signal level for tracking DVB LOCK – use only DVB Lock signal for tracking DVB DECODE - verify satellite using DVB decoding method for tracking DSS DECODE – decode only DSS Lock signal for tracking
- 2) Voltage supply method
- AUTO- change voltage to LNB by IRD voltage ONLY 13V - always supply 13V to LNB ONLY 18V – always supply 18V to LNB
- 3) DISEQC method

AUTO - change signal to LNB by IRD DISEQC ONLY 0KHZ - always supply 0kHz to LNB ONLY 22KHZ - always supply 22kHz to LNB

i3/i4/i4P Satellite Antenna System - Install and User Manual

Setting the Antenna Parameters

IC

NEXT

x3

It is not recommended for a novice satellite service user to use this mode. Consult Intellian for changing antenna parameters.

SET SAT PAIR ?

YES

Ο

PREV

0

2. Press NEXT three times to enter set antenna parameter mode.

1. Press YES to enter setup mode.

3. Press YES to set antenna parameter.

PARAM: PREV	SCAN YES	OFF	NEXT	0	
0	h		0	-	

4. Select the PARAM 1) - SCAN OFF PREV - Shows previous parameter. SELECT - Set the displayed parameter. NEXT - Shows next parameter. Press ENTER to move to next screen.

WRS -	LEVEL : INPUT	0500	Atte
0		0	
	\bigcirc		

5. Input the WRS LEVEL. +increases the value. - decreases the value. Change the underscored digit using the +/- buttons. Press INPUT to accept the value and move to next digit. Press BACK to move to previous digit. Press ENTER to move to next screen.

6. Press YES to save the input information. Press NO to cancel and return to main setup mode.

i3/i4/i4P Satellite Antenna System - Install and User Manual

Setting the LNB local frequency

It is not recommended for a novice satellite service user to use this mode. Consult Intellian for changing antenna parameters.

CASE 1. Single band LNB is used.

2. Press NEXT four times to enter set local frequency mode.

LNB TYPE : SINGLE

LOCAL FREQ: #####MHz

INPUT

 \mathcal{Q}

Ο

 \bigcirc

4. Select the LNB Type 1)- SINGLE. PREV - Shows previous LNB type.

3. Press YES to set local frequency.

PREV SELECT NEXT \cap SELECT - Set the displayed LNB type. Ο NEXT - Shows next LNB type. \mathcal{D} Press ENTER to move to next screen.

> + õ

Ο

 \bigcirc

C

5. Input the local frequency of LNB. +increases the value. - decreases the value. Change the underscored digit using the +/buttons. Press INPUT to accept the value and move to next digit. Press BACK to move to previous digit. Press ENTER to move to next screen.

6. Press YES to accept the data. Press NO to cancel and return to main setup mode.

1) Parameter Setting method

SCAN OFFSET - The actual angle between the marked point on the sub-reflector and the datum.

TRACK SCALE - To control the tracking speed while antenna is tracking the satellite. High Track Scale value resulting in high tracking speed.

DETECTLEVEL - The basic single detection level.

TRACKING LEVEL - The basic signal tracking level

ELADJUST - The mechanical tolerance compensation of elevation limit.

WRS LEVEL - The basic WRS detection level.

POWER THRESHOLD - The value to identify Vertical/Horizontal or RHCP/LHCP.

DISEQC LEVEL - The value to identify 22KHz tone.

OFFSET RH-LH - The difference value between RHCP/LHCP and SCAN OFFSET.

USE WRS - To apply WRS while antenna is searching for satellite.

OFFSET DIFFERENCE - To apply Offset Difference.

CASE 2. Universal LNB is used. (Low band local frequency-9750 MHz/ High bnad local frequeny 10600 MHz)

2. Press NEXT four times to enter set local frequency mode.

4. Select the LNB Type ¹⁾ – UNIVERSAL. PREV – Shows previous LNB type. SELECT – Set the displayed LNB type. NEXT – Shows next LNB type. Press ENTER to move to next screen.

1) LNB Type SINGLE: Single Band LNB Asia 11300 MHz, Japan 10678MHz, Korea 10750MHz, America 11250MHz

UNIVERSAL: Universal LNB Low band local frequency -9750 MHz High band local frequency -10600 MHz

Press NO to cancel and return to main setup menu.

PREV - Shows previous DiSEqC Method.

NEXT- Shows next DiSEqC Method.

SELECT/ENTER – Set the displayed DiSEqC

3. Press YES to use DISEQC.

4. Select the DiSEqC Method¹⁾ າດ DO NOT USE DISEQC PREV SELECT NEXT tu 0 0

1) DiSEqC Method

DONOT USE DISEQC – DISEqC is not using. USE TO CHANGE BAND – DISEqC is using to change to low and high band. USE TO CHANGE SAT – DiSEqC is using to change tracking satellite

method.

i3/i4/i4P Satellite Antenna System - Install and User Manual

1. Press YES to enter setup mode.

Display Versions

This sequence enables you to see what version of antenna and ACU software version are installed on your system.

SET SAT PAIR ? O PREV YES NEXT O 0 Ο

2. Press NEXT six times to enter the view version mode.

3. Press YES to view version.

4. Antenna product name and S/N are shown. Press center soft key to view antenna software version. Press EXIT to return to main setup mode.

5. Antenna software version and S/N are shown. Press center soft key to view ACU software version. Press EXIT to return to main setup mode.

ACI	J S/W VE	R : 0.	010
S/N:	0000000	000 EX	īIJŏ
0	0	C	$\overline{}$

6. ACU software version and S/N are shown. Press EXIT to return to main setup mode.

43

mode 6. IRD Voltage and frequency are shown.

Press center soft key to view antenna voltage.

Press center soft key to view IRD Voltage and

frequency. Press EXIT to return to main setup

Press EXIT to return to main setup mode.

4. ACU Voltage is shown.

Press EXIT to return to main setup mode.

7. Press EXIT to return to main setup mode.

i3/i4/i4P Satellite Antenna System – Install and User Manual

5. CODE¹⁾ 101 is pass.

Press EXIT to return to main setup mode.

CODE 101 PASSED.

Ο

RESULT: 1

 \bigcirc

 \bigcirc

EXIT

 \mathcal{D}

CHANGE SAT SLEEP MODE CLEAR REGISTERED KEY

Clear registered key.

i3/i4/i4P Satellite Antenna System – Install and User Manual

Setting Region

1) CONTINENT N. AMERICAN, S.AMERICAN, EUROPE, ASIA.. 2) REGION New York, Miami, UK, JAPAN..

0

Ο

0

Setting the factory default parameters

Initialize all of the antenna information to the factory set up.

2. Press NEXT thirteen times to enter the default setting mode.

3. Press YES to set default parameters.

OPERATION USING PC Controller Program

Introduction

GUI Software of Intellian i3/i4/i4P has been coded for the user to easily set up the antenna by using the user's personal computer. Using the GUI program enables the user to easily monitor and modify the information of antenna, satellite and GPS. Additionally, the detail diagnostic method of the antenna is provided by the GUI program.

- To start this GUI program,
- 1. Connect one end of PC serial cable to the serial port on the computer.
- 2. Connect the other end of the PC serial cable to the "PC Interface" on the rear of ACU.
- Execute GUI program by inserting the CD-ROM supplied into the CD-ROM drive of the computer.
- 4. After turning on the power of the ACU, if the blue status circle does not change to 'Search' or 'Tracking' from 'Initialize', then you have to change the "PC Interface" terminal of ACU for PC program use rather than GPS use.

Operation Using PC Controller Program

Program Initialing and Serial Port Setup

The communication between the ACU and antenna must be established as the first step in order to start setting your antenna.

Command Button

- Baud Rate Setting To display communication speed.
- Connection Status Display To display communication port between ACU and PC.
- · Serial Port Setting To select serial port to be used.
- Connect / Disconnect To establish communication between PC and ACU.

i3/i4/i4P Satellite Antenna System – Install and User Manual

Antenna Status Monitoring

- · Search Antenna is searching for the selected satellite.
- · Tracking Antenna is tracking the selected satellite.
- · Initialize Antenna or the ACU is initializing.
- Unwrap Antenna is unwrapping the wire.
- Setup Antenna is in setup mode.
- Comm. Antenna is possible communication.

Definition of program Command Buttons

- Restart To exit setup mode and restart antenna again.
- · Setup To enter the setup mode.
- Get Antenna Information To indicate the information on display after receiving it input to the antenna.
- Factory Setting To initialize all antenna information to the default as same as ex-factory status.
- Load Default To display the up-to-date information input to the PC program.
- Update Default To update the antenna information by the up-to-date information input to the PC program.

Operation Using PC Controller Program

Set Satellite Information

Satellite Information

The name, longitude and confirmation method of the satellite is displayed when a satellite is selected in the list box. Push "Edit Satellite Information" button to update the information on modifying the value.

DiSEqC

When the operation method of DiSEqC is selected to "Change Band", DiSEqC may be used for updating the local frequency and to "Change Satellite", for updating the target satellite.

Registration of target satellite

In case that the DISEqC is selected to "Not Use" or "Change Band", only OrRegister for Sat A" and OrRegister for Sat B" may be registered. Pushing O or O button after selecting the satellite in the list box makes it possible to register A or B. In case that DISEqC is selected to "Change Satellite", O'Register for Sat A" and O'Register for Sat B" are activated and the target satellite when DISEqC is available may be registered by pushing O and O buttons.

· Local Frequency

In case that DiSEqC is selected to "Change Band", be sure to push the "Universal LNB" button. In case that the DiSEqC is selected to "Not Use" or "Change Satellite", be sure to push "Single Band" button and key in into the Local Frequency, and then push " Set Local Frequency" button.

56

i3/i4/i4P Satellite Antenna System – Install and User Manual

Command Button

- Edit Satellite Information To modify the satellite information.
- Register for Sat A To register a satellite to satellite A.
- Register for Sat B To register a satellite to satellite B.
- Not Use Do not use DiSEqC.
- Change Band To use DiSEqC to change band.
- Change Satellite To use DiSEqC to change the satellite.
- Singe Band Antenna in use of Single LNB.
- Universal Band Antenna in use of universal LNB.
- Set Local Frequency To select local frequency of LNB.

Main Menu- Using Advanced Tri-sat Mode

Antenna Status Monitoring

- · Search Antenna is searching for the selected satellite.
- Tracking Antenna is tracking the selected satellite.
- · Initialize Antenna or the ACU is initializing.
- Unwrap Antenna is unwrapping the wire.
- Setup Antenna is in setup mode.
- Comm. Antenna is possible communication.

Definition of program Command Buttons

- · Restart To exit setup mode and restart antenna again.
- Setup To enter the setup mode.
- Get Antenna Information To indicate the information on display after receiving it input to the antenna.
- Factory Setting To initialize all antenna information to the default as same as ex-factory status.
- Load Default To display the up-to-date information input to the PC program.
- Update Default To update the antenna information by the up-to-date information input to the PC program.

Set Satellite Information

Satellite Information

The name, longitude and confirmation method of the satellite is displayed when a satellite is selected in the list box. Push "Edit Satellite Information" button to update the information on modifying the value.

DiSEqC

When the operation method of DiSEqC is selected to "Change Band", DiSEqC may be used for updating the local frequency and to "Change Satellite", for updating the target satellite.

Registration of target satellite

In case that Tri-sat Mode is selected and the DiSEqC is selected to "Not Use, only **0**"Register for Sat A", **0**"Register for

58

Sat B" and O"Register for Sat C" may be registered. Pushing O or O outform of the selecting the satellite in the list box makes it possible to register A or B or C.

Local Frequency

In case that DiSEqC is selected to "Change Band", be sure to push the "Universal LNB" button. In case that the DiSEqC is selected to "Not Use" or "Change Satellite", be sure to push "Single Band" button and key in into the Local Frequency, and then push " Set Local Frequency" button.

Command Button

- Edit Satellite Information To modify the satellite information.
- Tri-sat Mode To use Triple Satellite.
- Register for Sat A To register a satellite to satellite A.
- Register for Sat B To register a satellite to satellite B.
- Register for Sat C To register a satellite to satellite C.
- Not Use Do not use DiSEqC.
- Change Band To use DiSEqC to change band.
- Change Satellite To use DiSEqC to change the satellite.
- Singe Band Antenna in use of Single LNB.
- Universal Band Antenna in use of universal LNB.
- Set Local Frequency To select local frequency of LNB.

Load and Update Default Command Button

1) Load Default: Click "load default" button to select *.rif file according to your region.

10	Verification	n
on of Satel	열기 🔹 🔀	Only
on of Satel sute Diagno	찾는 위치(l): 🔁 Intellian Antenna PC Controller 💿 🔶 🖆 📰・	Lock Only
rs for Cont	Region Info_Asia_1,0,rif	Decode
	Elegion Into_Europe_1,0,nt	Decode
	Region Info_Korea_1,0,rif	
earch	Region Into.North America.10.rit Region Into.South America.10.rit	Satellite Mo
racking		0N
itialize	BSI (U.S.(N): Region Into North America 1.0 rtf 9171(0)	
nwrap	TRANSFER AND THE PROPERTY AND THE PROPER	er Regis A for Sa
etup		
leepMode	Load Update	
omm.	Default Diesec Local Excercise	

Operation Using PC Controller Program

 Update Default: Click "Update default" button to open update default Dialogue. Click "yes" button to update the system.

ecute Diagno ters for Cont n	rol COM1 COM5 © COM2 COM6			
16	- Tracking Satallite COM3 C COM7			
Search	Intellian Antenna PC Controller			
Tracking	Do you want to update default set "Region Info_North America_1,0,rif" ?			
Initialize				
Unwrap				
Setup				
SleepMode	Load Update			
Comm.	Default Default			

3) Click "confirm / yes" button to complete the update.

ters for Co n	ntrol	Longitude 101.0 W 🗸
15	Tracking Satellite	Edit Satellite Information
Search	Intellian Antenna PC Controller	a
Tracking		
Initialize	Default update complete successfully,	Dialige . Of t
Unwrap	(활연	Register Register
Setup		
SleepMod	e Load Update	
Comm.	Default Default	DiSEqC Local Fre

i3/i4/i4P Satellite Antenna System – Install and User Manual

Controller menu

Set Antenna GPS and Find Antenna Angle

Antenna makes use of GPS information to search satellite quickly. The more precise the GPS information is, the quicker the antenna is able to search the satellite. The method to input information into GPS is to push "Set GPS" button after keying in the latitude and longitude information on "City GPS". Pushing "Add City" button stores the GPS information. By selecting the stored region in the list box, the GPS information of such region is displayed. The Intellian i3/i4/i4P satellite TV antenna system utilizes GPS data to locate the satellite faster.

Command Buttons

- Load GPS Files Reads in the various city information from the GPS files.
- Add City Adds the name of city and its GPS information to GPS files.
- Delete City Deletes the name of city and its GPS information from the GPS files.
- Set GPS Inputs the indicated GPS information on display to antenna.

62

i3/i4/i4P Satellite Antenna System – Install and User Manual

- Find Angles & Skew Antenna GPS Finds the current antenna angles and Skew angle in relation to the longitude of satellite and GPS.
- Find Angles & Skew City GPS Finds the current city angles and Skew angle in relation to the latitude of satellite and GPS.

Set Tracking Information of Satellite [Primary]

Command Button

- Edit Satellite Information To change frequency information of the antenna
- Satellite Information Satellite information consists of frequency, symbol and NID(Network ID) of a transponder in tracking satellite. There are four groups of satellite information. 'Vertical/RHCP' is applied when IRD supply 13V, and 'Horizontal/LHCP' is applied when IRD supply 18V. 'LOW' is applied when DiSEqC signal is not detected from IRD, 'HIGH' is applied when DiSEqC signal is detected from IRD, 'HIGH' is applied when DiSEqC signal is detected from IRD, 'HIGH' jou select 'Not Use' or 'Change Satellite', two 'HIGH' groups are activated. If you select Change Band', two 'HIGH' groups are activated and you can modify satellite information which is applied when DISEqC signal is detected from IRD. After modifying information, press 'Edit Satellite Information' button, then new information is updated in the antenna.

 Pol & Band Control – The power controls 13V, Vertical (RHCP) and18V, Horizontal (LHCP) bands. The Band controls High and Low bands. (AUTO RRECOMMEDED)

AUTO & AUTO : 13V and 18V supplied to LNB without regard to IRD. AUTO & 0KHz : Low band supplied to LNB without regard to IRD AUTO & 22KHz : High band supplied to LNB without regard to IRD.

13V & AUTO : 13V supplied to LNB without regard to IRD. 13V & 0KHz : 13V & Low band supplied to LNB without regard to IRD. 13V & 22KHz :13V & High band supplied to LNB without regard to IRD.

18V & AUTO : 18V supplied to LNB without regard to IRD. 18V & 0KHz : 18V & Low band supplied to LNB without regard to IRD. 18V & 22KHz : 18V & High band supplied to LNB without regard to IRD.

Set Tracking Information of Satellite [Secondary]

Command Button

 Edit Satellite Information – To change frequency information of the antenna.

Move Antenna and Execute Antenna Diagnosis

Angle of Antenna

Two kinds of antenna movement is available. One is to move to the target position and the other is to move by certain amount of angle. The current position (angle) of the antenna is displayed as "Current" and to move to the target position, push "Go to target Position" button after keying in desired angle into "Target". To move to a certain amount of angle only, move antenna to direction of up or down, and CW or CCW by using a substant of Line the Mover Step" box. Rotate LNB to direct the skew angle by using substant.

Self-Diagnosis

If "Diagnosis" button is pressed to carry out self- diagnosis of antenna, itdisplays the result of self-diagnosis after carrying it out. Blue circle means the antenna is normal; red represents abnormal and green represents the antenna is under diagnosis.

Command Button

- Go to Target Position To move the antenna to the present position.
- Diagnosis To diagnose the antenna (BLUE Passed, RED Failed, GREEN Under diagnosis)

64

i3/i4/i4P Satellite Antenna System – Install and User Manual

Set Antenna Parameters for Control

Command Buttons

Set Control Parameter- To register parameters values. Set Flags - To set flag setting for WRS Method or Offset Difference.

Product Information – Antenna dish size. Serial NO, Voltage for antenna and ACU, Software version for ACU and Control.

Parameter Setting – To set antenna parameter values. SCAN OFFSET : The actual angle between the marked point on sub-reflector and the datum. TRACK SCALE : To control the tracking speed while antenna is tracking the satellite. High track scale value resulting in high tracking speed. DETECT LEVEL : The basic signal tracking level ELADJUST : The mechanical totelarace compensation of elevation limit. WRS LEVEL : The basic Using and tracking level LADJUST : The mechanical totelarace compensation of elevation limit. WRS LEVEL : The basic WRS detection level. OVITAGE THRESHOLD : The value to identify Vertical/Horizontal or RHCP/LHCP DISEGC THRESHOLD : The value to identify ZXKHz tone. OFFSET DIFFERENCE : The difference value between RHCP/LHCP and SCAN OFFSET . USE OFFSET DIFFERENCE : To apply Offset Difference. Troubleshooting

Troubleshooting

Symptom		I	Pos	sible	e ca	use'		
	1	2	3	4	5	6	7	8
Antenna not functioning	Х							
No picture on TV set			Х		Х	Х		Х
Intermittent picture for short intervals		Х	Х	Х	Х	Х		Х
System works at the dock but not underway		Х						
System will not find satellite		Х	Х	Х	Х	Х	Х	Х
'Snowy' television picture				Х				

Note: * for an explanation of possible cause and their remedies refer to the following paragraphs

1. Blown fuse, low power or wiring

Check that the in-line quick blow fuse (if fitted) has not blown or the circuit breaker has not tripped. Replace fuse with one of the same type and rating. If you have extended the power cable from the antenna unit, check that there is no power loss. Check the system wiring and connections.

2. Satellite signal blocked

Satellite signals can be blocked or degraded by buildings, other boats or equipment on your boat. Check to see if the antenna has a clear view of the sky.

3. Outside satellite coverage zone

Your system will provide excellent reception within the antenna coverage area for your satellite television service. However, signal quality may degrade as you approach the edges of this zone.

4. Radar interference

The energy levels radiated by radar units can overload the antenna a front-end circuits. Make sure that your antenna is installed as described in page 8; 'Selection of Installation Site'.

5. Incorrect or loose RF connectors

As part of the regular maintenance recommended by Intellian Technologies, Inc., all connections should be checked to ensure that they have not become loose. A loose RF connector can reduce signal quality.

6. Multi-switch interference

If you have multiple satellite receiver (IRD) connected to your system, make sure that you are using an active not passive multi-switch.

66

i3/i4/i4P Satellite Antenna System – Install and User Manual

7. Satellite receiver (IRD) troubleshooting

Your satellite receiver (IRD) may be the cause of less than ideal operation.

- Check the satellite receiver's (IRD's) configuration to ensure that it is programmed for the area in which you are operation.
- 2) Unplug the satellite receiver (IRD) from the power supply for 1 second. Reconnect and allow the system to initialize.

8. LNB fault

If you have an LNB fault, it may require replacing. Contact your local dealer, national distributor or Intellian Technologies, Inc. product support for further assistance.

Warranty

Preparation for Transportation

This is to describe how to fix the antenna internally for transportation, and the following procedures to fix antenna shall be strictly observed to protect it from being damaged during transportation.

1. Refer to the drawing given below.

2. Rotate antenna left and right slowly till the limit switch is pressed.

WARNING Don't rotate it quickly, or you may damage the antenna limit system.

- 3. Turn the antenna by 360 $^\circ\,$ to the reverse direction.
- 5. Insert the sponge in both sides of the dish to fix the pedestal in position with the bottom radome.
- Cover upper part of radome being careful for it's not touching the reflector, and then assemble upper part of radome.
- 7. Pack Intellian i3/i4/i4P into the original package box.

i3/i4/i4P Satellite Antenna System - Install and User Manual

Warranty

This product is guaranteed by Intellian Technologies Inc., against defect due to faulty workmanship or materials and this guarantee covers for 2-year parts and 1-year labor for labor performed at Intellian Technologies, Inc. service center from the date of purchase of the product.

You are requested to present a copy of the purchase receipt issued by Intellian Technologies, Inc. that presents the date of purchase for after sales service under warranty. In case of failure to present the date of purchase, the warranty period is to be calculated to 30 days after the manufacturing production date.

If you discover a defect, Intellian Technologies, Inc. will, at its option, repair, replace or refund the purchase price of the product at no charge to you, provided you return it during the warranty period, transportation charges prepaid, to the factory direct. Please attach your name, address, telephone number, a description of the problem and a copy of the bill of sale or sales receipt as proof of date of original retail purchase, to each product returned to warranty service. Alternatively, you may bring the product to an Authorized Intellian Technologies, Inc. dealer/distributor for repair.

This Limited Warranty does not apply if the product has been damaged by accident, abuse, misuse or misapplication or has been modified without the written permission of Intellian Technologies, Inc.; if any Intellian Technologies, Inc. serial number has been removed or defaced; or if any factory-sealed part of the system has been opened without authorization.

Appendix : Technical specification

Intellian i4/i4P

General

Approvals CE – conforms to FCC – verified to	EU Directive 89/336/EEC CFR47:Part 15
Dimensions Satellite antenna unit Antenna dish diameter Antenna control unit	50cm(19.7") x 54cm(21.2") 45cm(17.7") 17.8cm(7")x21.6cm(8.5")x5.38cm(2.1")
Weight Satellite antenna unit Antenna control unit	11.6kg (21.5 lbs) 1.2kg (2.6 lbs)
Environmental Operating temperature range Storage temperature range Humidity limit	-15°C to + 55°C -25°C to + 70°C 95% R.H
Operating voltage	10.8 ~ 15.6 V DC
Power consumption	Typ. 30W, Max. 50W

Antenna system performance

Frequency	Ku-band(10.7 to 12.75 GHz)
Minimum EIRP	49dBW
Azimuth range	680°
Elevation range	0° ~ +90°
Ship's motion	Roll ±25° Pitch ±15°
Roll and pitch response rate	50° / second
Turn rate	50° / second

i3/i4/i4P Satellite Antenna System – Install and User manual

Intellian i3

General	
Approvals CE – conforms to FCC – verified to	EU Directive 89/336/EEC CFR47:Part 15
Dimensions Satellite antenna unit Antenna dish diameter Antenna control unit	43cm (17") x 44cm(17.3") 37cm(14.6") 17.8cm(7")x21.68cm(8.5")x5.38cm(2.1")
Weight Satellite antenna unit Antenna control unit	9kg (19.8 lbs) 1.2kg (2.6 lbs)
Environmental Operating temperature range Storage temperature range Humidity limit	-15°C to + 55°C -25°C to + 70°C 95% R.H
Operating voltage	10.8 ~ 15.6 V DC
Power consumption	Typ. 30W, Max. 50W

Antenna system performance

Frequency	Ku-band(10.7 to 12.75 GHz)
Minimum EIRP	50dBW
Azimuth range	680°
Elevation range	+10° ~ +80°
Ship's motion	Roll ±25° Pitch ±15°
Roll and pitch response rate	60° / second
Turn rate	60° / second

71

Intellian Technologies, Inc.

- HQ Dongik Building 7th Flr., 98 Nonhyun-Dong, Gangnam-gu, Seoul 135-010, Korea Tel : +82-2-515-4923 Fax: +82-2-545-4903
- Factory SK Ventium 104-501, 522 Dangieong-Dong, Gunpo-Si, Kyunggi-Do 435-776, Korea Phone: +82-31-436-1488 Fax: +82-31-436-1489
- R&D Center SK Ventium 104-601, 522 Dangjeong-Dong, Gunpo-Si, Kyunggi-Do 435-776, Korea Phone: +82-31-436-2280 Fax: +82-31-436-2284

Intellian Technologies USA, Inc.

9261 Irvine Blvd. Irvine, CA 92618 USA Phone: +1-949-916-4411 Fax: +1-949-271-4183

E-Mail : customersupport@Intelliantech.com Homepage : http://www.Intelliantech.com