Please read this supplement to the CH500/600 8" Manual first.

FURUND CH500/600 Searchlight Sonar



Important Technical Installation Information

The following checklist and information sheets are provided to help you efficiently install your CH500/CH600 Sonar. If this is a high speed vessel, please pay careful attention to the tube length and fairing instructions.

Sonar Installation Supplement Contents

The following checklist and information sheets are provided to help you properly and efficiently install your Sonar. If this is a high speed vessel, please pay careful attention to the tube length and fairing instructions.

Page

- 1-2 Overall installation checklist Please return a completed copy to Furuno U.S.A.
- *3* Fiberglass (FRP) Sonar tube installation outline drawing
- 4-6 High speed hull, Sonar tube fairing pictures with comment
- 7 Tank guide assembly installation and adjustment instructions
- 8 Longer interconnect cables
- 8 Soundome cover and oil installation reminder
- 9 Tank gasket installation
- 9 Check soundome when in drydock

Please feel free to contact us with any questions that you may have. Additional information such as this may be found on our web site www.FurunoUSA.com.

Sonar Installation Check Sheet


Vessel Information	System Information				
Туре:	Use:	Serial Num	ber:		
Length:	Registry:	Shaft Trave			
Operating Speed:	Hull Type:	System Inp			
Dealer Information					
Dealer Name:					
Date:	Location:				
Standard System - MU121C	Display Check List				
Are all cables and connection	🖵 Yes	🖵 No			
Is NMEA data connected ar What NMEA devices are co	🖵 Yes	🖵 No			
	n & operation been checked?	🖵 Yes	🖵 No		
Is the unit grounded properl	•	🖵 Yes	🖵 No		
C	,				
OR					
Black Box System – HDMI I	Display Check List				
Are all cables and connection	ons tight & strapped?	🖵 Yes	🖵 No		
Does the monitor display the	e correct color palette?	🖵 Yes	🖵 No		
Is NMEA data connected ar What NMEA devices are co	Yes	🖵 No			
Has control head installatio	n & operation been checked?	🖵 Yes	🖵 No		
Is the unit grounded properl	-	🖵 Yes	🖵 No		
CH503 Transceiver Unit Che	ck List				
Are all cables and connection	ons tight & strapped?	🖵 Yes	🖵 No		
Check and note actual input	t voltage				
Is the unit grounded properl	🖵 Yes	🖵 No			
Motion Sensor Check List					
Has the motion sensor head	ding offset been adjusted?	🖵 Yes	🖵 No		
If the hoist control box is no	t attached to the hoist, has				
the heading, pitch and roll o	ffsets been adjusted?	🖵 Yes	🖵 No		
Sonar Tube Installation Chec	ck List				
Was a Furuno supplied Son	🖵 Yes	🖵 No			
If not, what was the ID of th					
What is the actual length of					
Where is the Sonar tube mo					
Is the Sonar tube on or off t		On Di Vere			
Has a Sonar tube air ventin		☐ Yes	🖵 No		
Has a forward Sonar tube fa	airing been installed?	🖵 Yes	🖵 No	D	

Has a forward Sonar tube fairing been installed?

Sonar Installation Check Sheet - continued

Hull Unit Check List						
Check and note actual input voltage:						
Are all cables and connections tight and strapped?	❑ Yes	🖵 No				
Is the unit grounded properly?	🖵 Yes	🖵 No				
Has the soundome been lowered and raised by hand?	🖵 Yes	🖵 No				
Have the shaft guides been adjusted for 0.5mm tolerance?	🖵 Yes	🖵 No				
Does the shaft have a heading mark inscribed?	🖵 Yes	🖵 No				
Is the soundome 1/2" up, in the Sonar tube when retracted?	🖵 Yes	🖵 No				
Has epoxy been used on shaft threads?	🖵 Yes	🖵 No				
Has Kinoruster been used?	🖵 Yes	🖵 No				
Has soundome packing sponge been removed?	🖵 Yes	🖵 No				
Was oil added to the soundome?	🖵 Yes	🖵 No				
CAUTION - Do not lay soundome on its side once oil has been added						
Are all the soundome capscrews tight?	❑ Yes	□ No				
Have 3 layers of greased cotton packing been used?	☐ Yes	□ No				
Is the safety clamp installed and tightened?	❑ Yes	🖵 No				
Accessories Check List - if applicable						
Checked operation of the CA-151S external speaker?	s 🛄 No					
Checked operation of the CH256 handheld remote control?	🖵 Yes	🖵 No				
Sea Trial Check List						
Date: Location:						
Operator:						
System Frequency: Sea conditions:						
Maximum detection range for the sea-bottom:						
Maximum detection range for fish targets: Has the Sonar picture been checked for alignment?	☐ Yes	🖵 No				
Has the auto-retraction feature been checked?						
Have the system manuals been given to the operator?		□ No				
Was any hoist movement noted at maximum speed?	🖵 Yes	🖵 No				
Operator Training						
Date: Location:						
Trainer:						
Training provided for:						
Necessary Follow-up						
Required for:						
When:						
Warranty Card Completed and Sent to Furuno USA						
Date:						

Drawing for keel installation only.



Standard tank length is 1 meter. Minimum tank length is 26 inches or 660mm.


単位 UNI	T:mm_	品番 ITEM	品名 NAME	材 MATE	質 RIAL	数量 Q′TY	図 番 DWG.NO.	摘 要 REMARKS
承認 APPROVED	5 2		角 法 GLE PROJECTION	名 称 TITLE	^務 TLE FRP製格納タンク外観図 FRP RETRACTION TANK			
検 図 CHECKED	July 18.75 Dela	尺度 SCALE	1/5			· Martin - Martine - Martine	DRAWING	
and the second s	July · 18 · 128 M. Mules	重量 WEIGHT	1000mm: 20kg 1800mm: 27kg	図 著 DWG.NO.		C1229	Э-007-Е	
		1 N N		-				


FURUNO ELECTRIC CO., LTD.

Sonar tube fairings for high speed vessels

Today, many Sonar hull tubes have to be placed in the forward part of the vessel. This location almost guarantees underway turbulence. Although a poor location, space limitations usually make it the only site available for the hull tube and hoist. As the installation manual shows, the best location is always one third to one half way back from the bow. This is okay, because a bit of prior planning and on - site fabrication will allow a very successful installation on a fast, planing hull vessel. When the vessel's bow rises or she is on a plane, you must prevent the hull tube rear wall from becoming a large water scoop. A simple but effective fairing must be constructed. The fairing routes (diverts) the water flow away from the tube opening, preventing it from striking the tube's rear wall. The same principles applicable for bow thruster installations are true for any Sonar hull tube.

Properly sized and shaped, the fairing will minimize turbulence and destructive soundome or shaft movement. Some vessels may require several fairing size and shape adjustments to be absolutely successful. Pictures of several typical, successful fairings are attached for your information and use. A carefully fitted installation will insure you many years of reliable, trouble free Sonar operation.









Instructions for modifying tank guide

1. As shown in the drawing below, confirm that the narrowest gap between the tank guide assy. and retraction tank in the slide range (20-170 mm) is within 0.5 mm.



- 2. If the gap at a side is more than 0.5 mm, install a shim to make the gap within 0.5 mm.
 - 2-1. Unscrew four M10X50 bolts.
 - 2-2. Unscrew four countersunk screws, then attach the shim with the countersunk screws as shown below.



3. Unscrew four M10X70 bolts, then fasten the tank guide to the neck of the main shaft as shown in the installation manual.

Longer Interconnect Cables

If a longer interconnect cable assembly is required, the following options are available:

Soundome Cover Removal and Replacement

Remember to detach or replace the soundome cover assembly, ONLY remove the 10 stainless steel Allen head cap screws! *These are the cap screws that hold the soundome cover assembly to the upper bronze housing*.

<u>The plastic cover cross head screws should never be touched!</u> This cover has been factory sealed and cannot be replaced in the field without destroying the soundome's watertight integrity and warranty.


Once the soundome has been filled with oil, keep it in a vertical position to prevent any internal seepage. If the soundome assembly has to be removed for repair or shipment, the oil must always be removed. You may wish to retain the soundome packing material for future use.

Clean surface of gasket, tank flange and shaft sleeve.

IMPORTANT

Normally a clean flange gasket is enough for a water tight seal. For added protection you may add an 1/16" bead of THREE BOND 1104.

Warning: Using an excessive amount of THREE BOND can distort the flange gasket and in some cases permanently attach the sonar flange to the retraction tank.



Check Soundome When In Dry Dock

When the vessel is dry-docked, check for any signs of corrosion on the Soundome. Find the reason for the corrosion and as necessary attach a zinc plate to the hull unit as an anticorrosion measure.

Please feel free to call us at (360) 834-9300 or visit us on the web at www.FurunoUSA.com if you have any additional questions.

Thank you for purchasing the CH500/600 Searchlight Sonar System!

Furuno U.S.A., Inc.

© 2018 Furuno USA, Inc. All rights reserved.